

ProCase PC-08360372

ProCase Smart Case for iPad 9.7 Inch (6th/5th Generation)

INSTRUCTION MANUAL

Model: PC-08360372

1. INTRODUCTION

This manual provides essential information for the proper use and care of your ProCase Smart Case. Designed to protect your iPad 9.7 Inch, this case offers functionality and durability. Please read these instructions carefully to ensure optimal performance and longevity of your product.

2. COMPATIBILITY

The ProCase Smart Case is specifically designed for the following iPad models:

- iPad 9.7 Inch 2018 (6th Generation): Model numbers A1893, A1954
- iPad 9.7 Inch 2017 (5th Generation): Model numbers A1822, A1823

To verify your iPad model number, check the back bottom of your device for the 'Axxxx' designation.

Compatibility

Only Fits for: iPad 9.7" 6th Gen 2018 / 5th Gen 2017

iPad 6th Gen 9.7" (2018)	A1893/A1954	✓
iPad 5th Gen 9.7" (2017)	A1822/A1823	✓



Find your iPad model here



Figure 1: Compatibility chart showing supported iPad 9.7 Inch models and their corresponding model numbers.

3. KEY FEATURES

- **Ultra Slim and Lightweight Design:** The case adds minimal bulk to your device, ensuring portability and comfortable handling.
- **Translucent Frosted Back Cover:** This design allows the Apple icon to be visible while protecting your iPad against fingerprints and scratches.
- **Precise Cutouts:** Full access to all ports, buttons, cameras, and speakers without removing the case.
- **Auto Sleep/Wake Function:** Magnets within the cover automatically wake your iPad when opened and put it to sleep when closed, conserving battery life.
- **Multi-Angle Stand:** The foldable front cover transforms into a stand, offering two distinct viewing angles for typing or media consumption.
- **Magnetic Closure:** Ensures the case remains securely closed, protecting the screen when not in use.

4. SETUP AND INSTALLATION

To install your ProCase Smart Case:

1. Ensure your iPad is clean and free of dust or debris.
2. Gently align your iPad with the hard back shell of the case.
3. Press down firmly on each corner of the iPad until it snaps securely into place within the case.
Ensure all edges are fully seated.

The precise cutouts ensure that all features remain accessible after installation.




Figure 2: Illustration of precise cutouts for full access to iPad features.

5. OPERATING INSTRUCTIONS

5.1. Using the Stand Function

The tri-fold front cover allows for versatile viewing angles:

- **Viewing Angle:** Fold the front cover into a triangular stand to prop up your iPad for watching videos or making video calls.
- **Typing Angle:** Fold the cover into a lower angle, ideal for comfortable typing or drawing.

TWO ANGLE VIEW

Foldable cover offers sturdy stand for viewing typing.



Viewing
angle



Typing
angle ↓



Figure 3: Demonstrates the two available stand angles for optimal viewing and typing.

5.2. Auto Sleep/Wake

The integrated magnets in the front cover enable the auto sleep/wake feature:

- Opening the cover will automatically wake your iPad.
- Closing the cover will automatically put your iPad to sleep.

This feature helps extend your iPad's battery life and provides quick access to your device.



Figure 4: Visual representation of the auto sleep/wake functionality.

6. MAINTENANCE

To keep your ProCase Smart Case in optimal condition:

- Wipe the exterior with a soft, damp cloth to remove dust and fingerprints.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.
- Ensure the case is completely dry before reattaching your iPad.



TRANSLUCENT COVER DESIGN

Matte finish exterior, will prevent fingerprints and scratches



Figure 5: The translucent frosted back cover is designed to resist fingerprints and scratches.

7. TROUBLESHOOTING

If you encounter any issues with your ProCase Smart Case, consider the following:

- **Case not fitting correctly:** Double-check your iPad model number against the compatibility list in Section 2. Ensure all corners are pressed firmly into the case.
- **Auto Sleep/Wake not working:** Verify that the case is properly aligned and fully closed. Ensure your iPad's settings for 'Lock/Unlock' are enabled (Settings > Display & Brightness > Lock/Unlock).
- **Difficulty accessing ports/buttons:** Confirm the iPad is correctly seated within the case, aligning with all cutouts.

For further assistance, please contact ProCase customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	ProCase

Feature	Detail
Model Number	PC-08360372
Compatible Devices	Apple iPad 9.7 inch 2018 6th Generation (A1893 A1954), 2017 5th Generation (A1822 A1823)
Item Weight	5 ounces
Product Dimensions	9.7 x 6.7 x 0.3 inches
Form Factor	Case
Shell Type	Hard
Color	Black

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your ProCase Smart Case, please refer to the official ProCase website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Contact Information: [Visit the ProCase Store on Amazon](#)