

Sunjoy 110109268

Sunjoy Replacement Canopy for Aspen Sling Bar

INSTRUCTION MANUAL

Product Overview

This manual provides essential information for the installation, operation, and maintenance of your Sunjoy Replacement Canopy for Aspen Sling Bar. This canopy is designed to replace an existing canopy on the Aspen Sling Bar structure, offering renewed shade and protection.

The replacement canopy is made from 100% durable polyester, engineered for weather resistance and ease of cleaning, ensuring a long lifespan for your outdoor bar setup.

Setup and Installation

The Sunjoy Replacement Canopy (Part Number S DN012 T L) is designed for universal fit with the Aspen Sling Bar. Assembly is required for proper installation.



Image: The Sunjoy Aspen Sling Bar with the replacement canopy fully installed, providing shade over the bar area in an outdoor setting.

- 1. Preparation:** Ensure the existing Aspen Sling Bar frame is clean and free of debris. If an old canopy is present, carefully remove it from the frame.
- 2. Unpack the Canopy:** Gently unroll and inspect the new replacement canopy for any shipping damage or defects.
- 3. Identify Attachment Points:** Locate the attachment points on the Aspen Sling Bar frame where the canopy will be secured. These typically include corner pockets or straps.
- 4. Install the Canopy:**
 - Begin by sliding the canopy fabric onto the frame's support rods or into the designated corner pockets.
 - Work systematically, attaching one corner or side at a time, ensuring the fabric is evenly distributed and taut.
 - Secure all attachment points according to the design of your Aspen Sling Bar frame. This may involve tying straps, snapping buckles, or inserting rods into sleeves.
- 5. Final Adjustment:** Once installed, gently pull on the canopy fabric to ensure it is stretched smoothly and securely over the frame, providing optimal coverage.

For detailed assembly instructions specific to your Aspen Sling Bar frame, please refer to the original manual provided with the bar unit.

Operation and Use

The Sunjoy Replacement Canopy is designed to provide shade and protection from light weather conditions for your Aspen Sling Bar. Its durable, weather-resistant polyester fabric ensures reliable performance in outdoor environments.

- Shade Provision:** The canopy effectively blocks direct sunlight, creating a comfortable shaded area for your outdoor activities.
- Weather Resistance:** While resistant to light rain and general outdoor elements, it is recommended to remove the canopy during strong winds, heavy rainfall, or snow to prevent damage to both the canopy and the bar structure.

Maintenance and Care

Maintaining your Sunjoy Replacement Canopy is simple due to its low-maintenance and easy-to-clean polyester fabric.

- Regular Cleaning:** To remove dust, dirt, or light stains, wipe the canopy fabric with a damp cloth and mild soap solution. Rinse thoroughly with clean water.
- Drying:** Allow the canopy to air dry completely before folding or storing to prevent mildew growth.
- Stain Removal:** For stubborn stains, a soft brush can be used with the mild soap solution. Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric.
- Seasonal Storage:** During off-seasons or periods of prolonged non-use, it is advisable to remove the canopy and store it in a clean, dry place to extend its lifespan.

Troubleshooting

Here are some common issues and their potential solutions:

- **Canopy does not fit properly:**

Ensure you have the correct replacement part (S DN012 T L) for your Aspen Sling Bar. Double-check that the canopy is oriented correctly and all attachment points are aligned before attempting to secure it fully.

- **Fabric appears wrinkled or saggy:**

Ensure the canopy is stretched tautly across all support rods and secured firmly at all attachment points. Minor wrinkles may smooth out over time with exposure to sunlight.

- **Water pooling on canopy:**

This indicates improper tension or an uneven frame. Re-adjust the canopy to ensure it is taut and slopes slightly to allow water runoff. Check the Aspen Sling Bar frame for levelness.

Specifications

Attribute	Detail
Brand	Sunjoy
Model Number	110109268
Part Number	S DN012 T L (Aftermarket/Generic)
Material	100% Durable Polyester
Fabric Type	Polyester 276%
Product Dimensions	139.7 x 132.08 x 85.09 cm (55 x 52 x 33.5 inches)
Item Weight	0.36 kg (0.8 Pounds)
Assembly Required	Yes
UPC	841057133798
ASIN	B06XTCBBQJ

Warranty and Support

For specific warranty information regarding your Sunjoy Replacement Canopy, please refer to the documentation provided at the time of purchase or contact Sunjoy customer service directly. As this is an aftermarket/generic replacement part, warranty terms may vary.

If you encounter any issues not covered in this manual or require further assistance, please contact the retailer from whom you purchased the product or the manufacturer, Sunjoy, for support.