

Datel EF001205

Datel Action Replay PowerSaves Amiibo Portal Instruction Manual

Model: EF001205

1. INTRODUCTION

The Datel Action Replay PowerSaves Amiibo Portal is a device designed to enhance and manage your Amiibo character data. It allows users to back up existing Amiibo saves, apply game-boosting profiles, and utilize POWERTAGS to store and transfer Amiibo data, providing expanded functionality for your Amiibo collection.

2. PRODUCT OVERVIEW

The PowerSaves system consists of the main PowerSaves portal device, a USB connection cable, and one or more POWERTAGS. These components work together to interact with your Amiibo figures and manage their data.



Image 2.1: The Datel Action Replay PowerSaves device, a white rectangular unit with a target logo, shown alongside a black POWERTAG and a USB cable. This image displays the core components included with the product.



Image 2.2: Front view of the retail packaging for Datel Action Replay PowerSaves, highlighting its compatibility with all Amiibo characters and its ability to add extra powers.



Image 2.3: Rear view of the retail packaging for Datel Action Replay PowerSaves, detailing features such as backing up Amiibo saves, restoring characters, and using POWERTAG for new saves.

3. SETUP

1. **Software Installation:** Download and install the official Datel PowerSaves software for Amiibo from the manufacturer's website. Ensure your computer meets the minimum system requirements.
2. **Connect the Device:** Connect the Datel Action Replay PowerSaves portal to your computer using the provided USB cable. The device should be recognized by your operating system.
3. **Launch Software:** Open the installed PowerSaves software. The software should detect the connected PowerSaves portal.
4. **Account Creation/Login:** Follow any on-screen prompts to create an account or log in, if required by the software.

4. OPERATING INSTRUCTIONS

The PowerSaves system allows for various interactions with your Amiibo figures and POWERTAGS.

4.1. Backing Up Amiibo Data

1. Place your Amiibo figure directly onto the PowerSaves portal. The software will instantly recognize the Amiibo.
2. Within the software interface, locate the option to "Backup" or "Save Data."
3. Select a location on your computer to save the Amiibo's data file. This creates a digital copy of your Amiibo's current state.

4.2. Applying Game-Boosting Profiles

1. Place your Amiibo figure onto the PowerSaves portal.
2. Browse the available game-boosting profiles within the PowerSaves software. These profiles offer various enhancements for your Amiibo characters in compatible games.
3. Select the desired profile and choose the "Boost" or "Apply" option. The software will write the selected enhancements to your Amiibo.

4.3. Using POWERTAGS

POWERTAGS are reusable NFC tags that can store Amiibo data, allowing you to use different Amiibo profiles without needing the physical figures. They are particularly useful for trying out new saves or managing multiple character configurations.

1. Writing Data to a POWERTAG:

- Place a blank or existing POWERTAG onto the PowerSaves portal.
- Select an Amiibo data file (either a backed-up file or a downloaded profile) from your computer within the software.
- Choose the option to "Write to POWERTAG" or "Restore." The selected data will be transferred to the POWERTAG.

2. **Using a POWERTAG in-game:** Once data is written to a POWERTAG, it functions identically to a physical Amiibo figure for compatible games. Simply place the POWERTAG on your game console's NFC reader.

5. MAINTENANCE

To ensure the longevity and proper functioning of your Datel Action Replay PowerSaves device:

- Keep the device and POWERTAGS clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the device to extreme temperatures, moisture, or direct sunlight.
- Handle the USB cable with care to prevent damage to the connectors.
- Store the device and POWERTAGS in a safe place when not in use to prevent physical damage.

6. TROUBLESHOOTING

6.1. Device Not Recognized by Computer/Software

- **Check USB Connection:** Ensure the USB cable is securely connected to both the PowerSaves portal and your computer. Try a different USB port.
- **Restart Software/Computer:** Close and reopen the PowerSaves software. If the issue persists, restart your computer.
- **Reinstall Drivers/Software:** If the device is still not recognized, try uninstalling and reinstalling the PowerSaves software and any associated drivers.

6.2. Amiibo/POWERTAG Not Registering on Portal

- **Proper Placement:** Ensure the Amiibo figure or POWERTAG is placed centrally and flat on the PowerSaves portal.
- **Clean Contact Surface:** Check for any debris or obstructions on the portal's surface or the Amiibo/POWERTAG.
- **Software Status:** Verify that the PowerSaves software is running and ready to detect an Amiibo.

6.3. Amiibo Files Not Displaying in Software (PC Specific)

If you are manually placing Amiibo data files (.bin files) on your PC and they are not appearing in the PowerSaves software, ensure they are in the correct directory:

- The correct path for Amiibo files on a PC is typically: **C:/Users/(YOUR USERNAME)/Powersaves For AMIIBO**
- Do **NOT** place files in **C:/Program Files/Powersaves For AMIIBO**.
- If the "Powersaves For AMIIBO" folder does not exist in your user directory, you may need to create it manually or perform an initial backup of an Amiibo to have the software create it.




7. SPECIFICATIONS

- **Model Number:** EF001205
- **Manufacturer:** Datel
- **Product Dimensions:** 6 x 4 x 1.5 inches
- **Item Weight:** 1.1 pounds
- **Type of Item:** Accessory
- **Language:** English
- **Date First Available:** March 25, 2017

8. WARRANTY AND SUPPORT

Specific warranty information for the Datel Action Replay PowerSaves device is typically provided at the point of purchase or within the product packaging. For detailed warranty terms, please refer to the documentation included with your product or contact Datel customer support directly.

For technical support, software updates, or further assistance, please visit the official Datel website or contact their customer service department. Keep your product model number (EF001205) and purchase details ready when seeking support.

	<p>Xero Wireless Controller for PS5: User Guide, Setup, and Features</p> <p>Comprehensive guide for the Xero Wireless Controller for PlayStation 5. Learn how to connect, charge, use features like button remapping and profile management, and find maintenance tips.</p>
	<p>Xero Wireless Controller for PS5 User Guide</p> <p>Comprehensive user guide for the Xero Wireless Controller for PS5, detailing setup, connection, charging, controller functions, remapping, profiles, and maintenance.</p>
	<p>CU Amiga Magazine: Desktop Publishing, Games & Hardware Guide (October 1995)</p> <p>Explore the October 1995 issue of CU Amiga Magazine, featuring 'Desktop Dreams' on DTP with PageStream 2.2, in-depth guides to mass storage devices, game reviews and previews, and a comprehensive look at Amiga hardware and peripherals from leading manufacturers.</p>