

Sharp PNC805B

Sharp 80-inch Interactive Display System (PNC805B) User Manual

Model: PNC805B

1. INTRODUCTION

This user manual provides essential instructions for the safe and effective use of your Sharp 80-inch Interactive Display System, model PNC805B. This interactive display is designed to facilitate engaging meetings, presentations, and educational lessons through its advanced features and intuitive interface. Please read this manual thoroughly before operating the device and retain it for future reference.

2. PRODUCT OVERVIEW AND KEY FEATURES

The Sharp PNC805B is an 80-inch interactive display system engineered for collaborative environments. Its robust design and advanced touch technology enhance user interaction and content delivery.

Key Features:

- **Multi-User Capability:** Supports up to 4 simultaneous users for collaborative work.
- **10-Point Multi-Touch Screen:** Provides precise and responsive touch interaction.
- **Integrated Audio System:** Features built-in 10W per channel stereo audio for clear sound.
- **High-Resolution Display:** 80-inch screen with Full HD (1920x1080) resolution for crisp visuals.
- **Durable Design:** Constructed for reliable performance in various professional settings.



Figure 1: The Sharp 80-inch Interactive Display in use, demonstrating its capability to present detailed information, such as a business growth chart. The screen displays a presentation with a bar graph illustrating store expansion over time, alongside textual descriptions of key business strategies.

3. SETUP INSTRUCTIONS

3.1 Unpacking and Placement

1. Carefully remove the display from its packaging. Due to its size and weight (approximately 384 pounds), it is recommended that multiple individuals assist with unpacking and placement to prevent injury or damage.
2. Place the display on a stable, level surface or mount it securely using a compatible VESA mount (sold separately). Ensure adequate ventilation around the display.
3. Keep the display away from direct sunlight, heat sources, and areas with high humidity.

3.2 Connecting Power and Devices

1. Connect the power cord to the display's power input and then to a grounded 110V AC power outlet.
2. Connect your source device (e.g., computer, laptop) to the display using an appropriate video cable (HDMI, DisplayPort, VGA).
3. For touch functionality, connect a USB cable from your source device to the display's USB upstream port.
4. If external audio is desired, connect audio cables as needed, or rely on the display's built-in stereo speakers.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- To power on the display, press the power button located on the side or bottom bezel. The power indicator light will illuminate.
- To power off, press and hold the power button until the display shuts down.

4.2 Using Touch Functionality

- Ensure the USB cable for touch is connected between the display and your computer.
- The display supports 10-point multi-touch, allowing multiple users to interact simultaneously.
- Use your finger or a compatible stylus to tap, drag, pinch, and zoom on the screen, similar to a large tablet.

4.3 Input Source Selection

- Use the input selection button on the display's control panel or remote control to cycle through available input sources (HDMI, DisplayPort, VGA).
- Select the input corresponding to your connected source device.

5. MAINTENANCE

5.1 Cleaning the Display

- Always power off and unplug the display before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a non-abrasive, screen-safe cleaning solution.
- Gently wipe the screen and bezel. Avoid excessive moisture and harsh chemicals, which can damage the surface.

5.2 General Care

- Avoid placing heavy objects on the display or applying excessive pressure to the screen.
- Ensure proper ventilation to prevent overheating.
- Do not attempt to repair the display yourself. Refer all servicing to qualified personnel.

6. TROUBLESHOOTING

If you encounter issues with your Sharp Interactive Display, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No Power	Power cord disconnected; Power outlet faulty; Display not turned on.	Check power cord connection; Test outlet with another device; Press the power button firmly.
No Display/Image	Incorrect input source selected; Video cable loose or faulty; Source device not outputting signal.	Select correct input source; Reconnect video cable; Check source device's display settings.
Touch Function Not Working	USB touch cable disconnected; Driver issue on source device; Display in incorrect mode.	Ensure USB touch cable is securely connected; Install/update touch drivers on your computer; Restart both display and source device.
No Audio	Volume too low; Muted; Audio cable disconnected; Incorrect audio output selected on source device.	Increase volume; Unmute display/source; Check audio cable connections; Select display as audio output on source device.

7. SPECIFICATIONS

Feature	Detail
Brand	Sharp
Model Number	PNC805B
Screen Size	80 Inches
Max Screen Resolution	1920 x 1080 Pixels (FHD 1080p)
Aspect Ratio	16:9
Screen Surface Description	Glossy
Touch Technology	10-point Multi-Touch
Audio System	Built-in 10W per channel stereo audio
Item Weight	384 pounds
Product Dimensions (LxWxH)	81 x 13.8 x 50.4 inches
Voltage	110 Volts
Color	Black
First Available Date	January 10, 2017

8. IMPORTANT INFORMATION

8.1 Legal Disclaimer

Age Restriction: Purchasers must be at least 18 years of age.

Delivery Signature: All purchased orders will require a direct signature at the time of delivery.






Return Policy: This item is non-returnable. Please ensure all specifications meet your requirements before purchase.


9. SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please contact Sharp customer service or visit the official Sharp website.

- **Manufacturer:** Sharp
- **Online Resources:** Refer to the official Sharp support website for updated drivers, FAQs, and additional documentation.

Related Documents - PNC805B

	<p>SHARP PN-LM551 & PN-LM431 Interactive Touchscreen Display Setup Manual</p> <p>Get started with your SHARP PN-LM551 and PN-LM431 interactive touchscreen displays. This setup manual provides comprehensive instructions for installation, connections, safety, and operation in commercial environments.</p>
	<p>Sharp Android TV Quick Start Guide: Setup, Remote, and Specifications</p> <p>Concise guide to setting up your Sharp Android TV, including stand installation, remote control usage, connectivity options, Google Assistant setup, and technical specifications. Learn how to get started quickly.</p>
	<p>Sharp Induction Cooktop Installation Manual</p> <p>Installation manual for Sharp Induction Cooktops SCH2443GB and SCH3043GB, providing detailed instructions for electrical connection, cutout dimensions, and safety precautions.</p>
	<p>SHARP FU-NC01 Air Purifier Operation Manual</p> <p>Comprehensive operation manual for the SHARP FU-NC01 Air Purifier, covering setup, usage, maintenance, safety guidelines, and troubleshooting for optimal air purification.</p>
	<p>Sharp KI-N50/KI-N40 Air Purifier with Humidifying Function Operation Manual</p> <p>This operation manual provides detailed instructions for the Sharp KI-N50 and KI-N40 air purifiers with humidifying function, covering features, safety, operation, maintenance, and specifications.</p>

	<p>SHARP FP-K50U Air Purifier Operation Manual</p> <p>User manual for the SHARP FP-K50U Air Purifier, detailing operation, features, safety instructions, maintenance, and specifications. Available in English, French, and Spanish.</p>
---	---