

[Manuals.plus](#) /

› [Treasure Garden](#) /

› Treasure Garden 9ft Deluxe Auto-Tilt Patio Umbrella (Sunbrella Jockey Red, Black Frame) - Instruction Manual

Treasure Garden 8109-5403

Treasure Garden 9ft Deluxe Auto-Tilt Patio Umbrella

MODEL: 8109-5403

Brand: Treasure Garden

PRODUCT OVERVIEW

This manual provides instructions for the Treasure Garden 9ft Deluxe Auto-Tilt Patio Umbrella. It features a durable black aluminum frame and a Sunbrella Jockey Red canopy, designed for outdoor use. This umbrella offers significant shade coverage and an easy-to-use auto-tilt mechanism for optimal sun protection.

Key Features

- **Shade Coverage:** 9ft octagon canopy provides up to 57 sq ft of shade, suitable for dining or lounge seating.
- **Tilt Mechanism:** Features a crank-to-open system; continued cranking engages a smooth, incremental auto-tilt function to adjust shade throughout the day.
- **Sunbrella Performance Fabric:** Canopy made from genuine Sunbrella solution-dyed acrylic, offering resistance to fading and UV exposure for long-lasting color. Backed by a 5-year Sunbrella fade warranty.
- **Sturdy Build:** Constructed with a black powder-coated aluminum frame, 8 ribs, and a Kevlar mesh lift cord for enhanced strength and durability. Overall height is approximately 102.5 inches.
- **Base Compatibility:** The 1.5-inch pole diameter is compatible with most patio tables and umbrella bases. Requires a compatible 50 lb or heavier stand or weighted table base (sold separately).

SETUP INSTRUCTIONS

Carefully unpack all components and ensure all parts are present before beginning assembly. Refer to the diagram below for component identification.




Image: Fully assembled 9ft Deluxe Auto-Tilt Patio Umbrella in a garden setting.

1. **Insert Pole into Base:** Place the lower pole section into a suitable umbrella base (minimum 50 lbs, sold separately). Ensure the base is stable and secure.
2. **Attach Upper Pole:** Carefully insert the upper pole section (with the canopy attached) into the lower pole section. Align any locking buttons or pins and secure them firmly.
3. **Secure Umbrella:** Tighten any securing knobs or screws on the umbrella base to hold the pole firmly in place.




Image: Detailed diagram illustrating the dimensions of the umbrella, including height and canopy span.

OPERATING THE UMBRELLA

Opening and Closing

To open the umbrella, locate the crank handle on the pole. Turn the crank clockwise until the canopy is fully extended. To close, turn the crank counter-clockwise until the canopy is completely retracted.



Image: Close-up of the manual crank handle for operating the umbrella.

Auto-Tilt Function

The Deluxe Auto-Tilt feature allows for easy angle adjustment. Once the umbrella canopy is fully open, continue turning the crank handle in the same direction (clockwise). The canopy will begin to tilt incrementally. To return the canopy to its upright position, turn the crank counter-clockwise until it is fully closed, then begin cranking clockwise again to open it without tilt, or continue past the open position to engage the tilt in the opposite direction.



Image: The patio umbrella shown in a tilted position, demonstrating the auto-tilt feature.

CARE AND MAINTENANCE

Cleaning the Canopy

The Sunbrella fabric canopy is designed for easy care. For general cleaning, brush off loose dirt, then spray with a mild cleaning solution (e.g., 1/4 cup mild soap per gallon of lukewarm water). Use a soft brush to clean, then rinse thoroughly until all soap residue is removed. Allow the fabric to air dry completely before closing or storing the umbrella.



Image: Overhead view of the umbrella canopy, highlighting the fabric texture and color.

Frame Care

The black powder-coated aluminum frame is rust-resistant. Clean the frame periodically with a soft cloth and mild soap and water. Rinse and dry thoroughly. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.

Storage

When not in use for extended periods or during inclement weather, it is recommended to close the umbrella and secure it with a tie. For off-season storage, clean the canopy and frame, allow to dry, and store in a dry, protected area, preferably using a protective umbrella cover.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Umbrella does not open/close smoothly.	Crank mechanism obstruction or damage.	Check for debris in the mechanism. Apply silicone spray to moving parts if stiff. If damaged, contact customer support.

Problem	Possible Cause	Solution
Canopy does not tilt.	Umbrella not fully open, or mechanism issue.	Ensure the canopy is fully extended before continuing to crank for tilt. If issue persists, inspect the tilt mechanism for damage.
Umbrella is unstable.	Insufficient base weight or loose pole.	Ensure a minimum 50 lb umbrella base is used and that the pole is securely tightened within the base. Do not use in high winds.

PRODUCT SPECIFICATIONS

Feature	Detail
Product Dimensions	108 x 108 x 102.5 inches (L x W x H)
Item Weight	18 pounds
Model Number	8109-5403
Brand	Treasure Garden
Color	Sunbrella Jockey Red w/Black Frame
Material	Aluminum frame, Sunbrella acrylic canopy
Shape	Octagonal
Special Feature	UV Blocking, Auto-Tilt Mechanism

WARRANTY AND SUPPORT

Treasure Garden Deluxe Auto-Tilt frames include a 2-year limited warranty against manufacturing defects. The Sunbrella fabric canopy is backed by a 5-year Sunbrella fade warranty.



Image: Warranty information indicating a 1-year extended frame warranty for Model 810 Auto-Tilt Umbrellas with Sunbrella Fabric.

For warranty claims or technical support, please refer to the contact information provided with your product packaging or visit the official Treasure Garden website for further assistance.

