

- Manuals.plus /
- › Treasure Garden /
 - › Treasure Garden Octagonal 9 ft Patio Umbrella Instruction Manual

Treasure Garden UM9200-4822-EW

Treasure Garden Octagonal 9 ft Patio Umbrella Instruction Manual

Brand: Treasure Garden | Model: UM9200-4822-EW

INTRODUCTION AND OVERVIEW

This manual provides instructions for the assembly, operation, and maintenance of your Treasure Garden Octagonal 9 ft Patio Umbrella. Designed for outdoor use, this umbrella offers ample shade and features a durable construction for longevity.



Image: The 9 ft Octagonal Patio Umbrella providing shade.

- **Shade Coverage:** The 9 ft octagonal canopy provides up to 57 sq ft of shade, suitable for dining or lounge areas.
- **Durable Frame:** Features a rust-resistant bronze aluminum pole with 8-rib support, designed for outdoor durability.
- **Vented Canopy:** The O'bravia2 solution-dyed polyester canopy in Khaki includes a wind vent for improved airflow and stability. It resists fading and everyday outdoor wear.

SETUP AND ASSEMBLY

Follow these steps to set up your patio umbrella:

1. **Prepare the Base:** Ensure you have a suitable umbrella base. A minimum 50 lb umbrella stand is recommended for secure placement. The umbrella base is sold separately.
2. **Insert the Pole:** Carefully insert the bottom pole of the umbrella into the umbrella hole of your patio table (if applicable) and then into the umbrella base. The 1.5 inch bottom pole fits standard patio table umbrella holes.
3. **Secure the Pole:** Tighten any securing knobs on your umbrella base to hold the pole firmly in place.

9 FT MARKET UMBRELLA

Designed for relaxed outdoor dining

102.7" DIAMETER

101"
OVERALL
HEIGHT

76.7"
CLEARANCE



PERFECT FOR 4-6 PERSON DINING

Image: Dimensions of the 9 ft Octagonal Market Umbrella.

PREMIUM ALUMINUM FRAME

**Engineered Strength.
Designed to Last.**

-  Rust-Resistant
-  Lightweight Yet Strong
-  Built for Outdoor Durability



Bronze

Black

White

Available in 3 Premium Finishes

OPERATING INSTRUCTIONS

Your Treasure Garden umbrella features an easy-to-use crank and push-button tilt mechanism.

- **Opening the Umbrella:** Turn the crank handle clockwise to smoothly open the umbrella canopy until it is fully extended.
- **Closing the Umbrella:** Turn the crank handle counter-clockwise to retract the canopy until it is fully closed.
- **Tilting the Umbrella:** To adjust the shade, locate the push-button tilt mechanism on the pole. Press the button and gently tilt the canopy to your desired angle (0° to 30°). Release the button to lock the tilt into place.




Image: Push-Button Tilt mechanism for shade adjustment.

MAINTENANCE

Proper maintenance will extend the life and appearance of your umbrella.

- **Cleaning the Canopy:** The Obravia2 fabric canopy can be machine washed. Refer to the fabric care label for specific instructions.
- **Frame Care:** Clean the aluminum frame with mild soap and water. Rinse thoroughly and dry to prevent water spots.
- **Storage:** When not in use, especially during strong winds or off-season, close the umbrella and secure it. For long-term storage, consider using an umbrella cover and storing it in a dry, protected area.



Image: Premium O'bravia Fabric features.

TROUBLESHOOTING

If you encounter issues with your umbrella, consider the following:

- Umbrella Not Opening/Closing Smoothly:** Check for any obstructions in the canopy or crank mechanism. Ensure the fabric is not caught in the ribs.
- Umbrella Not Tilting:** Verify that the push-button is fully depressed when attempting to tilt. Ensure no debris is preventing the mechanism from moving freely.
- Stability Issues:** Always use a sufficiently weighted umbrella base (minimum 50 lbs). Do not use the umbrella in high winds.

SPECIFICATIONS

Brand	Treasure Garden
Model Number	UM9200-4822-EW
UPC	811605021495
Size	9-FT Push-Button-Tilt
Canopy Diameter	9 Feet
Overall Height	101 inches (approx.)
Clearance	76.7 inches (approx.)
Color	Obravia2 Khaki /Bronze Frame

Canopy Material	Obravia2 Solution-Dyed Polyester
Frame Material	Aluminum (Bronze finish)
Opening Mechanism	Crank Lift
Tilt Mechanism	Push-Button Tilt (0° to 30°)
Item Weight	16 Pounds
Recommended Uses	Outdoor, Patio, Sun Shade

WARRANTY AND SUPPORT

Your Treasure Garden umbrella is backed by the following warranties:

- **Frame Warranty:** 1-year limited warranty against manufacturing defects for push-button frames.
- **Fabric Warranty:** 4-year fade warranty for O’bravia2 solution-dyed polyester fabric.

For warranty claims or further support, please refer to the official Treasure Garden warranty documentation or contact Treasure Garden customer service directly. Contact information can typically be found on the manufacturer's website or original packaging.



Image: Summary of Treasure Garden Warranty Protection.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B06XXM4DXR>

More documents and user manuals: <https://manuals.plus/>