

## PARAMOUNT B06XXQLGPL

# Friday The 13th The Ultimate Collection - Official Instruction Manual

Brand: PARAMOUNT

## INTRODUCTION

Welcome to the official instruction manual for the Friday The 13th The Ultimate Collection DVD set. This comprehensive collection brings together eight iconic films from the legendary horror franchise, allowing you to re-experience the chilling saga of Jason Voorhees. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your DVD collection to ensure optimal viewing pleasure.

8-MOVIE COLLECTION

# FRIDAY THE 13TH



Image: The cover art for the Friday The 13th The Ultimate Collection DVD set, featuring Jason Voorhees.



## CONTENTS OF THE COLLECTION

This collection includes eight individual DVD discs, each featuring a film from the original Friday The 13th series. The films are presented in their original theatrical versions, with some discs offering additional special features.

- Friday the 13th (1980)
- Friday the 13th Part 2 (1981)
- Friday the 13th Part III (1982)
- Friday the 13th: The Final Chapter (1984)
- Friday the 13th: A New Beginning (1985)
- Friday the 13th Part VI: Jason Lives (1986)
- Friday the 13th Part VII: The New Blood (1988)
- Friday the 13th Part VIII: Jason Takes Manhattan (1989)

## SETUP

To begin enjoying your Friday The 13th collection, follow these simple setup steps:

1. **Unpack:** Carefully remove the DVD set from its packaging.
2. **Inspect Discs:** Check each of the 8 discs for any visible scratches or damage. While the discs are designed for durability, proper handling is recommended.
3. **Prepare Player:** Ensure your DVD or Blu-ray player is connected to your television and powered on.
4. **Insert Disc:** Open the disc tray of your player and gently place the desired DVD disc onto the spindle, label side facing up. Close the disc tray.
5. **Select Input:** On your television, select the correct input source (e.g., HDMI 1, AV) that corresponds to your DVD player.
6. **Start Playback:** The DVD menu should appear automatically. Use your player's remote control to navigate the menu and select "Play" to start the movie.

## OPERATING INSTRUCTIONS

Basic controls for navigating and playing your DVDs:

- **Play/Pause:** Press the "Play" button to start playback or "Pause" to temporarily stop.
- **Stop:** Press the "Stop" button to end playback and return to the main menu or stop the disc.
- **Fast Forward/Rewind:** Use the fast forward (>>) or rewind (<<) buttons to quickly scan through the movie.
- **Skip Chapter:** Use the "Next Chapter" or "Previous Chapter" buttons to jump between scenes.
- **Menu:** Press the "Menu" or "Title" button to return to the DVD's main menu.
- **Audio/Subtitles:** Most players have dedicated buttons or menu options to change audio tracks (e.g., English, French, Spanish) or enable/disable subtitles (e.g., English, French, Portuguese, Spanish).

## MAINTENANCE

Proper care will extend the life of your DVD collection:

- **Handling:** Always hold discs by their edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If a disc becomes dirty, gently wipe it with a soft, lint-free cloth (like a microfiber cloth) from the center

outwards. Do not use abrasive materials or harsh chemicals.

- **Storage:** Store discs in their original cases, away from direct sunlight, extreme temperatures, and high humidity. Keep them in a vertical position to prevent warping.
- **Avoid Scratches:** Be careful when inserting or removing discs from the player or cases to prevent scratches.

## TROUBLESHOOTING

If you encounter issues while playing your DVDs, consider the following:

Problem	Possible Cause	Solution
Disc not playing / "No Disc" error	Disc inserted incorrectly, dirty disc, or player issue.	Ensure disc is inserted correctly (label side up). Clean the disc. Try another disc to check if the player is functioning.
Skipping or Freezing	Scratched or dirty disc, or dust in player's lens.	Clean the disc thoroughly. If the problem persists with multiple discs, consider cleaning your DVD player's lens with a specialized cleaning disc.
No Audio	TV/player volume too low, incorrect audio track selected, or audio cables disconnected.	Increase volume. Check audio settings on your player/TV. Ensure audio cables are securely connected.
No Video	Incorrect TV input selected, video cables disconnected, or TV/player issue.	Select the correct TV input. Check video cables (HDMI, AV) for secure connection.

If these steps do not resolve the issue, consult your DVD player's manual or contact the player's manufacturer for further assistance.

## SPECIFICATIONS

- **Product Title:** Friday The 13th The Ultimate Collection
- **Format:** DVD
- **Number of Discs:** 8
- **MPAA Rating:** R (Restricted)
- **Run Time:** Approximately 12 hours and 16 minutes (total for all films)
- **Release Date:** May 23, 2017
- **Studio:** PARAMOUNT
- **Languages:** English (original), French (dubbed), Spanish (dubbed)
- **Subtitles:** English, French, Portuguese, Spanish
- **Product Dimensions:** 0.7 x 7.5 x 5.4 inches
- **Weight:** 8.48 ounces
- **ASIN:** B06XXQLGPL

## WARRANTY AND SUPPORT

Specific warranty information for this DVD collection is typically provided by the retailer or the distributor at the time of purchase. Please refer to your purchase receipt or the product packaging for details regarding returns, exchanges, or warranty claims. For technical support related to playback, please consult the user manual of your DVD or Blu-ray player.

## Related Documents - B06XXQLGPL

	<p><a href="#">Scream The Game: Official Instructions and Rules</a></p> <p>Learn how to play Scream The Game, a cooperative, real-time board game based on the popular horror franchise. This guide covers setup, gameplay, winning conditions, and special Ghost Face events.</p>
	<p><a href="#">TELUS Optik TV Channel Guide</a></p> <p>A comprehensive guide to TELUS Optik TV channels, detailing essential and premium channel listings across various categories and regions, including music and radio.</p>
	<p><a href="#">Peerless-AV Paramount Articulating Wall Mount Installation Guide</a></p> <p>Comprehensive installation guide for the Peerless-AV Paramount Articulating Wall Mount, supporting displays from 39 to 90 inches. Includes detailed instructions, safety warnings, and parts list for secure wall mounting.</p>
	<p><a href="#">Bison Workwear Product Guide Edition 2.0</a></p> <p>Explore the comprehensive Bison Workwear Product Guide Edition 2.0, featuring a wide range of safety apparel, rainwear, overalls, and food industry garments designed for durability and protection. Discover Bison's commitment to innovation, sustainability, and quality, with detailed product information, standards, and care instructions.</p>
	<p><a href="#">LSTN Paramount Soundbar User Manual</a></p> <p>User manual for the LSTN Paramount Soundbar, covering setup, connections, remote control operation, troubleshooting, and specifications.</p>

This manual provides instructions for the safe and proper use and operation of the Paramount Bed Air Mattress cococia Fūka. It covers intended use, part names, safety precautions, functions, installation, maintenance, troubleshooting, storage, specifications, and after-sales service.