

[Manuals.plus](#) /

› [Mercana](#) /

› Mercana Art Decor 65273 Chandelier Instruction Manual

Mercana 65273

Mercana Art Decor 65273 Chandelier Instruction Manual

Model: 65273

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Mercana Art Decor 65273 Chandelier. This spherical hanging metal light fixture features elegant wooden bead details and requires six E26 standard bulbs (not included), each up to 60 watts. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Mercana Art Decor 65273 Chandelier, showcasing its design and scale in a typical room setting.

SAFETY INFORMATION

WARNING: Risk of Electric Shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is intended for indoor use only.

- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulbs (60 watts per bulb).
- Handle glass components and bulbs with care.
- Keep flammable materials away from the light fixture.

PACKAGE CONTENTS

Carefully unpack your chandelier and ensure all parts are present. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer service for assistance.

- Chandelier Frame with Wooden Beads
- Mounting Hardware (Canopy, Mounting Plate, Screws, Wire Nuts)
- Chain (pre-attached or separate, depending on model variation)
- Instruction Manual

Note: Six E26 standard bulbs are not included and must be purchased separately.

TOOLS REQUIRED FOR INSTALLATION

- Phillips Head Screwdriver
- Flat Head Screwdriver
- Wire Strippers
- Pliers (for chain adjustment)
- Electrical Tape
- Ladder
- Safety Glasses

SETUP AND INSTALLATION

Follow these steps carefully to install your Mercana Art Decor 65273 Chandelier. Professional installation is recommended if you are unsure about any steps.

Step 1: Prepare for Installation

1. **Turn off power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where you will be installing the fixture. This is a critical safety step.
2. **Unpack components:** Carefully remove all parts from the packaging. Place them on a clean, flat surface to avoid scratches or damage.

Step 2: Attach Mounting Plate and Adjust Chain

1. Attach the mounting plate to the ceiling junction box using the screws provided. Ensure it is securely fastened and can support the fixture's weight.
2. Adjust the length of the hanging chain to your desired height. Use pliers to open and close chain links as needed to shorten or lengthen.



Image: The ceiling canopy and chain mechanism, illustrating how the fixture connects to the ceiling.

Step 3: Wire the Fixture

1. Carefully thread the fixture's electrical wires through the chain and canopy.
2. Connect the fixture's ground wire (typically bare copper or green insulated) to the house ground wire (typically bare copper or green insulated) using a wire nut.
3. Connect the fixture's hot wire (typically black insulated) to the house hot wire (typically black insulated) using a wire nut.
4. Connect the fixture's neutral wire (typically white insulated) to the house neutral wire (typically white insulated) using a wire nut.
5. Ensure all wire connections are secure. You may wrap wire nuts with electrical tape for added security.

Step 4: Secure the Canopy

1. Carefully push the wired connections and excess wire into the junction box.
2. Raise the canopy to the ceiling and secure it to the mounting plate using the provided screws or decorative nuts.

Step 5: Install Bulbs

1. Screw six E26 standard bulbs (not included) into the sockets. Do not exceed 60 watts per bulb. Ensure bulbs are fully seated but do not overtighten.



Image: Detailed view of the bulb sockets and the decorative wooden bead design on the chandelier's frame.



Image: An alternative close-up highlighting the gold-finished metal frame and the placement of the bulb holders.

OPERATING INSTRUCTIONS

Once the chandelier is fully installed and bulbs are securely in place:

1. **Restore Power:** Return to the circuit breaker or fuse box and turn the power back on to the junction box.
2. **Test Fixture:** Use the wall switch to turn the chandelier on and off to ensure proper operation.

The Mercana Art Decor 65273 Chandelier is designed for standard on/off operation via a wall switch. If using a dimmer switch, ensure it is compatible with the type of bulbs installed (e.g., incandescent, dimmable LED) to avoid flickering or damage.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:** Always disconnect power at the circuit breaker before cleaning. Use a soft, dry, lint-free cloth to gently wipe the metal frame and wooden beads. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or beads.
- **Bulb Replacement:** Ensure the fixture is cool and power is disconnected before replacing bulbs. Use E26 standard bulbs, not exceeding 60 watts.
- **Inspection:** Periodically check all connections and mounting hardware for tightness. If any looseness is detected, turn off power and re-secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fixture does not light	Power is off at the circuit breaker. Loose wire connections. Bulbs are faulty or not screwed in properly.	Check circuit breaker and turn power on. With power off, ensure all wire connections are secure. Replace bulbs and ensure they are fully tightened.
Flickering lights	Loose bulb connection. Incompatible dimmer switch (if applicable). Faulty bulb.	Tighten bulbs. Ensure dimmer switch is compatible with bulbs (if applicable). Replace faulty bulb.
Fixture hums	Incompatible dimmer switch. Loose wiring.	Replace dimmer switch with a compatible one. With power off, check and secure all wiring connections.

SPECIFICATIONS

- **Model Number:** 65273
- **Brand:** Mercana
- **Material:** Metal, Wooden Beads
- **Finish Type:** Metal
- **Color:** Gold
- **Product Dimensions (L x W x H):** 35"L x 35"W x 36"H
- **Item Weight:** 35 Pounds
- **Mounting Type:** Hanging
- **Bulb Type:** E26 Standard (not included)
- **Number of Bulbs:** 6
- **Max Wattage per Bulb:** 60 Watts
- **Country of Origin:** China
- **UPC:** 696018652739

WARRANTY AND SUPPORT

Mercana products are manufactured to high-quality standards. For specific warranty information or technical support, please refer to the retailer where the product was purchased or visit the official Mercana website. Please have your model number (65273) and proof of purchase ready when contacting support.