

MINKA-AIRE F803L-MP

Minka-Aire F803L-MP Artemis 58 Inch LED Ceiling Fan User Manual

Model: F803L-MP

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Minka-Aire F803L-MP Artemis 58 Inch LED Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference. Proper installation and use are essential for optimal performance and safety.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these guidelines:

- Ensure the electrical supply is disconnected at the main circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound outlet box or support system capable of supporting a minimum of 35 lbs (15.9 kg).
- Do not operate this fan on a dimmer circuit. This fan is designed for use with its dedicated controls and is not compatible with standard dimmer switches. Using a dimmer switch may cause damage to the fan motor or LED light.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- Do not bend the blades during installation or cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PACKAGE CONTENTS

Carefully unpack your fan and check the contents. You should have the following items:

- Fan Motor Assembly
- Fan Blades (3)
- LED Light Kit
- Remote Control
- Mounting Bracket
- Downrod Assembly
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual



Image: Overview of Minka-Aire F803L-MP Artemis 58 Inch LED Ceiling Fan components, including the motor housing, blades,

SETUP AND INSTALLATION

Professional installation is recommended for ceiling fans. Ensure all safety precautions are followed.

1. **Turn Off Power:** Before starting, ensure the power supply to the fan location is turned off at the circuit breaker.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling outlet box. The outlet box must be listed for fan support.
3. **Downrod Assembly:** Insert the downrod through the canopy and coupling. Secure the downrod to the motor housing with the provided pin and screw.
4. **Hang Fan:** Carefully lift the fan assembly and hang it on the mounting bracket hook.
5. **Wiring Connections:** Connect the fan's electrical wires to the household supply wires according to the wiring diagram provided in the full instruction manual. Use the wire nuts provided. Ensure all connections are secure.
6. **Secure Canopy:** Slide the canopy up and secure it to the mounting bracket with the screws.
7. **Blade Attachment:** Attach the fan blades to the motor housing using the provided screws. Ensure all blades are securely fastened.
8. **Light Kit Installation:** Connect the light kit wires to the fan motor wires and secure the light kit to the fan housing.
9. **Restore Power:** Once all steps are complete and connections are secure, restore power at the circuit breaker.



Image: An example of the Minka-Aire F803L-MP Artemis 58 Inch LED Ceiling Fan fully assembled and installed on a ceiling.

OPERATING INSTRUCTIONS

Your Minka-Aire F803L-MP fan is controlled by the included remote control. It also supports app and voice control.

Remote Control Operation:

- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Fan Speed:** Use the speed buttons (typically 1, 2, 3) to adjust the fan speed. This model has 3 speeds.
- **Light ON/OFF:** Press the light button to turn the LED light on or off.
- **Light Dimming:** If applicable, press and hold the light button to dim or brighten the light.
- **Reverse Function:** Some remotes include a reverse button to change the direction of the fan blades for

summer (downward airflow) or winter (upward airflow) operation. Refer to your specific remote's instructions.

App and Voice Control:

For app and voice control features, refer to the separate instructions provided with your fan for connecting to smart home systems and compatible applications. This functionality allows for remote operation and integration with voice assistants.

MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Clean the fan housing and blades periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Blade Inspection:** Check the blade screws periodically to ensure they are tight. Loose blades can cause wobbling and noise.
- **Electrical Connections:** Annually, with power off, check all electrical connections for tightness.
- **Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING

Before performing any troubleshooting, ensure the power supply is disconnected at the main circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	• No power to the fan. • Loose wire connections. • Remote control battery is dead. • Incorrect dimmer switch used.	• Check circuit breaker and wall switch. • Verify all wire connections are secure. • Replace remote control battery. • Ensure no dimmer switch is installed on the circuit.
Fan wobbles excessively	• Loose blade screws. • Unbalanced blades. • Loose mounting bracket.	• Tighten all blade screws. • Use a balancing kit (not included) to balance blades. • Ensure mounting bracket is securely fastened to the ceiling.
Light does not work	• Loose wire connection to light kit. • Faulty LED light kit.	• Check light kit wiring connections. • Contact customer support for a replacement LED light kit if necessary.
Fan makes noise	• Loose screws. • Motor hum. • Blades hitting an obstruction.	• Check and tighten all screws on the fan and mounting bracket. • Some motor hum is normal; ensure it's not excessive. • Verify nothing is obstructing the fan blades.

SPECIFICATIONS

Feature	Detail
Brand	MINKA-AIRE
Model Number	F803L-MP
Electric Fan Design	Ceiling Fan
Product Dimensions (D x W x H)	58"D x 58"W x 12"H
Blade Span	58 inches
Number of Blades	3
Material	Glass, Maple
Light Type	LED
Number of Speeds	3
Control Method	Remote, App, Voice
Voltage	120 Volts
Wattage	95.00 Watts
Item Weight	26.06 Pounds
Room Type	Bedroom, Living Room
Mounting Type	Ceiling Mount

WARRANTY AND SUPPORT

For warranty information or technical support, please contact MINKA-AIRE customer service. Refer to the contact information provided in the product packaging or on the official MINKA-AIRE website. Keep your purchase receipt as proof of purchase for warranty claims.

Note: The manufacturer's warranty typically covers defects in materials and workmanship under normal use. Damage resulting from improper installation, misuse, or unauthorized repairs may not be covered.