

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LG](#) /

> [LG G6 User Manual](#)

LG LG.G6-32GB-Platinum

LG G6 Smartphone User Manual

Model: LG.G6-32GB-Platinum

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your LG G6 smartphone. The LG G6 is a powerful and durable device designed for a seamless mobile experience.

Key features include a 5.7-inch QHD Plus FullVision display with an 18:9 aspect ratio, dual 13 MP wide-angle rear cameras, and IP68 dust and water resistance. It runs on Android 7.0 and is powered by a Qualcomm Snapdragon 821 processor.

SETUP

1. Inserting the SIM Card and microSD Card

The LG G6 uses a Nano-SIM card. If you wish to expand storage, a microSD card can also be inserted. Locate the SIM/microSD card tray on the side of the device.






Image: LG G6 with its SIM and microSD card tray partially ejected, showing the slots for both cards.

1. Gently insert the provided ejection pin into the small hole on the SIM/microSD card tray to eject it.
2. Place your Nano-SIM card into the designated slot on the tray with the gold contacts facing down.
3. If using a microSD card, place it into its designated slot on the same tray.
4. Carefully reinsert the tray back into the phone until it clicks into place.

2. Charging the Battery

Before first use, fully charge the LG G6 battery. The device is equipped with a 3,300 mAh battery and supports wireless charging.

- Connect the USB-C cable to the charging port at the bottom of the phone.
- Connect the other end of the cable to a power adapter and plug it into a wall outlet.
- The charging indicator will appear on the screen.

3. Powering On/Off

To power on your LG G6, press and hold the Power/Lock key (located on the back, integrated with the fingerprint sensor) until the LG logo appears. To power off, press and hold the Power/Lock key, then select 'Power off' from the options.

OPERATING YOUR LG G6

Display and Navigation





Image: Front view of the LG G6, showcasing its 5.7-inch FullVision display.

The LG G6 features a 5.7-inch QHD Plus FullVision display with an 18:9 aspect ratio, providing an immersive viewing experience. Navigate the device using touch gestures on the screen.

Camera Features





Image: Rear view of the LG G6, highlighting the dual 13 MP cameras and the circular fingerprint sensor.

The LG G6 is equipped with dual 13 MP standard-angle and wide-angle rear cameras, allowing for versatile photography. The 5 MP front camera includes a Selfie Light feature for improved self-portraits.

Performance and Storage

Powered by a Qualcomm Snapdragon 821 2.35 GHz and 1.6 GHz quad-core processor, the LG G6 offers smooth performance. It comes with 4 GB of RAM and 32 GB of internal memory, expandable up to 2 TB via a microSD card.

Connectivity

The LG G6 is an unlocked GSM device, compatible with various GSM networks. It supports fast 4G LTE speeds, Wi-Fi, and GPS for navigation.

MAINTENANCE

Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your LG G6. Avoid using harsh chemicals or abrasive materials that could damage the device.

Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Updates are typically delivered over-the-air (OTA).

Battery Care

To prolong battery life, avoid exposing your phone to extreme temperatures. While the LG G6 has a 3,300 mAh battery, heavy usage can deplete it faster. Consider enabling battery saver modes when needed.

Durability Features

The LG G6 boasts IP68 dust and water resistance, meaning it can withstand immersion in up to 1.5 meters of water for up to 30 minutes. It has also passed 14 different military standard tests (MIL-STD-810G certification) for durability, offering enhanced protection against drops and shocks.

TROUBLESHOOTING

If you encounter issues with your LG G6, consider the following basic troubleshooting steps:

- **Device not powering on:** Ensure the battery is charged. Connect to a charger and try again.
- **Network connectivity issues:** Check if Airplane Mode is off. Restart the device. Verify your SIM card is properly inserted.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache or data in settings. Restart the phone.
- **Slow performance:** Close unused apps. Clear cache. Consider freeing up storage space.

For more detailed troubleshooting, refer to the official LG G6 User Manual PDF available from LG's support website or the document link provided with your purchase.

SPECIFICATIONS

| Feature | Detail |
|------------------|---------------------------|
| Model Name | LG G6 |
| Model Number | LG.G6-32GB-Platinum |
| Dimensions | 5.86 x 0.31 x 2.83 inches |
| Weight | 5.8 ounces |
| Operating System | Android 7.0 |
| RAM | 4 GB |

| Feature | Detail |
|--------------------|--|
| Internal Storage | 32 GB (expandable up to 2 TB with microSD) |
| Display Size | 5.7 Inches |
| Display Resolution | 2880 x 1440 pixels |
| Processor | Qualcomm Snapdragon 821 (2.35 GHz and 1.6 GHz quad core) |
| Rear Camera | Dual 13 MP (standard-angle and wide-angle) |
| Front Camera | 5 MP |
| Battery Capacity | 3300 mAh |
| Connectivity | 4G LTE, Wi-Fi, GPS, GSM |
| Durability | IP68 Dust and Water Resistant, MIL-STD-810G Compliant |

WARRANTY INFORMATION

The LG G6 typically comes with a standard manufacturer's warranty, which usually covers defects in materials and workmanship for a period of one year from the date of purchase. Please refer to the warranty card included with your product or visit the official LG website for specific terms and conditions, including details on what is covered and how to make a claim.

SUPPORT

For further assistance, technical support, or to download the full user manual, please visit the official LG support website. You can also find FAQs and community forums for common issues and tips.

LG Support Website: www.lg.com/us/support