**Line 6 HELIX LT**

# Line 6 Helix LT Guitar Processor User Manual

**Brand:** Line 6 | **Model:** HELIX LT

## 1. Introduction

The Line 6 Helix LT Guitar Processor is a powerful and versatile multi-effects unit designed for guitarists seeking authentic tone and flexible control. Utilizing the award-winning HX Modeling engine, the Helix LT accurately recreates the sound and feel of classic and modern amplifiers, cabinets, microphones, and effects. Its intuitive interface, robust I/O, and comprehensive routing options make it suitable for a wide range of live performance and studio recording applications. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Helix LT.

## 2. Setup

### 2.1 Unpacking and Initial Inspection

Upon opening the package, carefully remove the Helix LT processor and all accessories. Verify that all components are present and in good condition. The standard package should include:

- Line 6 Helix LT Guitar Processor
- Power Cable
- USB Cable
- Quick Start Guide (this manual serves as a comprehensive guide)

### 2.2 Power Connection

Connect the provided power cable to the AC input on the rear panel of the Helix LT and then to a standard electrical outlet. Ensure the power switch is in the OFF position before connecting. The Helix LT operates on 9 Volts DC power.

### 2.3 Connecting to Instruments and Amplifiers

The Helix LT offers a robust I/O complement for flexible integration into any setup. Refer to the image below for a visual guide to the rear panel connections.




**Figure 2.3:** Rear panel connections of the Line 6 Helix LT. This view displays the various input and output ports including Guitar In, Send/Return loops, XLR Out, 1/4" Out, Phones, Variax, Digital Out, MIDI, and USB.

- **Guitar In:** Connect your guitar to this 1/4" input.
- **1/4" Outputs (Left/Right):** Connect these to your amplifier, mixer, or audio interface.
- **XLR Outputs (Left/Right):** For balanced connections to a PA system or studio mixer.
- **Send/Return Loops (1 & 2):** Integrate external effects pedals or connect to an amplifier's effects loop.
- **Phones:** Connect headphones for silent practice or monitoring.
- **Variax:** For digital integration with Line 6 Variax guitars, providing power and control.
- **Digital Out (AES/EBU/L6 Link):** For digital audio output and L6 Link connectivity with compatible Line 6 products.
- **MIDI In/Out/Thru:** For MIDI control and synchronization with other devices.
- **USB:** Connect to your computer for use with the Helix Edit software, firmware updates, and audio interface functionality.
- **EXP Pedal 1/2:** Connect external expression pedals for additional real-time control.

## 3. Operation

### 3.1 User Interface Overview

The Helix LT features a clear and intuitive interface designed for fast tone creation and easy interaction. The large color LCD displays the entire signal chain and provides instant access to amp and effects parameters. Touch-sensitive footswitches with color LED rings allow for quick selection and editing of effect blocks.




**Figure 3.1:** Top view of the Line 6 Helix LT. This image highlights the central LCD screen, the various footswitches with colored LED rings, the volume knob, navigation buttons, and the integrated expression pedal.

### 3.2 Basic Navigation

- **Preset Navigation:** Use the PRESET knob to scroll through and select different presets.
- **Footswitch Modes:** The footswitches can operate in various modes (e.g., Stomp, Preset, Snapshot) which can be changed by pressing the MODE button.
- **Parameter Editing:** Touch a footswitch assigned to an effect block to select it for editing. Parameters will appear on the LCD and can be adjusted using the corresponding knobs below the screen.

### 3.3 Editing Tones (Pedal Edit Mode)

The Helix LT's Pedal Edit Mode allows you to adjust parameters using the expression pedal without stopping your playing. Simply select the block and parameter you wish to change, and then use the expression pedal to modify its value. This feature streamlines the tone-tweaking process during live performance or practice.

### 3.4 Software Editor (Mac/PC)

The Helix Edit software for Mac and PC provides a user-friendly graphical interface for creating and editing presets. You can drag and drop amps, cabs, and effects to build complex signal chains, reorganize, rename, and modify performance view labels. Connect your Helix LT to your computer via the USB port to utilize this powerful editor.

## 4. Maintenance

### 4.1 Cleaning

To maintain the appearance and functionality of your Helix LT, regularly wipe the unit with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or waxes, as these can damage the finish and internal components. Ensure the unit is powered off and unplugged before cleaning.

### 4.2 Firmware Updates

Line 6 regularly releases firmware updates for the Helix family of products, adding new amp and effect models, features, and workflow improvements. It is recommended to keep your Helix LT's firmware up to date to ensure

optimal performance and access to the latest functionalities. Firmware updates are typically performed via the Helix Edit software connected to your computer.

## 5. Troubleshooting

This section addresses common issues you might encounter with your Line 6 Helix LT. If you experience a problem not listed here, please refer to the official Line 6 support resources.

| Problem | Possible Cause / Solution |
|---|---|
| No sound output | • Check all cable connections (instrument, output to amp/mixer, power).<br>• Ensure the Helix LT is powered on and the volume knob is turned up.<br>• Verify that the selected preset has active blocks and is not muted.<br>• Check the input and output levels within the Helix LT's settings. |
| Footswitches unresponsive | • Ensure the unit is powered on correctly.<br>• Try restarting the Helix LT.<br>• Check if the unit is in a specific mode that limits footswitch functionality (e.g., bypass mode). |
| Difficulty connecting to computer via USB | • Ensure the USB cable is securely connected to both the Helix LT and your computer.<br>• Install the latest Line 6 USB drivers for your operating system.<br>• Try a different USB port or cable.<br>• Restart both the Helix LT and your computer. |
| Unexpected noise or hum | • Check for ground loops; try connecting all audio equipment to the same power strip.<br>• Ensure all cables are in good condition and properly shielded.<br>• Test with different power outlets.<br>• Reduce input gain if the noise is distortion-related. |

## 6. Specifications

Below are the technical specifications for the Line 6 Helix LT Guitar Processor:

| Feature | Detail |
|---|---|
| Item Weight | 13.2 pounds (6 Kilograms) |
| Product Dimensions | 30.5 x 15.5 x 6.75 inches |
| Model Number | HELIX LT |

| Feature | Detail |
|---|---|
| Hardware Interface | USB 2.0 |
| Signal Format | Analog |
| Power Source | DC Power Supply |
| Voltage | 9 Volts |
| Amperage | 300 Milliamps |
| Dynamic Range | 123 dB |
| DSP Power | Dual-DSP (HX Modeling Engine) |
| Preset Compatibility | Compatible with Helix Floor, Helix Rack, and Helix Native |

## 7. Warranty and Support

Line 6 products are designed for reliability and performance. For detailed information regarding the warranty coverage for your Helix LT, please refer to the warranty card included with your product or visit the official Line 6 website. For technical support, product registration, and access to the latest drivers and firmware, please visit the Line 6 support portal online. Regular firmware updates are provided to enhance functionality and performance.

© 2024 Line 6. All rights reserved. Specifications are subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question