

Bialetti 5770

Bialetti Milk Frother Model 5770 Instruction Manual

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, operation, and maintenance of your Bialetti Milk Frother Model 5770. Please read this manual thoroughly before first use and retain it for future reference.

2. PRODUCT OVERVIEW

2.1 Components

- Bialetti Milk Frother Unit
- Stainless Steel Whisk
- User Manual

2.2 Features

- Material: Stainless Steel
- Ergonomic Handle for comfortable grip
- Compact Design for easy storage
- Manual power source (battery-operated)






Image 1: Bialetti Milk Frother alongside a glass of frothed milk.



Image 2: Close-up view of the frother whisk creating foam.



Image 3: A user demonstrating the frother in action with a cup of milk.

3. SETUP

3.1 Battery Installation

1. Twist the bottom cap of the frother counter-clockwise to open the battery compartment.
2. Insert 2 AA batteries, ensuring correct polarity (+/-). Batteries are not included.
3. Replace the bottom cap by twisting it clockwise until secure.

3.2 Initial Cleaning

Before first use, gently wipe the frother unit with a damp cloth. The whisk can be rinsed under warm water. Ensure the battery compartment remains dry.

4. OPERATING INSTRUCTIONS

4.1 Frothing Milk

1. Pour cold or warm milk into a cup or container. For best results, use milk that is not overly full, allowing space for foam.
2. Submerge the whisk end of the frother into the milk, ensuring the whisk is fully covered but not touching the bottom of the cup.

- Press and hold the power button located on the side of the frother. The whisk will begin to rotate.
- Move the frother gently up and down in the milk for approximately 15-30 seconds, or until desired foam consistency is achieved.
- Release the power button to stop the frother.
- Carefully remove the frother from the frothed milk.

Tip: For optimal foam, use fresh, cold milk. Whole milk generally produces richer foam.

5. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your Bialetti Milk Frother.

5.1 Cleaning Instructions

- Hand Wash Only:** The frother unit is not dishwasher safe.
- After each use, immediately rinse the whisk under warm running water.
- Wipe the body of the frother with a damp cloth. Do not immerse the main unit in water.
- Ensure all parts are completely dry before storing.
- Do not use abrasive cleaners or scouring pads, as these can damage the stainless steel finish.

6. TROUBLESHOOTING

- Frother not turning on:** Check if the batteries are correctly installed and have sufficient charge. Replace batteries if necessary.
- Milk not frothing effectively:** Ensure the whisk is fully submerged in the milk. Try using colder milk or a different type of milk (e.g., whole milk). Ensure the whisk is clean and free of residue.
- Frother making unusual noise:** Check for any obstructions around the whisk. Ensure the whisk is securely attached.



7. SPECIFICATIONS

Brand	Bialetti
Model Number	5770
Material	Stainless Steel
Color	Silver
Power Source	Manual (Battery-operated)
Batteries Required	2 AA batteries (not included)
Product Dimensions	7.87"W x 11.81"H
Item Weight	0.21 Kilograms (7.4 ounces)
Special Features	Ergonomic Handle, Compact Design
Care Instructions	Hand Wash Only

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the packaging or contact Bialetti customer service directly. Contact details can typically be found on the official Bialetti website or product packaging.

Related Documents - 5770

	Bialetti Loyalty Program Rules Official regulations for the Bialetti loyalty program, detailing membership conditions, card usage, benefits, and responsibilities for participants in Italy.
	Bialetti Moka Express User Manual and Brewing Guide Learn how to safely and effectively use your Bialetti Moka Express stovetop coffee maker. This guide covers assembly, operation, cleaning, maintenance, and troubleshooting for perfect Italian-style coffee.
	Manuale d'uso Macchina Caffè Espresso Bialetti BREAK CF67S Manuale d'uso per la macchina da caffè espresso Bialetti BREAK CF67S. Scopri come utilizzare, mantenere e risolvere problemi per un autentico espresso italiano a casa.
	Istruzioni per la Caffettiera Bialetti Moka Express Guida completa alle istruzioni d'uso, consigli, preparazione, pulizia, manutenzione e garanzia per la caffettiera Bialetti Moka Express.
	Bialetti Mignon CF91: Guida all'uso e alla sicurezza Manuale completo per la macchina da caffè Bialetti Mignon CF91, che include istruzioni per l'uso, avvertenze di sicurezza, descrizione dei componenti e dati tecnici.

Café de acero inoxidable

Las cafeteras de acero inoxidable de Bialetti son una excelente alternativa para quienes buscan un producto duradero y resistente al calor. Estas cafeteras están diseñadas para preparar café de alta calidad y son ideales para uso doméstico o comercial.

Modelos disponibles: Bialetti Musa y Bialetti Venus.

Características principales:

Modelo	Capacidad (L)	Peso (kg)	Material	Color
Musa	1.5	1.5	Acero inoxidable	Plateado
Venus	1.5	1.5	Acero inoxidable	Plateado

Para más información sobre los modelos Musa y Venus, visite nuestra página web o contacte con nuestro equipo de atención al cliente.

[Cafeteras de Acero Inoxidable Bialetti: Modelos Musa y Venus](#)

Descubra las cafeteras de acero inoxidable para estufa de Bialetti, incluyendo los modelos Musa y Venus. Conozca sus características, especificaciones, uso, limpieza y mantenimiento para preparar un delicioso café en casa.