

## Home Decorators Collection 201322A

# Home Decorators Collection 3-Light Matte Nickel Multi Pendant Instruction Manual

## INTRODUCTION

---

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Home Decorators Collection 3-Light Matte Nickel Multi Pendant. Please read and understand all instructions before beginning installation and retain this manual for future reference.

## SAFETY INFORMATION

---

### **WARNING: RISK OF ELECTRIC SHOCK.**

- Always turn off the power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Do not install this fixture in wet locations.
- Ensure all connections are secure and properly insulated.
- Do not exceed the maximum wattage specified for this fixture (180 watts total, 60 watts per bulb).

### **CAUTION:**

- Wear safety glasses and gloves during installation.
- Handle glass components with care.
- Keep combustible materials away from the light fixture.

## PACKAGE CONTENTS

---

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, do

not attempt to assemble or install the product. Contact customer service for assistance.

- Pendant Light Fixture (3-light assembly)
- Mounting Hardware Kit
- Instruction Manual

*Note: Bulbs are not included.*

## TOOLS REQUIRED (NOT INCLUDED)

---

- Phillips Head Screwdriver
- Flat Head Screwdriver
- Wire Strippers
- Electrical Tape
- Pliers
- Safety Glasses
- Ladder

## INSTALLATION INSTRUCTIONS

---

Follow these steps carefully to install your pendant light fixture. It is recommended to have two people for installation.

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker.
2. **Prepare Mounting Plate:** Attach the mounting plate to the junction box using the provided screws. Ensure it is securely fastened.
3. **Adjust Hanging Length:** The pendant lights feature an adjustable hanging length. Determine the desired height for each pendant. Loosen the set screw on the canopy to adjust the cable length. Once the desired length is achieved, tighten the set screw to secure the cable.
4. **Make Electrical Connections:** Connect the fixture's wires to the house wires according to the following:
  - Connect the black (live) wire from the fixture to the black (live) wire from the junction box.
  - Connect the white (neutral) wire from the fixture to the white (neutral) wire from the junction box.
  - Connect the green or bare copper (ground) wire from the fixture to the green or bare copper (ground) wire from the junction box.
  - Secure all connections with wire nuts and wrap with electrical tape for added safety.
5. **Mount Fixture:** Carefully push the excess wiring into the junction box. Align the fixture canopy with the mounting plate and secure it with the provided screws.
6. **Install Bulbs:** Screw in three A19 type bulbs (not included) into the sockets. Do not exceed 60 watts per bulb.
7. **Restore Power:** Turn the power back on at the circuit breaker and test the fixture.

## Product Dimensions




Figure 1: Overall dimensions of the Home Decorators Collection 3-Light Multi Pendant. Note the adjustable hanging length up to 59 inches and a total width of 33.74 inches.

### Installed Appearance



Figure 2: The 3-light multi pendant fixture installed in a kitchen setting, showcasing its matte nickel finish and adjustable

## OPERATING INSTRUCTIONS

This fixture is designed for simple operation.

- **Power On/Off:** Control the light fixture using a standard wall switch connected to the circuit.
- **Bulb Type:** Use E26 base A19 LED compatible bulbs. The fixture is retrofit for LED bulbs.
- **Remote Control:** The product specifications mention "Control Method: Remote". However, no remote is typically included with such fixtures unless explicitly stated. If a remote control system was purchased separately and integrated, refer to its specific instructions for operation. This fixture itself does not include a remote.

## MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:** Turn off the power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, polishes, or solvents as they may damage the finish.
- **Bulb Replacement:** Turn off the power and allow bulbs to cool before replacing. Use only E26 base A19 bulbs, not exceeding 60 watts per bulb.
- **Inspection:** Periodically check all electrical connections and mounting hardware for tightness.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	<ol style="list-style-type: none"><li>1. Power is off.</li><li>2. Faulty bulb.</li><li>3. Loose wiring connection.</li><li>4. Faulty wall switch.</li></ol>	<ol style="list-style-type: none"><li>1. Check circuit breaker or fuse.</li><li>2. Replace bulb.</li><li>3. Check wiring connections (ensure power is off).</li><li>4. Test or replace wall switch.</li></ol>
Flickering light.	<ol style="list-style-type: none"><li>1. Loose bulb.</li><li>2. Incorrect bulb type.</li><li>3. Loose wiring connection.</li></ol>	<ol style="list-style-type: none"><li>1. Tighten bulb.</li><li>2. Ensure correct bulb type (E26 base, A19, LED compatible).</li><li>3. Check wiring connections (ensure power is off).</li></ol>
Fixture hums.	Incompatible dimmer switch or LED bulb.	Ensure dimmer switch is LED compatible. Try different LED bulbs.

## SPECIFICATIONS

Model Number	201322A
Brand	Home Decorators Collection
Fixture Type	Multi Pendant Light
Number of Lights	3

<b>Finish</b>	Matte Nickel
<b>Shade Material</b>	Nickel
<b>Maximum Hanging Length</b>	59 inches (adjustable)
<b>Product Width</b>	33.74 inches
<b>Bulb Base</b>	E26
<b>Recommended Bulb Shape</b>	A19
<b>Maximum Wattage (per bulb)</b>	60 Watts
<b>Total Maximum Wattage</b>	180 Watts
<b>Voltage</b>	120 Volts
<b>Connection Type</b>	Hardwired
<b>Control Method</b>	Wall Switch (Remote compatible, if integrated separately)
<b>Certifications</b>	ETL Listed
<b>Item Weight</b>	7.6 Pounds

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact Home Decorators Collection customer service. Keep your purchase receipt for warranty claims.

*Note: Specific warranty details are not provided in this manual. Refer to the product packaging or manufacturer's website for the most current warranty information.*