

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Brondell](#) /
› [Brondell Bidet Toilet Seat S1400, Smart Toilet Seat, Dual Stainless-Steel, Self-Cleaning Nozzle With Clean Plus Technology, Endless Warm Water Bidet, Warm Air Dryer-Nightlight, Heated Seat, Elongated Elongated S1400 User Manual](#)

Brondell S1400-EW

Brondell Swash 1400 Bidet Toilet Seat User Manual

Model: S1400-EW | Brand: Brondell

INTRODUCTION

The Brondell Swash 1400 is an advanced electronic bidet toilet seat designed to provide a hygienic and comfortable cleansing experience. This manual provides comprehensive instructions for the installation, operation, and maintenance of your new bidet seat, ensuring optimal performance and longevity. Key features include dual stainless-steel nozzles with Clean Plus Technology, endless warm water spray, a heated seat, warm air dryer, and a programmable remote control.

SAFETY INFORMATION

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- Ensure the electrical outlet is a grounded 120V AC outlet.
- Do not immerse the unit, power cord, or plug in water or other liquids.
- Unplug the unit from the power outlet when not in use for extended periods or before cleaning.
- Do not allow children to operate or play with the bidet seat without supervision.
- Avoid using abrasive cleaners or harsh chemicals on the bidet seat.
- Do not attempt to repair or disassemble the unit yourself. Contact qualified service personnel.

PRODUCT OVERVIEW AND FEATURES

The Brondell Swash 1400 is equipped with a range of features designed for comfort and hygiene.

Key Features:

Dual Stainless-Steel Nozzles: Separate nozzles for posterior and feminine wash, ensuring optimal hygiene.

Nozzle Clean+ Technology: Self-cleaning function for nozzles before and after each use.

Endless Warm Water: Instant ceramic water heater provides continuous warm water for a comfortable wash.

Heated Seat: Adjustable seat temperature with three warmth levels.

Warm Air Dryer: Four-level adjustable warm air dryer for a complete experience.

Cool Blue LED Nightlight: Illuminates the bowl for convenience during nighttime use.

Programmable Remote Control: User-friendly remote with settings for two individual users.

Carbon Block Deodorizer: Helps neutralize odors.

Sittable Lid: Durable lid designed to support weight.

Hidden Pocket: Conceals water and power connections for a sleek appearance.

Full Features



Designed for
North American
bathroom toilets



Dual, self-
cleaning stainless
steel nozzles



Nozzle Clean+
technology



Endless warm
water washes



Spray width
adjustment and
oscillating spray



Multiple spray
patterns



Seven adjustable
nozzle positions



Fully adjustable
water temperature
and pressure



Separate front
and rear washes



Carbon
deodorizer



Warm air dryer
with 3 temperature
levels



Heated toilet seat
with 3 warmth levels
and on/off option



Cool blue LED
nightlight



Programmable
remote with 2
user presets



Convenient,
one-touch auto
mode



Energy-efficient
eco mode



Sittable lid




Image: Overview of the Brondell Swash 1400's full features, including dual stainless-steel nozzles, endless warm water, heated seat, and more.

Engineered for North American toilets.

Streamlined,
elegant design

Secure fit with no
toilet seat gap

Durable, sittable lid



Hidden pocket hides
connection lines



Access essential
features with
convenient side
control panel



Image: Side view of the bidet seat highlighting the hidden pocket for connections and the convenient side control panel.

User-friendly remote control.

Separate rear and front washes

Adjust water temperature, pressure, settings, & more

Ergonomic, single-sided design

Wide and concentrated spray patterns

Programmable for 2 users

One-touch auto mode




Image: Detailed view of the user-friendly remote control, showing buttons for various functions like water temperature, spray width, and user presets.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Swash Bidet Seat
- Brondell Remote Control
- Mounting Bolt (2)
- Rubber Cone Washer (2)
- Flat Washer (2)
- Barrel Nut (2)
- Mounting Plate
- Adjustable Bracket (2)

- T-valve Connector
- Rubber Washer
- Bidet Hose
- Cable Clip (2)
- Remote Control Wall Mount
- Remote Screw (2)
- Remote Anchor (2)
- CR2032 Battery-Lithium (4)

SETUP AND INSTALLATION

The Brondell Swash 1400 is designed for easy self-installation, typically taking less than an hour. No special plumbing tools are required.

Before You Begin:

- Ensure you have an elongated toilet bowl. The S1400 is designed for elongated models.
- Confirm a grounded 120V AC electrical outlet is within 42 inches of the toilet.
- Turn off the water supply to the toilet at the shut-off valve.
- Flush the toilet to drain the tank.

Installation Steps:

1. **Remove Existing Toilet Seat:** Loosen and remove the nuts and bolts securing your current toilet seat. Remove the seat and lid.
2. **Install T-Valve:** Disconnect the existing water supply hose from the toilet tank. Install the T-valve connector onto the fill valve at the bottom of the toilet tank. Reconnect the water supply hose to the bottom of the T-valve.
3. **Install Mounting Plate:** Place the mounting plate over the toilet bowl holes. Insert the mounting bolts through the plate and toilet holes. Secure with rubber cone washers, flat washers, and barrel nuts from underneath. Do not overtighten.
4. **Attach Bidet Seat:** Slide the Brondell Swash 1400 bidet seat onto the mounting plate until it clicks into place. Adjust the seat position as needed.
5. **Connect Bidet Hose:** Connect one end of the bidet hose to the T-valve and the other end to the bidet seat's water inlet. Ensure connections are hand-tightened, then use a wrench for a quarter turn to prevent leaks.
6. **Restore Water Supply:** Slowly turn on the water supply valve to the toilet. Check for any leaks.
7. **Plug In:** Plug the bidet seat's power cord into the grounded 120V AC electrical outlet.

Two sizes available.



Image: Diagram illustrating the difference between round and elongated toilet bowl sizes, confirming the S1400 is for elongated models (18 inches and up).

OPERATING INSTRUCTIONS

The Brondell Swash 1400 is operated primarily via its wireless remote control. Ensure the included CR2032 batteries are installed in the remote.

Basic Functions:

- **Rear Wash:** Press the **Rear** button for posterior cleansing.
- **Front Wash:** Press the **Front** button for feminine cleansing.
- **Stop:** Press the **Stop** button to cease any operation.
- **Dry:** Press the **Dry** button to activate the warm air dryer.

Adjusting Settings:

- **Water Pressure/Dry Temp:** Use the **+** and **-** buttons to adjust water pressure during wash cycles or air temperature during drying.
- **Nozzle Position:** Use the **Nozzle Position** arrows to adjust the nozzle's forward or backward position.
- **Seat Temp:** Press the **Seat Temp** button to cycle through heated seat temperature settings.
- **Spray Width:** Press the **Spray Width** button to change between wide and concentrated spray patterns.
- **Water Temp:** Press the **Water Temp** button to cycle through water temperature settings.

Advanced Features:

- **Nozzle Clean+:** Press the **Nozzle Clean+** button to manually activate the nozzle self-cleaning cycle.
- **Deodorize:** Press the **Deodorize** button to activate the carbon deodorizer.
- **User Presets (User 1 / User 2):** Program and recall preferred settings for two different users by pressing **User 1** or **User 2**. Refer to the full manual for programming instructions.
- **Auto Mode:** Press the **Auto** button for a pre-programmed wash and dry cycle.
- **Nightlight:** The cool blue LED nightlight automatically activates in low light conditions.



Gentle-glow LED nightlight.

Image: The bidet seat with its gentle-glow LED nightlight illuminated, providing visibility in the dark.

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your Brondell Swash 1400 bidet seat.

Cleaning the Bidet Seat:

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth and a mild, non-abrasive household cleaner. Do not use harsh chemicals, benzene, paint thinner, or abrasive powders.
- **Nozzles:** The nozzles have a self-cleaning function. For additional cleaning, gently pull out the nozzles and wipe them with a soft cloth or toothbrush. Do not use excessive force.
- **Deodorizer Filter:** The carbon block deodorizer is replaceable. Refer to the full product manual for instructions on replacing the filter.

Long-Term Storage:

If the bidet seat will not be used for an extended period, or if there is a risk of freezing temperatures, it is recommended to drain the water from the unit. Consult the full manual for detailed draining procedures.



Durable, stainless steel nozzles.

7-position nozzle with NozzleClean+ technology

Nozzles retract for self-cleaning
Separate front and rear washes

Image: Close-up view of the durable, stainless steel nozzles, highlighting their 7-position adjustability and self-cleaning technology.

TROUBLESHOOTING

If you encounter issues with your Brondell Swash 1400, refer to the common problems and solutions below. For more complex issues, contact Brondell customer support.

Problem	Possible Cause	Solution
No power to the unit.	Power cord unplugged, circuit breaker tripped, or outlet malfunction.	Ensure the power cord is securely plugged in. Check your household circuit breaker. Test the outlet with another device.

Problem	Possible Cause	Solution
No water spray or weak spray.	Water supply valve closed, bidet hose kinked, or water filter clogged.	Ensure the toilet's water supply valve is fully open. Check the bidet hose for kinks. Clean or replace the water filter if applicable (refer to full manual).
Water temperature is not warm.	Water heater setting too low or unit not fully warmed up.	Adjust the water temperature setting on the remote. Allow a few moments for the instant heater to warm up.
Heated seat not working.	Heated seat function turned off or setting too low.	Press the "Seat Temp" button on the remote to cycle through temperature settings.
Remote control not responding.	Batteries are dead or incorrectly installed.	Replace the CR2032 batteries in the remote control. Ensure they are installed with correct polarity.

SPECIFICATIONS

Attribute	Detail
Model Number	S1400-EW
Color	White
Material	Stainless Steel (nozzles)
Style	S1400
Shape	Oval (Elongated)
Product Dimensions (L x W x H)	20.43" x 15.2" x 5.75"
Item Weight	14.3 Pounds
Power Source	Corded Electric
Voltage	120 Volts
Installation Method	Self Install
Batteries Required	4 Lithium Metal CR2032 (included for remote)
UPC	819911012237

WARRANTY AND SUPPORT

The Brondell Swash 1400 Bidet Toilet Seat comes with a **3-year limited manufacturer's warranty** when purchased from an authorized seller. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or further assistance, please visit the official Brondell website or contact their customer service department. Keep your proof of purchase for warranty validation.

Brondell Official Website: www.brondell.com

