

Kela 11476

Kela Elvira Splatter Guard Instruction Manual

Model: 11476

Brand: Kela

PRODUCT OVERVIEW

The Kela Elvira Splatter Guard is designed to enhance safety and cleanliness in your kitchen by preventing oil splashes and burns during cooking. Crafted from high-quality 18/10 stainless steel, this durable accessory is suitable for use with pans up to 30 cm in diameter.

Key Features

- Protects against burns and keeps cooking surfaces clean.
- Compatible with pans up to 30 cm (approximately 11.8 inches) in diameter.
- Provides optimal safety by shielding from hot oil splashes.
- Easy to clean and dishwasher safe.
- Constructed from premium 18/10 stainless steel.

SETUP

The Kela Elvira Splatter Guard requires no assembly. Before first use, wash the splatter guard thoroughly with warm soapy water and rinse completely. Dry it with a soft cloth.

Compatibility

This splatter guard is designed to fit securely over frying pans and pots with a diameter of up to 30 cm (approximately 11.8 inches). Ensure the splatter guard rests stably on the rim of your cookware.



Image showing the Kela Elvira Splatter Guard. It features a fine mesh screen for ventilation and a sturdy stainless steel frame with a long handle for safe placement and removal.

OPERATING INSTRUCTIONS

Using the Splatter Guard

1. Place the splatter guard directly onto the rim of your frying pan or pot before you begin cooking with oil or other liquids that may splatter.
2. Ensure the splatter guard is centered and stable on the cookware.
3. The fine mesh allows steam to escape while containing oil and food splashes, keeping your stovetop and surrounding areas clean and reducing the risk of burns.
4. Use the handle to safely lift and remove the splatter guard when checking food or stirring. Always use caution as the guard may become hot during use.



This image illustrates the Kela Elvira Splatter Guard in use, resting on a dark-colored frying pan. The guard's design allows it to sit securely on the pan's rim, providing effective splash protection.



A view of the Kela Elvira Splatter Guard positioned on a stainless steel frying pan, demonstrating its universal fit for various cookware types up to 30 cm in diameter.

CARE AND MAINTENANCE

Cleaning

The Kela Elvira Splatter Guard is designed for easy cleaning.

- After each use, allow the splatter guard to cool completely.
- Wash by hand with warm soapy water and a soft sponge, or place it in the dishwasher.
- For stubborn grease, a non-abrasive cleaner can be used. Avoid steel wool or harsh scouring pads, which can scratch the stainless steel.
- Rinse thoroughly and dry immediately to prevent water spots and maintain the luster of the stainless steel.

Storage

Store the splatter guard in a dry place. Its flat design allows for easy storage in a drawer or hanging on a hook.

TROUBLESHOOTING

Common Issues and Solutions

- **Splatter Guard does not fit my pan:** Ensure your pan's diameter is 30 cm or less. This model is designed for pans up to 30 cm.
- **Splatter guard appears stained or discolored:** This can occur from heat or certain foods. Regular cleaning with a stainless steel cleaner can help restore its appearance. Ensure thorough drying after washing.
- **Splatter guard is still hot after cooking:** Always allow the splatter guard to cool down before handling or cleaning. Use oven mitts or a cloth if immediate handling is necessary.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Kela
Model Number	11476
Material	18/10 Stainless Steel
Color	Stainless Steel
Diameter	30 cm (approx. 11.8 inches)
Dimensions (L x W x H)	52 x 0.43 x 1.5 cm (including handle)
Item Weight	390 g
Dishwasher Safe	Yes

WARRANTY AND SUPPORT

For specific warranty information and customer support, please refer to the official Kela website or contact your retailer. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

