

## Philips BT6900B/37

# Philips BT6900B/37 Wireless Speaker

## INSTRUCTION MANUAL

### 1. Introduction

---

This manual provides essential information for the safe and efficient use of your Philips BT6900B/37 Wireless Speaker. Please read these instructions carefully before using the product and retain them for future reference.

### 2. Package Contents

---

Verify that all items are present in the package:

- Philips BT6900B/37 Wireless Speaker
- USB charging cable (doubles as a lanyard strap)
- Quick Start Guide

### 3. Product Features

---

The Philips BT6900B/37 Wireless Speaker offers the following key features:

- **Strong Bluetooth Connection:** Enjoy wireless audio with a range of up to 30 meters (100 feet).
- **Durable Build:** Designed to be shockproof, dustproof, and waterproof with an IP57 rating, suitable for outdoor use.
- **Integrated USB Cable:** The charging cable also functions as a convenient lanyard strap for portability.
- **Quick-Charge Function:** Recharges the speaker battery up to three times faster than standard charging.
- **Built-in Microphone:** Enables hands-free phone calls directly through the speaker.

## 4. Setup

---

### 4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status. The quick-charge feature allows for faster charging times.

### 4.2 Power On/Off

- **To Power On:** Press and hold the power button until the indicator light illuminates.
- **To Power Off:** Press and hold the power button until the indicator light turns off.

### 4.3 Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (the Bluetooth indicator will flash).
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "Philips BT6900B/37" from the list of devices.
4. Once connected, the Bluetooth indicator on the speaker will glow steadily, and you will hear a confirmation tone.



*Image: Philips BT6900B/37 Wireless Speaker. This image displays the speaker's design, including the speaker grille and control panel, which are essential for setup and operation.*

## 5. Operating Instructions

---

### 5.1 Playing Audio

After successful Bluetooth pairing, you can play audio from your connected device. Use the controls on your device or the speaker's buttons to adjust volume, play/pause, and skip tracks.

### 5.2 Hands-free Calls

When a call comes in while connected via Bluetooth, the music will pause. Press the call button on the speaker to answer or end the call. The built-in microphone allows for clear communication. Press and hold the call button to reject an incoming call.

### 5.3 Waterproof and Dustproof Usage (IP57)

The speaker is rated IP57, meaning it is protected from dust ingress and can withstand immersion in water up to 1 meter for 30 minutes. Ensure all port covers are securely closed before exposing the speaker to water or dust. After exposure to water, dry the speaker thoroughly before charging.

## 6. Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

## 7. Troubleshooting

If you encounter issues with your speaker, refer to the following common solutions:

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Turn off and on Bluetooth on your device. Move closer to the speaker. Clear previous pairings on your device.
No sound or distorted sound.	Check volume levels on both the speaker and your connected device. Ensure the speaker is properly paired. Try restarting both devices.
Microphone not working during calls.	Ensure the speaker is connected and selected as the audio output for calls on your device.

## 8. Specifications

Key technical specifications for the Philips BT6900B/37 Wireless Speaker:

Feature	Detail
Model Name	BT6900B/37
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth Wireless
Speaker Maximum Output Power	10 Watts
Power Source	Battery Powered (1 Lithium Polymer battery included)
Waterproof Rating	IP57
Maximum Bluetooth Range	Up to 30 meters (100 feet)
Product Dimensions	6.3 x 2.8 x 2.9 inches
Item Weight	11 ounces (0.69 Pounds)
Compatible Devices	Smartphone

Feature	Detail
Included Components	Speaker, USB cable, guide

## 9. Warranty and Support

---

This product is covered by a manufacturer's warranty. For detailed warranty information, terms, and conditions, please refer to the warranty card included in your package or visit the official Philips support website. For technical assistance or customer service, please contact Philips customer support.

You can find more information and support resources on the [Philips Store on Amazon](#) or the official Philips website.