Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OMEGA FH0916B

User Manual

Omega Wireless Bluetooth Headphones

Model: FH0916B

Introduction

This manual provides essential information for the safe and efficient operation of your Omega Wireless Bluetooth Headphones. Please read it thoroughly before using the device and keep it for future reference.
The headphones are equipped with Bluetooth technology for wireless connection to compatible devices such as mobile phones, smartphones, tablets, laptops, and PCs. Before connecting, ensure your device is compatible with Bluetooth V3.0. These headphones are foldable for easy portability and feature an integrated microphone, volume control, pause function, and call answering capabilities.

Product Features

- **Bluetooth Connectivity:** Wirelessly stream music from your mobile device.
- **MicroSD Card Reader:** Play music directly from microSD cards.
- **FM Radio:** Enjoy your favorite radio stations.
- **Line-In (Aux-In):** Connect the headphones to your smartphone or laptop using the included Aux-In cable.
- **Foldable Design:** Easy to transport and store.
- **Built-in Microphone:** For hands-free calling.
- **USB Charging Cable:** Included for convenient charging.

What's in the Box




Image: Contents of the Omega Wireless Bluetooth Headphones package, showing the headphones, charging cable, and audio cable.

- USB Charging Cable
- User Manual (English version)
- Omega Wireless Bluetooth Headphones
- 3.5mm Mini-Jack Audio Cable (120 cm)

Setup

1. Charging the Headphones

Before first use, fully charge the headphones. Connect the included USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. Charging time is approximately 2 hours.

2. Powering On/Off

Press and hold the Power button ( ) for a few seconds to turn the headphones on or off. A voice prompt will indicate the power status.





Image: Close-up view of the right earcup, showing the control buttons including the power button, volume/track controls, and mode button.

Operating Instructions

Bluetooth Pairing

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power button ( ) until the LED indicator flashes blue and red, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "FH0916B" or "Omega Headphones" from the list of found devices.
5. Once paired, the LED indicator will flash blue slowly, and a voice prompt will confirm the connection.
6. The headphones will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

Music Playback (Bluetooth/MicroSD)

- **Play/Pause:** Press the Play/Pause button ( ).
- **Next Track/Volume Up:** Press and hold the "V+" button for volume up. Short press for next track.
- **Previous Track/Volume Down:** Press and hold the "V-" button for volume down. Short press for previous track.
- **MicroSD Playback:** Insert a microSD card into the designated slot. The headphones will automatically switch to MP3 mode and begin playing music from the card.

FM Radio Mode

- Press the "M" (Mode) button to switch to FM Radio mode.
- Press the Play/Pause button ( ) to auto-scan and save available FM stations.
- Use the "V+" and "V-" buttons to navigate between saved stations.

Aux-In Mode

Connect one end of the 3.5mm audio cable to the Aux-In port on the headphones and the other end to the audio output of your device (e.g., smartphone, laptop). The headphones will automatically switch to Aux-In mode. In this mode, controls on the headphones (volume, track) may not function, and you will need to control playback from your connected device.

Hands-Free Calling

- **Answer Call:** Press the Play/Pause button ( ) when an incoming call rings.
- **End Call:** Press the Play/Pause button ( ) during a call.
- **Reject Call:** Press and hold the Play/Pause button ( ) for 2 seconds when an incoming call rings.
- **Redial Last Number:** Double-press the Play/Pause button ( ) in Bluetooth mode.

Maintenance

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Do not disassemble or attempt to repair the headphones yourself, as this will void the warranty.
- Store the headphones in a cool, dry place when not in use.

Troubleshooting

Problem	Possible Cause / Solution
Headphones do not power on.	Battery is low. Charge the headphones fully.

Problem	Possible Cause / Solution
Cannot pair with Bluetooth device.	Ensure headphones are in pairing mode (flashing blue/red LED). Ensure Bluetooth is enabled on your device. Move headphones closer to the device (within 10m). Clear previous pairings on your device and try again. Restart both the headphones and your device.
No sound or low volume.	Adjust volume on both headphones and connected device. Ensure headphones are properly paired. If using Aux-In, ensure cable is fully inserted.
FM Radio reception is poor.	Move to an area with better signal. The audio cable can sometimes act as an antenna, try connecting it.

Specifications

Parameter	Value
Model Number	FH0916B
Bluetooth Version	v3.0
Bluetooth Profiles Supported	HFP1.6, A2DP1.2, AVRCP1.4
Wireless Range	Up to 10 meters (33 feet)
Standby Time	Up to 100 hours
Music Playback Time	Up to 8 hours
Battery Capacity	400mAh
Charging Time	Approx. 2 hours
Weight	150g
Dimensions (Product)	17.5 x 19.5 x 7.5 cm
Headphone Jack	3.5 mm Jack
Impedance	24 Ohm
Ear Placement	Over Ear

Warranty and Support

For warranty information and technical support, please refer to the contact details provided on the product packaging or the official OMEGA website. Keep your proof of purchase for warranty claims.

© 2023 OMEGA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06Y56JZZH

More documents and user manuals: **https://manuals.plus/**