

[Manuals.plus](#) /

› [Rfiver](#) /

› Rfiver Universal Swivel Floor TV Stand Instruction Manual for 40-77 Inch TVs (Model: 2-Shelf)

Rfiver 2-Shelf Floor TV Stand

Rfiver Universal Swivel Floor TV Stand Instruction Manual

Model: 2-Shelf Floor TV Stand

For 40-77 Inch LCD LED Flat/Curved Screen TVs

1. INTRODUCTION

Thank you for choosing the Rfiver Universal Swivel Floor TV Stand. This manual provides detailed instructions for the safe and proper assembly, operation, and maintenance of your new TV stand. Designed for 40-77 inch LCD, LED, flat, or curved screen televisions, this stand features a sturdy wood base, height adjustability, a flexible shelf, and integrated cable management to enhance your viewing experience and organize your entertainment space.



Figure 1: Rfiver Universal Swivel Floor TV Stand with a mounted television.

2. SAFETY INFORMATION

WARNING:

- Read all instructions carefully before assembly and use. Failure to do so may result in serious personal injury or property damage.
- Ensure all components are securely fastened before placing a television on the stand.
- Do not exceed the maximum weight capacity of 110 lbs for the TV mount and 10 lbs for the metal shelf.
- This TV stand is designed for indoor use only. Keep the TV stand away from direct exposure to sunlight, high temperatures, and water to prevent damage and ensure longevity.
- Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- Always use appropriate lifting techniques when handling the television and stand components. It is recommended to have at least two people for lifting and mounting the TV.
- Periodically check all connections and fasteners to ensure they remain tight and secure.

3. PACKAGE CONTENTS

Please verify that all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact Rfiver customer service for assistance.

- Main Support Column
- Wood Base
- TV Mounting Bracket (with VESA arms)
- Adjustable Metal Shelf
- Hardware Kit (screws, washers, spacers, nuts, Allen wrench)
- Cable Management Clips/Ties
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Rfiver TV Stand. It is recommended to lay out all parts on a soft, clean surface to prevent scratches.

4.1 Pre-Assembly Check

- **TV Compatibility:** Ensure your TV's VESA bolt pattern is between 100(h)mm x 100(w)mm and 600(h)mm x 400(w)mm. The stand supports TVs from 40 to 77 inches.
- **Weight Capacity:** Confirm your TV weighs no more than 110 lbs.



Figure 2: VESA compatibility and weight capacity guidelines.

4.2 Base and Main Column Assembly

1. Attach the main support column to the sturdy wood base using the provided screws and tools. Ensure the connection is tight and stable.
2. The wood base is designed to be thicker and heavier for enhanced stability.



Figure 3: Detail of the sturdy wooden base.

4.3 TV Bracket Installation

1. Secure the TV mounting bracket to the back of your television using the appropriate VESA screws, washers, and spacers from the hardware kit.
2. Carefully lift the television and hook the mounted bracket onto the main support column. Ensure the safety lock mechanism engages to prevent accidental dislodgement.
3. The TV bracket offers 3 levels of height adjustment, and the metal pole support provides 8 levels, totaling 24 possible height settings from 50 to 56 inches.




Figure 4: TV height adjustment options.



Figure 5: Safety lock detail for secure TV mounting.

4.4 Shelf Installation and Adjustment

1. Attach the metal shelf to the main support column at your desired height. The shelf is designed to hold A/V components, cable boxes, DVD players, or gaming systems, with a maximum capacity of 10 lbs.
2. The shelf is flexible and can be adjusted up or down along the main column to accommodate various

component sizes.




Figure 6: Adjustable metal shelf.




Figure 7: Detail of the flexible metal shelf.

4.5 Cable Management


Utilize the integrated wire storage at the back of the bracket and column to hide and organize cables. This helps maintain a clean and organized appearance for your entertainment area.



CABLE MANAGEMENT



SAFETY LOCK



FLEXIBLE METAL SHELF



UNBREAKABLE

Figure 8: Efficient cable management system.




Figure 9: Detail of cable management clips.

5. OPERATING INSTRUCTIONS

5.1 Swivel Function

The TV mounting bracket allows for a swivel of $\pm 30^\circ$ degrees to the left or right. Gently push the side of the television to adjust the viewing angle as needed. This feature provides optimal viewing from various positions in your room.



Figure 10: Swivel functionality for flexible viewing.



Swivel Icon.

5.2 Height Adjustment

To adjust the TV height after initial assembly, you will need to carefully unhook the TV from the main column, adjust the bracket or pole support to the desired level, and then re-secure the TV. Refer to section 4.3 for details on the 24 available height settings.



Height Adjustment Icon.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the stand. Avoid abrasive cleaners or solvents that may damage the finish.
- **Inspection:** Periodically inspect all bolts and connections to ensure they are secure. Tighten any loose fasteners.
- **Environment:** Ensure the stand is not exposed to extreme temperatures or humidity, which can affect the wood and metal components.

7. TROUBLESHOOTING

- **Stand feels unstable:**
 - Ensure all screws and bolts are tightened securely.
 - Verify the TV weight does not exceed the stand's capacity.
 - Place the stand on a flat, level surface.
- **TV not fitting the bracket:**
 - Double-check your TV's VESA pattern against the stand's compatibility (100x100mm to 600x400mm).
 - Ensure you are using the correct screws and spacers for your TV model.
- **Cables are messy:**
 - Utilize the integrated cable management system by routing wires through the designated channels in the main column.
 - Use additional cable ties if necessary to bundle excess wires.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	26 x 15.7 x 56 inches (W x D x H)
Item Weight	27.7 pounds
TV Size Compatibility	40-77 inches
VESA Compatibility	100x100mm up to 600x400mm
TV Weight Capacity	Up to 110 lbs
Shelf Weight Capacity	Up to 10 lbs
Material	Alloy Steel & Wood

Color	Black
Movement Type	Swivel ($\pm 30^\circ$)
Height Adjustment	50-56 inches (24 levels)




Figure 11: Detailed product dimensions and capacities.

9. WARRANTY & SUPPORT

All Rfiver products are backed by a **5-year manufacturer warranty** to ensure your satisfaction. For any questions, issues, or support needs, please contact our local customer service team. We are prepared to provide prompt replies and solutions.

For further assistance, please visit the official Rfiver website or contact our support team directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B06Y61LH3N>

More documents and user manuals: <https://manuals.plus/>