

Ateco 609

Ateco Reversible 2-Sided Revolving Cake Decorating Stand

MODEL 609 INSTRUCTION MANUAL

1. Product Overview

The Ateco Model 609 Reversible 2-Sided Revolving Cake Decorating Stand is designed to assist in the decoration of both round and rectangular cakes. This versatile stand features two distinct decorating surfaces: a 12-inch by 16-inch rectangular turntable for sheet cakes and a 12-inch diameter circular turntable for round cakes. Both turntables are equipped with blue non-skid inserts to prevent cake slippage during use and can be locked in place when rotation is not desired. The stand is constructed from durable, food-grade plastic.



Image 1.1: The Ateco Model 609 stand, showcasing its reversible design with both rectangular and round decorating

surfaces.

2. Setup

1. **Unpacking:** Carefully remove all components from the packaging. Inspect the stand for any signs of damage.
2. **Cleaning:** Before first use, wipe the stand with a damp cloth. Do not submerge the entire unit in water. Refer to the Maintenance section for detailed cleaning instructions.
3. **Selecting the Turntable:** The stand features two sides. Determine whether you require the rectangular (12" x 16") or round (12" diameter) decorating surface for your cake.
4. **Positioning:** Place the desired turntable side facing upwards on a stable, flat countertop. Ensure the stand is level.




Image 2.1: Top view of the rectangular decorating surface, featuring non-skid inserts.



Image 2.2: Top view of the round decorating surface, also with non-skid inserts.

3. Operating Instructions

- 1. Placing the Cake:** Carefully center your cake on the chosen decorating surface. The blue non-skid inserts are designed to help secure the cake.
- 2. Rotating the Stand:** Gently rotate the turntable as needed for even frosting or detailed decoration. The stand is designed for smooth rotation.
- 3. Locking the Turntable:** If a stationary surface is preferred, locate the locking mechanism on the side of the base. Engage the lock to prevent rotation. Disengage to resume rotation.
- 4. Switching Sides:** To use the alternate decorating surface, lift the top turntable section from the base, flip it over, and re-seat it securely on the base.



Image 3.1: Detail of the locking mechanism located on the base of the stand, used to secure the turntable.

4. Maintenance

Proper care ensures the longevity and performance of your Ateco decorating stand.

- **Cleaning:** Wipe the stand clean with a damp cloth after each use.
- **Drying:** Ensure the stand is thoroughly dry before storage.
- **Dishwasher Safety:** This product is **not** dishwasher safe. Do not submerge the stand in water, as this may affect the internal rotating mechanism.
- **Storage:** Store in a clean, dry place away from direct heat or sunlight.

5. Troubleshooting

Issue	Possible Cause	Solution
-------	----------------	----------

Issue	Possible Cause	Solution
Turntable does not rotate smoothly.	Debris in the rotating mechanism; locking mechanism engaged.	Ensure the locking mechanism is disengaged. Clean the area around the base and rotating parts with a damp cloth to remove any obstructions.
Cake slips on the surface.	Non-skid inserts are dirty or wet; cake not centered.	Ensure the non-skid inserts are clean and dry. Center the cake properly on the turntable. A small amount of frosting can also help secure the cake.
Stand feels unstable.	Uneven surface; stand not properly assembled.	Place the stand on a flat, stable surface. Ensure the top turntable section is securely seated on the base.

6. Specifications

Feature	Detail
Brand	Ateco
Model Number	609
Material	Food-grade Plastic
Color	White
Rectangular Turntable Dimensions	12 inches x 16 inches
Round Turntable Diameter	12 inches
Height	3.5 inches (approximate)
Item Weight	2.3 pounds
Special Features	Reversible, 2-sided, Revolving, Non-skid inserts, Lockable rotation
Care Instructions	Wipe with damp cloth, do not submerge

7. Warranty and Support

Ateco products are manufactured to high standards. For specific warranty information or support inquiries, please refer to the official Ateco website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

For additional product information and other Ateco offerings, visit the [Ateco Store on Amazon](#).