

manuals.plus /

- › [Zidoo](#) /
- › [ZIDOO V5 Wireless Keyboard Air Mouse User Manual](#)

## Zidoo V5

# ZIDOO V5 Wireless Keyboard Air Mouse User Manual

Model: V5

## INTRODUCTION

---

This manual provides detailed instructions for the ZIDOO V5 Wireless Keyboard Air Mouse. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. The ZIDOO V5 combines a wireless keyboard, air mouse, and voice input functionality, designed for use with various devices including Google Android TV/Box, IPTV, HTPC, Windows, Mac OS, and Xbox.



Image: Front and back view of the ZIDOO V5 Wireless Keyboard Air Mouse, showcasing its dual-sided design with a remote control layout on one side and a QWERTY keyboard on the other.

## 1. SETUP

---

### 1.1 Package Contents

- ZIDOO V5 Wireless Keyboard Air Mouse
- USB Receiver

- USB Charging Cable
- User Manual (this document)

## 1.2 Charging the Device

The ZIDOO V5 has a built-in rechargeable battery. Before first use, fully charge the device.

1. Connect the small end of the USB charging cable to the micro-USB port on the ZIDOO V5.
2. Connect the standard USB end of the cable to a USB power adapter (not included) or a powered USB port on your computer or device.
3. The indicator light on the device will illuminate during charging and turn off when fully charged.



Image: Side view of the ZIDOO V5 Wireless Keyboard Air Mouse, highlighting the micro-USB charging port located on the top edge.

## 1.3 Connecting the USB Receiver

The ZIDOO V5 connects wirelessly via a 2.4G USB receiver.

1. Locate the USB receiver, typically stored within the battery compartment or a dedicated slot on the device.
2. Plug the USB receiver into an available USB port on your target device (e.g., Android TV box, HTPC, computer).
3. The device should automatically recognize the receiver and install necessary drivers. No manual pairing is usually required.

## 2. OPERATING INSTRUCTIONS

---

### 2.1 Power On/Off

Press the **Power Switch** button (usually located at the top left of the remote side) to turn the device on or off.

### 2.2 Remote Control Side Functions



Image: Detailed view of the ZIDOO V5 remote control side, with labels for each button's function, including Power Switch, Muting, TV Control Area, Home, APP Switch, Direction Key, OK, Enter, Return, Menu, Voice Input, Volume Up/Down, APP Management, Subtitle, Cursor Switch, Audio Track, Previous, Stop, and Next.

- **Power Switch:** Turns the device on or off.
- **Muting:** Mutes or unmutes audio.
- **TV Control Area:** Dedicated buttons for basic TV functions (e.g., input, power for TV).
- **Home:** Returns to the main screen or home interface.
- **APP Switch:** Switches between applications.
- **Direction Key (Up, Down, Left, Right):** Navigates through menus and options.
- **OK:** Confirms selections.
- **Enter:** Confirms input or selection.
- **Return:** Goes back to the previous screen or menu.
- **Menu:** Opens context-sensitive menus.
- **Voice Input:** Activates voice command or search (requires compatible software/device).
- **VOL+ / VOL-:** Adjusts volume up or down.
- **APP Management:** Accesses application management settings.
- **Subtitle:** Toggles or selects subtitle options.
- **Cursor Switch:** Toggles between air mouse mode and D-pad navigation.
- **Audio Track:** Selects different audio tracks.
- **Previous / Stop / Next:** Media playback controls.

## 2.3 Air Mouse Function

The ZIDOO V5 features a 3-Gyro + 3-Gsensor for precise air mouse control.

1. To activate the air mouse, ensure the cursor switch is enabled.
2. Hold the device in your hand and move your wrist to control the on-screen cursor.
3. Press the **OK** button to click.
4. To recalibrate the air mouse, place the device on a flat surface for a few seconds until the cursor stabilizes.

## 2.4 Keyboard Side Functions



Image: Close-up view of the ZIDOO V5 keyboard side, displaying a full QWERTY layout with alphanumeric keys, function keys (Fn, Ctrl, Alt), and special characters.

The reverse side of the ZIDOO V5 features a full QWERTY keyboard for easy text input.

- **Typing:** Use the keys as you would a standard keyboard.
- **Function (Fn) Key:** Press and hold the **Fn** key to access secondary functions printed in blue on certain keys (e.g., numbers, symbols).
- **Caps Lock:** Toggles uppercase and lowercase letters.
- **Back:** Acts as a backspace key.
- **Enter:** Confirms text input.

## 2.5 Voice Input

The ZIDOO V5 supports voice input functionality.

1. Ensure your connected device supports voice input and has the necessary applications installed (e.g., Google Assistant, voice search).
2. Press the **Voice Input** button (microphone icon) on the remote control side.
3. Speak clearly into the microphone located at the bottom of the device.
4. Release the button when finished speaking.

### 3. MAINTENANCE

---

#### 3.1 Cleaning

- Use a soft, dry cloth to clean the surface of the device.
- Do not use liquid cleaners, aerosols, or abrasive materials, as these may damage the device.

#### 3.2 Storage

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan.

#### 3.3 Battery Care

- Avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in constant use, to maintain battery health.

### 4. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Device not responding	Low battery; USB receiver not connected; Device turned off; Out of range.	Charge the device; Ensure USB receiver is securely plugged in; Turn on the device; Move closer to the receiver (within 10 meters).
Air mouse cursor erratic or not moving	Needs calibration; Interference; Air mouse mode disabled.	Place the device on a flat surface for a few seconds to recalibrate; Ensure no strong electromagnetic interference; Press the Cursor Switch button to enable air mouse mode.
Voice input not working	Device/application does not support voice input; Microphone blocked; Software issue.	Verify host device/application compatibility; Ensure microphone is clear; Restart the host device.
Keyboard input incorrect	Caps Lock enabled; Fn key usage; Language settings.	Check Caps Lock status; Ensure correct use of Fn key for secondary characters; Verify language settings on the host device.

### 5. SPECIFICATIONS

---

- **Brand:** Zidoo
- **Model:** V5 (zidooV517420)
- **Connectivity:** 2.4G Wireless (Radio Frequency)

- **Sensors:** 3-Gyro + 3-Gsensor
- **Features:** Wireless Keyboard, Air Mouse, Voice Input, Rechargeable Battery
- **Compatible Operating Systems:** Android, Mac OS, Windows
- **Compatible Devices:** Google Android TV/Box, IPTV, HTPC, Windows PCs, Mac OS devices, Xbox
- **Power Source:** Built-in Rechargeable Battery
- **Dimensions:** Approximately 21.2 x 11.4 x 1.8 cm
- **Weight:** Approximately 200 g

## 6. WARRANTY INFORMATION

---

Specific warranty details for the ZIDOO V5 Wireless Keyboard Air Mouse may vary by region and retailer. Please refer to the warranty card included with your purchase or contact your point of sale for detailed information regarding warranty coverage and terms.

## 7. SUPPORT

---

For technical support or further assistance, please visit the official Zidoo website or contact their customer service department. Contact information can typically be found on the product packaging or the Zidoo official website.

*Note: Product specifications and features are subject to change without prior notice.*

