

[Manuals.plus](#) /

› [USARemote](#) /

› USARemote Key Fob Shell Case Instruction Manual

USARemote t-14t-3b-case

USARemote Key Fob Shell Case Instruction Manual

MODEL: T-14T-3B-CASE

Replacement Key Fob Keyless Entry Remote Shell Case & Pad

1. Introduction

This manual provides instructions for the USARemote Key Fob Keyless Entry Remote Shell Case & Pad, model t-14t-3b-case. This product is designed as a direct replacement for your original worn or damaged key fob shell, allowing you to transfer your existing internal electronics and battery into a new, durable casing. Please note that this product includes only the outer shell and button pad; it does not contain any internal electronic components or a battery.

2. Product Contents

Your package should contain the following items:

- One (1) Key Fob Replacement Shell Case
- One (1) Button Pad

Important: Electronics and battery are NOT included with this product.



INCLUDED

*Case and shell only
No electronics*

INSTALLATION

*Remove old case
and install new one
No programming required*

CONDITION

*New, never used
replacement part*

PART NUMBERS

GQ43VT14T

89742-AA030

Image showing the key fob shell, button pad, and a clear indication that electronics are not included. It also highlights the simple installation process and the new condition of the replacement part.

3. Compatibility

This replacement key fob shell is compatible with various Toyota and Pontiac vehicle models. Please verify your original key fob's part number (P/N) to ensure compatibility.

Compatible Part Number:

P/N: GQ43VT14T

P/N: 89742-AA030

Compatible Vehicle Models:

- Toyota Camry
- Toyota Corolla
- Toyota Matrix

- Toyota Sienna
- Toyota Solara (2002-2003)
- Pontiac Vibe



Image displaying specific Toyota models and years compatible with this key fob shell, including Solara (2002-2003) and Camry (2002-2006).

4. Installation Instructions (Setup)

Replacing your key fob shell is a straightforward process and does not require any programming. Follow these steps to transfer your existing electronics:

1. **Open Your Old Key Fob:** Carefully pry open your existing key fob shell. You may need a small flathead screwdriver or a pry tool. Be gentle to avoid damaging the internal circuit board.
2. **Remove Internal Components:** Once open, carefully remove the circuit board (electronics) and the battery from the old shell. Note their orientation.

3. **Insert into New Shell:** Place the button pad into the new USARemote shell. Then, carefully insert the circuit board and battery into the new shell, ensuring they are correctly oriented and seated securely.
4. **Close the New Shell:** Align the two halves of the new shell and press them firmly together until they snap shut. Ensure there are no gaps and the shell is fully closed.

No re-programming is required as you are simply transferring the existing electronics.



Detailed view of the key fob shell opened, illustrating where the internal circuit board and battery would be placed. The buttons for Lock, Unlock, and Hold are visible on the closed half.

5. Operation

Once your existing electronics are installed in the new USARemote shell, the key fob will function exactly as it did before. The new shell provides a fresh, durable exterior for your remote's internal components. The buttons on the shell correspond to the functions of your original remote:

- **LOCK:** Locks all vehicle doors.
- **UNLOCK:** Unlocks all vehicle doors.
- **HOLD (Trunk/Panic):** Depending on your vehicle model and original remote, this button may activate the trunk release or a panic alarm when held down.





Image showing the back of the key fob shell, featuring a distinct red "PANIC" button, which is typically located on the reverse side of the remote.

6. Maintenance

To ensure the longevity of your USARemote key fob shell, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the shell with a soft, damp cloth to remove dirt or grime. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic.
- **Protection:** While the shell is made from durable materials, avoid dropping it on hard surfaces or exposing it to extreme temperatures or direct sunlight for prolonged periods.
- **Liquid Exposure:** This shell is not waterproof. Avoid exposing it to water or other liquids, as this could damage the internal electronics.

7. Troubleshooting

If you encounter issues after installing your electronics into the new shell, consider the following:

- **Shell Not Closing Properly:** Ensure the internal circuit board and battery are correctly seated and aligned within the shell. Do not force the shell closed if there is resistance; re-open and re-align components.
- **Buttons Not Responding:** Verify that the button pad is correctly placed and that the internal circuit board's buttons align with the shell's buttons. If the remote was not working before the shell replacement, the issue is likely with the internal electronics or battery, not the new shell.
- **Remote Not Functioning:** Since this product is only a shell, it does not affect the remote's electronic functionality. If your remote is not working after transferring the components, check the battery in your circuit board or consult a professional for electronic diagnosis.

8. Specifications

Feature	Detail
Product Model Number	t-14t-3b-case

OEM Part Number (Compatible)	GQ43VT14T, 89742-AA030
Material	Plastic
Number of Buttons	4 (Lock, Unlock, Hold, Panic)
Product Dimensions	1.25"L x 0.5"W
Item Weight	0.528 ounces
Automotive Fit Type	Vehicle Specific Fit

9. Warranty & Support

USARemote is committed to providing high-quality products. If you experience any issues with your key fob shell, please refer to the following:

- Return Policy:** We offer a hassle-free return policy in case your item does not work as expected. Please initiate returns through your order section on the platform where the purchase was made.
- Customer Support:** For further assistance or inquiries, please contact USARemote customer support through the seller contact options on the purchase platform.

Legal Disclaimer: *This product is a replacement aftermarket part.*

© 2024 USARemote. All rights reserved.

For more products and information, visit the [USARemote Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question