

[Manuals.plus](#) /

› [Carlett](#) /

› Carlett LETT 460 Shopping Trolley User Manual

## Carlett LETT-460

# Carlett LETT 460 Shopping Trolley User Manual

## 1. INTRODUCTION

---

The Carlett LETT 460 Shopping Trolley is designed to provide a convenient and efficient way to transport groceries and other items. Constructed from lightweight yet durable aluminum, this trolley features a foldable design, an adjustable handle, and a spacious, waterproof bag with an insulated compartment. This manual provides instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your Carlett LETT 460.



Figure 1: Carlett LETT 460 shopping trolley in its upright, unfolded position, viewed from the side. The black bag with white 'CARLETT' logo is visible, along with the silver aluminum frame and four black wheels. The adjustable handle is extended.





Figure 2: Front view of the Carlett LETT 460 shopping trolley, showing the black bag with a striped flap and the 'Lett460' model name. The sturdy aluminum frame and four wheels are clearly visible.

## 2. SETUP AND ASSEMBLY

---

The Carlett LETT 460 requires minimal assembly. Follow these steps to prepare your trolley for use:

1. **Unfolding the Frame:** Gently pull the handle upwards and outwards to unfold the aluminum frame until it locks into its open position. Ensure all locking mechanisms are engaged for stability.
2. **Attaching the Bag:** The main shopping bag is designed to be easily attached and removed. Align the bag with the frame and secure it using the integrated Velcro fasteners or clips provided. Ensure the bag is firmly attached to prevent it from shifting during use.
3. **Wheel Installation (if detached):** If the wheels are not pre-installed, attach them according to the instructions provided with the wheel components. Ensure they click securely into place. The front wheels are designed to rotate 360 degrees for easy maneuverability.



**Leicht**  
Leichtes Gestell (Aluminium)



**Verstellbarer Schiebegriff**  
Verstellbarer Schiebegriff (3 Positionen)



**Zerlegbar und leise**  
4 laufruhige und leicht abnehmbare Räder  
(Material EVA) Um 360 Grad drehbare  
Vorderräder



**Stabil**  
Unterer Bügel



**Verwandelbar**  
Verwandelbar in 2 Räder



**Isothermische Tasche**  
Innenfach für Tiefgefrorenes



**Praktisch und kompakt**  
Einfaches Zusammenklappen und  
abnehmbare Tasche (mit Klettverschlüssen)



**Großes Fassungsvermögen**  
Tasche mit großem Fassungsvermögen (40  
Liter), dehnbar und wasserdicht



**Innenfächer**  
Taschen seitlich und hinten mit  
Reißverschluss

Figure 3: This diagram illustrates key features of the Carlett LETT 460, including its lightweight aluminum frame, adjustable handle with three positions, easily removable and quiet EVA wheels with 360-degree rotating front wheels, a stable lower bracket, the ability to convert to a 2-wheel configuration, an insulated inner compartment for frozen goods, practical and compact folding with a removable bag, a large 40-liter expandable and waterproof capacity, and inner side and rear zippered pockets.

### 3. OPERATING INSTRUCTIONS

#### 3.1 Adjusting the Handle

The handle of the Carlett LETT 460 is adjustable to three different positions to suit your height and comfort. Locate the adjustment buttons or levers on the side of the handle. Press them to release the lock and slide the handle to your desired height. Release the buttons to lock the handle in place. Ensure it is securely locked before use.

#### 3.2 Using the Trolley

- **Loading:** Place your items inside the main compartment of the bag. Utilize the insulated inner compartment for frozen or temperature-sensitive items. The side and rear zippered pockets can be used for smaller essentials like keys, wallet, or an umbrella.
- **Maneuvering:** The trolley can be pushed like a pram using its four wheels, with the front wheels offering 360-degree rotation for easy steering. For navigating stairs or curbs, the trolley can be converted to a 2-wheel configuration by tilting it back onto its larger rear wheels.

- **Folding for Storage:** To fold the trolley, ensure the bag is empty and removed if desired. Locate the folding mechanism (often a lever or button near the base or handle). Engage the mechanism and gently collapse the frame until it is compact.

## 4. MAINTENANCE

Regular maintenance will extend the life of your Carlett LETT 460 Shopping Trolley:

- **Cleaning the Frame:** Wipe the aluminum frame with a damp cloth and mild soap. Dry thoroughly to prevent water spots or corrosion. Avoid abrasive cleaners.
- **Cleaning the Bag:** The bag can be wiped clean with a damp cloth. For more thorough cleaning, it can be detached from the frame. Do not machine wash or tumble dry the bag unless specified on its care label. Allow it to air dry completely before reattaching.
- **Wheel Care:** Periodically check the wheels for debris such as hair, string, or dirt. Remove any obstructions to ensure smooth rolling. If wheels become stiff, a small amount of silicone-based lubricant can be applied to the axles.
- **Storage:** Store the trolley in a dry place, away from direct sunlight and extreme temperatures, when not in use.

## 5. TROUBLESHOOTING

If you encounter issues with your Carlett LETT 460, refer to the following common problems and solutions:

- **Trolley does not fold or unfold smoothly:**
  - Ensure all locking mechanisms are disengaged before attempting to fold or unfold.
  - Check for any obstructions in the folding joints.
  - Apply a small amount of silicone lubricant to the moving parts of the frame.
- **Wheels are stiff or not rolling properly:**
  - Inspect wheels for trapped debris (hair, lint, dirt) and remove it.
  - Ensure the wheels are securely attached to the frame.
  - Lubricate the wheel axles with a silicone-based spray.
- **Bag is not staying securely attached:**
  - Verify that all Velcro fasteners or clips are properly engaged.
  - Check for wear or damage to the fasteners; replace if necessary.

## 6. SPECIFICATIONS

|                                |                                                         |
|--------------------------------|---------------------------------------------------------|
| Brand                          | Carlett                                                 |
| Model Number                   | LETT-460                                                |
| Product Dimensions (D x W x H) | 71 x 20 x 42 cm                                         |
| Material                       | Aluminum (Frame), EVA (Wheels), Waterproof Fabric (Bag) |
| Color                          | Black                                                   |
| Item Weight                    | 4.8 kg                                                  |

|                   |                                                      |
|-------------------|------------------------------------------------------|
| Bag Capacity      | 40 Liters (expandable)                               |
| Handle Material   | Metal                                                |
| Assembly Required | Yes                                                  |
| Wheel Type        | 4 wheels (2 fixed rear, 2 x 360-degree swivel front) |

## 7. WARRANTY AND SUPPORT

For specific warranty information regarding your Carlett LETT 460 Shopping Trolley, please refer to the documentation provided at the time of purchase. If you require further assistance, have questions, or need to report an issue, please contact Carlett customer service through their official website or the retailer from whom you purchased the product.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question