Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- OttLite /
- > OttLite 24 Watt Floor Lamp with Flexible Neck Instruction Manual

OttLite 823WG4-FFP

OttLite 24 Watt Floor Lamp with Flexible Neck Instruction Manual

Model: 823WG4-FFP

1. SETUP AND ASSEMBLY

Carefully unpack all components from the packaging. Ensure all parts are present before beginning assembly. The lamp consists of a sturdy base, a main pole, a flexible neck, and the lamp head with an included bulb.

- 1. **Attach the Main Pole to the Base:** Align the bottom end of the main pole with the opening in the lamp base. Gently push and twist until it is securely seated. The base is designed to be heavy for stability.
- 2. **Install the Bulb:** The OttLite 24 Watt Type C bulb is included. Carefully insert the bulb into the lamp head socket. Ensure it is firmly seated.
- 3. Connect to Power: Plug the power cord into a standard electrical outlet.



Figure 1: Fully assembled OttLite 24 Watt Floor Lamp. The lamp features a sturdy base, a straight pole, and a flexible neck leading to the lamp head.



Figure 2: Lamp dimensions. The height adjusts from 44 to 54 inches (111.8 cm to 137.2 cm), and the base size is 12 x 9 inches (30.1 x 22.9 cm).

2. OPERATING INSTRUCTIONS

The OttLite 24 Watt Floor Lamp is designed for ease of use, providing natural daylight illumination for various tasks.

- Power On/Off: Locate the power switch on the lamp head. Flip the switch to the 'On' position to illuminate the lamp. Flip it to 'Off' to turn the lamp off.
- Adjusting the Flexible Neck: The lamp features a highly flexible neck, allowing you to position the light precisely where needed. Gently bend the flexible neck to direct the lamp head. The heavy base ensures stability even when the neck is fully extended or angled.
- **Optimal Lighting:** This lamp provides natural daylight illumination, which helps reduce glare and eyestrain, making it ideal for reading, crafting, and other detailed tasks.



Figure 3: The flexible neck allows for precise positioning of the light.



Figure 4: The lamp's sturdy base provides excellent stability.

3. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your OttLite lamp.

- Cleaning: To clean the lamp, ensure it is unplugged from the power outlet. Use a soft, dry cloth to wipe down the lamp head, flexible neck, pole, and base. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** The included OttLite bulb is designed to last up to 10,000 hours. When replacement is necessary, ensure the lamp is unplugged and the bulb has cooled down. Carefully remove the old bulb and insert a new 24 Watt Type C OttLite replacement bulb.



Figure 5: The 24 Watt Type C OttLite bulb, designed for long life and natural daylight illumination.

4. TROUBLESHOOTING

If you encounter any issues with your OttLite lamp, refer to the following common troubleshooting steps:

- Lamp Does Not Turn On:
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check the power switch on the lamp head to ensure it is in the 'On' position.
 - Verify that the bulb is correctly seated in its socket. If the bulb is old, it may need replacement.
- Light is Flickering:

• While OttLite lamps are designed for steady illumination, flickering can sometimes occur if the bulb is not fully seated or is nearing the end of its lifespan. Re-seat the bulb or replace it if necessary.

• Lamp is Unstable:

- Ensure the main pole is securely attached to the heavy base.
- Place the lamp on a flat, stable surface.

If these steps do not resolve the issue, please contact OttLite customer support for further assistance.

5. SPECIFICATIONS

Feature	Detail
Brand	OttLite
Model Number	823WG4-FFP (Manufacturer Part Number: TC00560)
Lamp Type	Floor Lamp with Flexible Neck
Light Source Type	CFL
Wattage	24 watts
Brightness	1300 Lumen
Product Dimensions	6.25"D x 10"W x 45"H (Adjustable height up to 54")
Item Weight	13.8 Pounds
Base Material	Metal
Shade Material	Plastic
Color	White
Switch Type	Touch
Included Components	Bulb
UPC	761712005607, 761712013626

6. WARRANTY AND SUPPORT

For warranty information or technical support regarding your OttLite 24 Watt Floor Lamp, please refer to the documentation included with your purchase or visit the official OttLite website. Customer service contact details are typically available on the manufacturer's website.

Please retain your proof of purchase for any warranty claims.

Related Documents - 823WG4-FFP

COLLAN STATEMENT OF THE PROPERTY OF THE PROPER	OttLite 24w Extended Reach Floor Lamp Assembly and Safety Instructions Comprehensive user manual for the OttLite 24w Extended Reach Floor Lamp (Model 823WG4). This document provides detailed assembly instructions, critical safety warnings, product registration guidance, and tube replacement procedures. It includes textual descriptions of diagrams and merges multilingual content into clear English instructions.
The state of the s	OttLite F30G53/F30SV3 13-Watt Flexible Natural Daylight Desk Lamp User Guide Learn how to assemble, use, and maintain your OttLite F30G53/F30SV3 13-Watt Flexible Natural Daylight Desk Lamp. This guide includes step-by-step instructions, safety warnings, and bulb replacement information.
Onture Once of the control of the c	OttLite Soft Touch Flex LED Lamp User Manual and Safety Information Comprehensive guide for the OttLite Soft Touch Flex LED Lamp, including assembly, operation, safety warnings, and FCC compliance information. Covers models D59PNC, D5900C, D5900B, D59PNB, D59CPC, D5900B-FFP, D59PNB-FFP.
	OttLite EasyView LED Craft Floor Lamp with Magnifier - Assembly, Operation, and Safety Guide Comprehensive guide for the OttLite EasyView LED Craft Floor Lamp (CSP57WGC, CSP57WGC-SHPR), detailing assembly instructions, operation, safety warnings, and FCC compliance.
STATE OF THE PROPERTY OF THE P	OttLite LED Desk Lamp with Color Changing Tunnel - User Manual Comprehensive instructions and safety guidelines for the OttLite LED Desk Lamp with Color Changing Tunnel (models CY4G59-FFP, CY4009-FFP). Learn how to operate the lamp's touch controls, adjust brightness and color modes, use the color-changing tunnel, and understand important safety precautions.
	OttLite Dual Shade LED Floor Lamp with USB Charging Station - Assembly and Operation Guide Comprehensive guide for the OttLite Dual Shade LED Floor Lamp with USB Charging Station (Model 6D200C-SHPR), covering assembly, operation, safety warnings, and FCC compliance.

Documents - OttLite - 823WG4-FFP



OttLite 24w Extended Reach Floor Lamp Assembly and Safety Instructions

Comprehensive user manual for the OttLite 24w Extended Reach Floor Lamp (Model 823WG4). This document provides detailed assembly instructions, critical safety warnings, product registration guidance, and tube replacement procedures. It includes textual descriptions of diagrams and merges multilingual content into clear English instructions.

lang:en score:60 filesize: 322.26 K page_count: 2 document date: 2017-02-13