Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ToysBuggy 3007-2

ToysBuggy Cogo Army Action Block Set 3007-2 Instruction Manual

Model: 3007-2 / LBS009

Product Overview

The ToysBuggy Cogo Army Action Block Set 3007-2 is a 94-piece construction toy designed to encourage creative thinking and imaginative play. This set allows children to build various army-themed models, providing hours of engagement. It is made from high-quality, durable, and non-toxic ABS plastic material, ensuring safety during play.



Figure 1: Packaging for the Cogo Army Action Block Set 3007-2. The box illustrates a completed block model of a military boat, highlighting the set's theme and components. Key details like the brand name "COGO" and model number "3007-2" are visible, along with a "WARNING: CHOKING HAZARD" notice for small parts, not suitable for children under 3 years.

Safety Information

- **Choking Hazard:** This set contains small parts. Not suitable for children under 3 years of age. Adult supervision is recommended for younger children.
- **Material Safety:** The blocks are made from non-toxic ABS plastic. Ensure children do not ingest any parts.
- **Assembly:** Follow assembly instructions carefully to prevent injury.
- **Storage:** Store all pieces in a safe place away from very young children when not in use.

Setup and Assembly

This block set includes 94 pieces designed for building various models. Refer to the included pictorial instructions for detailed step-by-step assembly guides for each model. The primary model depicted on the packaging is an army action

boat.

1. **Unpack Components:** Carefully open the product packaging and remove all block pieces. Verify that all 94 pieces are present.
2. **Review Instructions:** Consult the assembly booklet provided within the box. Identify the model you wish to build first.
3. **Sort Pieces:** For easier assembly, sort the blocks by color, size, or type as indicated in the instructions.
4. **Follow Steps:** Begin assembling the model by following the numbered steps in the instruction booklet. Ensure each block is securely connected to the next.
5. **Verify Connections:** After each major step, gently test the connections to ensure the structure is stable.

The set allows for the creation of 3 different models from one pack. Experiment with different configurations once familiar with the basic building techniques.

Operating and Play

Once assembled, the Cogo Army Action Block Set models are ready for imaginative play. The models are designed for creative scenarios and interaction.

- **Creative Play:** Encourage children to use the assembled models in various imaginative play scenarios, fostering social skills and creativity.
- **Reconfiguration:** The blocks can be disassembled and reassembled into different models or custom creations. Refer to the instruction booklet for alternative model designs.
- **Interaction:** The models are designed to be handled and played with. Avoid excessive force to prevent damage to the blocks or connections.

Maintenance and Care

Proper care will ensure the longevity of your Cogo Army Action Block Set.

- **Cleaning:** To clean the blocks, wipe them with a damp cloth and mild soap. Rinse thoroughly with clean water and allow them to air dry completely before storing. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store all block pieces in a dry, cool place, away from direct sunlight and extreme temperatures. Keep them in the original box or a designated storage container to prevent loss.
- **Inspection:** Periodically inspect all pieces for any signs of wear or damage. Discard any broken or cracked pieces to prevent potential hazards.

Troubleshooting

If you encounter any issues with your Cogo Army Action Block Set, consider the following:

- **Missing Pieces:** Double-check the packaging and play area. If a piece is genuinely missing, contact the manufacturer or retailer.
- **Difficulty Connecting Blocks:** Ensure blocks are aligned correctly. Apply gentle, even pressure. Avoid forcing pieces together, as this can cause damage.
- **Model Instability:** Review the assembly steps in the instruction booklet. Ensure all connections are secure and that pieces are placed in the correct orientation.
- **Damaged Pieces:** If any pieces are damaged, discontinue use of those specific pieces to maintain safety.

Specifications

Brand	ToysBuggy
Model Number	3007-2 (Item Part Number: LBS009)
Number of Pieces	94
Material Type	ABS Plastic
Color	Multicolor
Educational Objective	Creative Thinking
Recommended Age	12 months and up (*Note: Choking hazard warning for under 3 years applies due to small parts.*)
Batteries Included	No
Manufacturer	ToysBuggy
Date First Available	2 May 2017

Warranty and Support

For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or contact ToysBuggy directly through their official channels. Specific warranty details are typically provided with the product packaging or on the manufacturer's website.

For further assistance, please retain your proof of purchase and product model number (3007-2 / LBS009).

© 2023 ToysBuggy. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0713WT4ZS

More documents and user manuals: **https://manuals.plus/**