

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RCECAOSHAN](#) /

› [RCECAOSHAN Replacement COMFORT-AIRE Air Conditioner Remote Control User Manual](#)

RCECAOSHAN 6711A20128L, 6711A20128K, 6711A20128V

User Manual for RCECAOSHAN Replacement COMFORT-AIRE Air Conditioner Remote Control

Models: 6711A20128L, 6711A20128K, 6711A20128V

1. INTRODUCTION

This manual provides comprehensive instructions for the RCECAOSHAN replacement remote control, designed for various COMFORT-AIRE air conditioner models. It covers setup, operation, and troubleshooting to ensure optimal use of your air conditioning unit.

This remote is a direct replacement for original COMFORT-AIRE remote control models 6711A20128L, 6711A20128K, and 6711A20128V.

2. PRODUCT OVERVIEW

The RCECAOSHAN replacement remote control features a clear LCD display and ergonomically designed buttons for easy operation of your COMFORT-AIRE air conditioner.






Figure 1: Front view of the remote control with main display and buttons.

Key Features:

- Clear LCD display for temperature and mode settings.
- Dedicated buttons for power, mode, fan speed, and temperature adjustment.
- Hidden panel for advanced functions such as Plasma, Auto Clean, and Timer settings.
- Supports both Celsius and Fahrenheit temperature display.



Figure 2: Remote control with the advanced function panel visible.



Figure 3: Detailed view of advanced function buttons.

3. SETUP: BATTERY INSTALLATION

The remote control requires two AAA batteries (not included). Follow these steps to install them:


1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

- Slide the battery compartment cover back into place until it clicks securely.

Important: Ensure correct battery polarity. Remove batteries if the remote will not be used for an extended period to prevent leakage.

4. OPERATING INSTRUCTIONS

4.1 Basic Functions

- Power On/Off:** Press the **Power** button (usually marked with  or a power symbol) to turn the air conditioner on or off.
- Temperature Adjustment:** Use the **Up (▲)** and **Down (▼)** arrow buttons to increase or decrease the desired temperature.
- Mode Selection:** Press the **Mode** button (often depicted with a snowflake, water drop, fan, or sun icon) to cycle through modes like Cool, Dry, Fan, Heat, and Auto.
- Fan Speed:** Press the **Fan** button (often depicted with a fan icon) to adjust the fan speed (e.g., Low, Medium, High, Auto).

4.2 Advanced Functions (Under Sliding Panel)

Slide down the front panel of the remote to access additional functions:

- Timer ON/OFF:** Use the **ON- -OFF** buttons to set a timer for the unit to turn on or off automatically. Refer to your air conditioner's main manual for specific timer programming details.
- SET:** This button is typically used to confirm timer settings or other programmable features.
- AUTO CLEAN:** Activates the self-cleaning function of the indoor unit, if available.
- PLASMA:** Engages the Plasma or air purification function, if your AC unit supports it.
- RESET 2ndF:** Used for resetting certain settings or accessing secondary functions. Consult your AC unit's manual for specific applications.

4.3 Temperature Display (Celsius/Fahrenheit)

This remote control supports displaying temperature in both Celsius and Fahrenheit. The method to switch between these units may vary:

- Some models may have a dedicated button (e.g., "C/F" or "Temp Unit").
- Others may require pressing and holding the "Mode" or "Temp Up/Down" buttons simultaneously for a few seconds.
- Refer to your specific air conditioner model's manual or experiment with button combinations if a dedicated switch is not apparent.



Figure 4: Remote control highlighting Celsius and Fahrenheit display capability.

5. COMPATIBLE COMFORT-AIRE AIR CONDITIONER MODELS

This replacement remote control is compatible with the following COMFORT-AIRE air conditioner models, replacing original remote models 6711A20128L, 6711A20128K, and 6711A20128V:

- A2-H183GA0
- ASNH2435GA0
- B-DMH09SB
- B-DMH09SB-0
- B-DMH12SB
- B-DMH12SB-0

- B-DMH18SB-1
- B-DMH24SB
- DMC24DB-1
- DMH09SB-0
- DMH12SB-0
- DMH18DB-1
- DMH18SB-1
- DMH24DB-1
- DMH24SB-1
- DMH36TB-1
- A2NC123GHA0
- B-DMC09SB
- B-DMC09SB-0
- B-DMC12SB
- B-DMC12SB-0
- B-DMC18SB
- B-DMC18SB-1
- B-DMC24DB-1
- B-DMC24SB
- B-MMC12FA-1
- DMC09SB-0
- DMC12SB-0
- DMC18SB-1
- DMC24DB-1
- DMC-24SB-1
- DMC36TB-1
- MMC12FA-1
- B-VMC09SB
- B-VMC12SB
- B-VMC18SB
- B-VMC24SB
- B-VMC30SB

If your specific model is not listed, please compare your original remote with the images provided or contact support for compatibility verification.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote not responding / AC not turning on.	<ul style="list-style-type: none"> ◦ Dead or incorrectly installed batteries. ◦ Obstruction between remote and AC unit. ◦ Remote not compatible with AC unit. 	<ul style="list-style-type: none"> ◦ Replace batteries with new AAA alkaline batteries, ensuring correct polarity. ◦ Ensure a clear line of sight to the AC unit's receiver. ◦ Verify your AC model is listed in the "Compatible Models" section.
Display is dim or blank.	<ul style="list-style-type: none"> ◦ Low battery power. 	<ul style="list-style-type: none"> ◦ Replace batteries.
AC unit responds intermittently.	<ul style="list-style-type: none"> ◦ Weak batteries. ◦ Interference from other electronic devices. 	<ul style="list-style-type: none"> ◦ Replace batteries. ◦ Minimize interference by moving other devices or ensuring direct line of sight.

7. SPECIFICATIONS

- **Brand:** RCECAOSHAN
- **Model Numbers:** 6711A20128L, 6711A20128K, 6711A20128V
- **Compatible Devices:** COMFORT-AIRE Air Conditioners
- **Power Source:** 2 x AAA Batteries (not included)
- **Item Weight:** Approximately 2.64 ounces (75 grams)
- **Special Feature:** Ergonomic design, Celsius/Fahrenheit display
- **Manufacturer:** Home Appliances Inc Of ShenZhen

8. SUPPORT AND CONTACT INFORMATION

For any questions regarding compatibility, operation, or troubleshooting not covered in this manual, please contact the seller or manufacturer directly.

We are professional in remote control for AC, TV, DVD, projector, and other devices. Your satisfaction is our priority. Please refer to your purchase documentation for specific contact details or visit the product page on the retailer's website.