

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Amazon Basics](#) /
- › [Amazon Basics Zero Gravity Folding Reclining Lounge Chair User Manual](#)

Amazon Basics LF60040

Amazon Basics Zero Gravity Folding Reclining Lounge Chair

Model: LF60040

1. PRODUCT OVERVIEW

The Amazon Basics Zero Gravity Folding Reclining Lounge Chair is designed for outdoor relaxation, offering a comfortable, weightless feel. This chair features a durable powder-coated steel frame and weather-resistant Textilene fabric, making it suitable for various outdoor environments.

Key features include:

- Adjustable zero-gravity reclining mechanism for optimal comfort.
- Padded headrest pillow for enhanced support.
- Contoured armrests for ergonomic support.
- Double-bungee support system for secure fabric attachment.
- Lightweight and foldable design for easy storage and portability.



Image: The Amazon Basics Zero Gravity Folding Reclining Lounge Chair in Beige, showcasing its design and padded headrest.

2. SAFETY INFORMATION

WARNING:

It is a safety mechanism not to have the chair fasten tight because when the user stands up without loosening the lock, the legs of the chair might fold automatically, and cause the user to collapse. Serious injury may happen. Always ensure the chair is stable and locked in position before use. Exercise caution when adjusting the reclining position.

- Do not exceed the maximum weight capacity of 300 pounds (136 kg).
- Keep hands and fingers clear of moving parts during adjustment to prevent pinching.

- Ensure the chair is placed on a stable, level surface to prevent tipping.
- Supervise children around the chair.

3. SETUP AND ASSEMBLY

This Amazon Basics Zero Gravity Folding Reclining Lounge Chair requires no assembly. It arrives pre-assembled and ready for immediate use. Simply unfold the chair to set it up.



Image: Diagram showing the dimensions of the chair in both open and folded positions. Open dimensions are approximately 25.6 inches wide, 35.4 inches deep, and 43.3 inches high. Folded dimensions are approximately 25.6 inches wide, 33.5 inches high, and 6.5 inches deep.

4. OPERATING INSTRUCTIONS

The chair features an adjustable reclining mechanism and a customizable headrest pillow for personalized comfort.

4.1 Unfolding the Chair

1. Grasp the chair frame and gently pull the sides apart until the chair fully extends.
2. Ensure all legs are firmly on the ground and the chair is stable before sitting.

4.2 Adjusting the Recline Position

1. Sit comfortably in the chair.
2. To recline, gently push back with your body weight while holding the armrests. The chair will smoothly transition to a reclined position.
3. To lock the desired position, locate the recline adjustment knobs on the underside of each armrest. Turn the knobs clockwise to tighten and secure the chair in place.
4. To return to an upright position, loosen the recline adjustment knobs by turning them counter-clockwise. Lean forward, and the chair will return to an upright position. Retighten the knobs to lock.

Chair Usage Instructions




Image: Visual guide demonstrating how to sit, recline, and stand from the zero gravity chair. It shows a person sitting upright, then fully reclined, and finally standing up from the chair.

4.3 Adjusting the Headrest Pillow

The padded headrest pillow is customizable and can be slid up or down the back of the chair to achieve your preferred head and neck support.

Adjustable Zero Gravity Folding Recliner



Image: Detailed view of the chair's features, including the weather-resistant Textilene fabric, customizable removable headrest pillow, recline adjustment knob, and double bungee support system.

5. MAINTENANCE

To ensure the longevity and appearance of your lounge chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, especially during inclement weather or off-season, fold the chair flat and store it in a dry, protected area to prevent damage from prolonged exposure to elements.
- **Inspection:** Periodically check all bolts, screws, and bungee cords to ensure they are tight and secure. Replace any worn or damaged parts immediately.

Durable Metal Frame

Resilient 20D foam pillow
for comfort



Heavy-duty frame with
strong pull cords



Weather-resistant, breathable
fabric for comfort




Image: Close-up views highlighting the resilient foam pillow, heavy-duty frame with strong pull cords, and the weather-resistant, breathable Textilene fabric texture.

6. TROUBLESHOOTING

If you encounter any issues with your lounge chair, consider the following:

- **Chair not reclining smoothly:** Ensure the recline adjustment knobs are fully loosened. Check for any obstructions in the reclining mechanism.
- **Chair feels unstable:** Verify that the chair is fully unfolded and placed on a flat, stable surface. Inspect the frame and bungee cords for any damage or looseness.
- **Fabric appears dirty or stained:** Refer to the cleaning instructions in the Maintenance section.

For issues not resolved by these steps, please contact customer support.

7. SPECIFICATIONS

Brand	Amazon Basics
Model Name	LF60040

Color	Beige
Material	Carbon Steel (Frame), Textilene (Fabric), Polyester (Fill)
Product Dimensions (Open)	35.43"D x 25.59"W x 43.31"H (90cm D x 65cm W x 110cm H)
Item Weight	17.59 pounds (7.98 kg)
Maximum Weight Capacity	300 pounds (136 kg)
Indoor/Outdoor Usage	Outdoor
Special Features	Adjustable, Lightweight, Foldable
UPC	841710177053

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the Amazon Basics official website or contact Amazon customer service directly. Keep your purchase receipt for any warranty claims.

Online Support: [Amazon Customer Service](#)