

[Manuals.plus](#) /

› [SLLEA](#) /

› SLLEA AC Adapter Instruction Manual for Sharper Image SI585, SI586, S1585, S1586, SM917 Soother CD

SLLEA AC Adapter

SLLEA AC Adapter Instruction Manual

FOR SHARPER IMAGE SI585, SI586, S1585, S1586, SM917 SOOTHER CD

Brand: SLLEA | Model: AC Adapter

1. Introduction

This instruction manual provides essential information for the safe and effective use of your SLLEA AC Adapter. This adapter is designed to provide reliable power to compatible Sharper Image devices, including models SI585, SI586, S1585, S1586, and SM917 Soother CD players. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: SLLEA AC Adapter (Side View)

2. Setup

1. **Unpack the Adapter:** Carefully remove the AC adapter from its packaging. Inspect it for any visible damage.
2. **Verify Device Compatibility:** Before connecting, ensure that your device is one of the compatible Sharper Image models (SI585, SI586, S1585, S1586, SM917). Check your device's power input specifications to confirm it matches the adapter's output requirements.
3. **Connect to Device:** Insert the adapter's output connector firmly into the power input port of your Sharper Image device.
4. **Connect to Power Outlet:** Plug the adapter's 2-pin plug into a standard wall power outlet (100-240VAC, 50/60Hz). Ensure the outlet is easily accessible.



Figure 2: SLLEA AC Adapter (Top View with Plug)

3. Operating Instructions

The SLLEA AC Adapter operates on a simple plug-and-play principle. Once properly connected to your device and a power outlet, it will automatically supply power. The adapter is designed for worldwide use, accepting input voltages from 100V to 240V AC at 50/60Hz, making it suitable for travel.

This adapter incorporates industry-standard safety features, including over-voltage protection and over-heat protection, to safeguard both the adapter and your connected device.

4. Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Do not expose the adapter to extreme temperatures, humidity, or physical shock. Avoid dropping the adapter or placing heavy objects on it.

5. Troubleshooting

- **Device Not Powering On:**
 - Ensure the adapter is securely plugged into both the device and the wall outlet.
 - Test the wall outlet with another device to confirm it is functional.
 - Verify that your device model is listed as compatible with this adapter.
- **Adapter Feels Warm:**
 - It is normal for the adapter to feel slightly warm during operation.
 - If it becomes excessively hot, disconnect it immediately and allow it to cool. Ensure it is not covered or in an enclosed space that restricts airflow.

6. Specifications

Brand	SLLEA
Model	AC Adapter
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	Designed to match specific requirements of compatible Sharper Image devices (SI585, SI586, S1585, S1586, SM917)
Main Power Connector Type	2-Pin US Plug
Special Feature	Travel-friendly design
ASIN	B0716LKF8T
UPC	761675721729

7. Warranty and Support

Your SLLEA AC Adapter comes with the following warranty:

- **30 Days Money Back Guarantee**
- **60 Days Free Exchange** (with paid return label)
- **360 Days Worry-Free Warranty**

For any questions, concerns, or warranty claims, please do not hesitate to contact the seller directly. We are committed to providing assistance and ensuring your satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question