

VARO WiFi WSD-602

VARO Vibe Portable WiFi + Bluetooth Multi-Room Speaker User Manual

Model: WSD-602

[Introduction](#) [What's in the Box](#) [Product Overview](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the VARO Vibe Portable WiFi + Bluetooth Multi-Room Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance. The VARO Vibe speaker offers versatile audio connectivity through both WiFi and Bluetooth, supporting multi-room audio experiences and integration with various streaming services.

2. WHAT'S IN THE BOX

Please verify that all items are present in your package:

- VARO Vibe Speaker
- Instruction Manual (this document)
- Quick Start Guide
- AUX Cable
- Wall Adaptor

3. PRODUCT OVERVIEW

The VARO Vibe speaker is designed for flexible audio playback, featuring both WiFi and Bluetooth connectivity. It allows for multi-room audio setups and supports various streaming platforms.

Key Features:

- **WiFi-Controlled:** Integrate speakers into your home WiFi network for extended streaming range and uninterrupted audio.

- **Bluetooth Connectivity:** Seamlessly switch to Bluetooth when WiFi is unavailable.
- **Multiple Input Options:** Direct plug-in options include AUX, USB, and SD Cards.
- **Rechargeable Battery:** Samsung-powered built-in rechargeable batteries provide portable playback.
- **Streaming Services:** Supports Apple AirPlay, Spotify Connect, iHeartRadio, TIDAL, TuneIn Radio, and Napster. Additional services like Apple Music, Pandora, SoundCloud, and YouTube are supported on iOS devices via AirPlay.
- **Intuitive App Control:** The VARO app allows pairing multiple speakers, adjusting individual volume levels, and customizing playlists.

Speaker Components:

Familiarize yourself with the speaker's physical layout and controls.



Image 3.1: Front view of the VARO Vibe Speaker, showcasing the speaker grille and VARO logo.



Image 3.2: The VARO Vibe Speaker positioned on a marble shelf, demonstrating its compact design.



Image 3.3: The VARO Vibe Speaker placed on a textured metal table, highlighting its portability.



Image 3.4: The VARO Vibe Speaker in a living room environment, suitable for various home placements.



Image 3.5: Side view of the VARO Vibe Speaker on a shelf, showing its depth and design.

4. SETUP

4.1 Powering On

1. Connect the provided Wall Adaptor to the speaker's power input and then to an electrical outlet.
2. Press and hold the Power button (location typically on the back or top panel) until the indicator light

illuminates.

3. The speaker is equipped with a built-in rechargeable battery for portable use. Ensure it is charged before extended use without AC power.

4.2 WiFi Connection (for Multi-Room and Streaming)

For WiFi functionality, you will need the VARO app, also known as 'Soundlogic WiFi Controller' on iOS devices.

1. Download the 'Soundlogic WiFi Controller' app from the Apple App Store on your iOS device.
2. Ensure your speaker is powered on and within range of your home's 2.4 GHz WiFi network.
3. Open the app and follow the on-screen instructions to connect the speaker to your home WiFi network. This typically involves connecting your phone to the speaker's temporary WiFi network first, then selecting your home network within the app.
4. The speaker may perform a firmware update during the initial setup. Allow this process to complete without interruption. If the app loses connection after an update, power cycle the speaker and restart the app.
5. Once connected, you can rename the speaker within the app for easy identification, especially in multi-speaker setups.

4.3 Bluetooth Connection

Use Bluetooth when a WiFi network is not available or preferred.

1. Press the Mode button on the speaker to switch to Bluetooth mode. An audible prompt or indicator light will confirm Bluetooth mode.
2. On your mobile device, navigate to Bluetooth settings and enable Bluetooth.
3. Search for available devices and select 'VARO Vibe' (or similar name) from the list.
4. Once paired, the speaker will confirm the connection, and you can begin playing audio from your device.

4.4 Direct Audio Connections

The VARO Vibe speaker supports direct audio input:

- **AUX Input:** Use the provided AUX cable to connect external audio sources (e.g., MP3 players, computers) to the speaker's AUX port.
- **USB Input:** Insert a USB drive containing audio files into the USB port.
- **SD Card Slot:** Insert an SD card with audio files into the SD card slot.

5. OPERATING INSTRUCTIONS

5.1 Multi-Room Audio (WiFi Only)

The VARO app allows you to connect and control up to 8 VARO speakers on the same WiFi network.

1. Ensure all VARO speakers are connected to the same home WiFi network via the VARO app.
2. Open the VARO app on your iOS device.
3. From the app interface, you can group speakers to play the same audio simultaneously for a cohesive multi-room experience.
4. Alternatively, you can select individual speakers to play different audio streams, allowing for personalized listening in various rooms.

5. Adjust volume levels for individual speakers or groups directly from the app.



Image 5.1: An illustration of multiple VARO speakers, demonstrating the potential for a multi-room audio system.

5.2 Streaming Music

The VARO Vibe speaker supports various streaming services when connected via WiFi:

- **Direct Integration:** Stream directly from Apple AirPlay, Spotify Connect, iHeartRadio, TIDAL, TuneIn Radio, and Napster.
- **AirPlay (iOS Devices):** For other services like Apple Music, Pandora, SoundCloud, and YouTube, use AirPlay from your iOS device to stream audio to the VARO Vibe speaker.

5.3 App Functionality

The VARO app provides comprehensive control over your speaker system:

- **Speaker Pairing:** Easily add and manage multiple VARO speakers.
- **Volume Control:** Independently adjust volume for each speaker or control grouped speakers.
- **Playlist Management:** Create and customize playlists from your preferred streaming services.
- **Source Selection:** Switch between WiFi, Bluetooth, AUX, USB, and SD card inputs.

6. MAINTENANCE

6.1 Cleaning

- Wipe the speaker's exterior with a soft, dry cloth.

- Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.
- Keep the speaker free from dust and debris, especially around ports and grilles.

6.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Recharge the battery periodically if stored for a long time to prevent deep discharge.

7. TROUBLESHOOTING

If you encounter issues with your VARO Vibe speaker, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker does not power on	Low battery or no power connection	Connect the speaker to the wall adaptor and ensure it is plugged into a working outlet. Allow time for charging if the battery is fully depleted.
Cannot connect to WiFi	Incorrect WiFi password, 5GHz network, or app issue	Ensure you are using the correct password. Verify your home network is 2.4 GHz. Restart the VARO app and the speaker, then try connecting again. Check for firmware updates.
Bluetooth pairing fails	Speaker not in pairing mode, device too far, or interference	Ensure the speaker is in Bluetooth pairing mode. Move your device closer to the speaker. Turn off other Bluetooth devices nearby.
No sound or distorted audio	Volume too low, incorrect source, or poor connection	Increase volume on both the speaker and your source device. Verify the correct input source (WiFi, Bluetooth, AUX) is selected. For WiFi, check network stability. For AUX, ensure the cable is fully inserted.
Multi-room audio not working	Speakers not on same network or app issue	Confirm all speakers are connected to the same 2.4 GHz WiFi network via the VARO app. Restart the app and re-group speakers.

If the problem persists, please refer to the Warranty & Support section for further assistance.

8. SPECIFICATIONS

Feature	Detail
Model Name	Vibe Speaker
Item Model Number	WSD-602
Speaker Type	Multi Room
Connectivity Technology	Auxiliary, Bluetooth, USB, Wi-Fi

Feature	Detail
Wireless Communication Technology	Bluetooth, Wi-Fi
Bluetooth Range	10 Meters
Power Source	AC, Battery
Speaker Maximum Output Power	5 Watts
Control Method	App
Compatible Devices	Smartphone, Tablet, Laptop
Product Dimensions	15"D x 9.5"W x 15"H
Item Weight	3 Pounds
Batteries	2 AAA batteries required (included)
Manufacturer	Skyline Brands Inc.

9. WARRANTY & SUPPORT

9.1 Limited Warranty

The VARO Vibe Portable WiFi + Bluetooth Multi-Room Speaker comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. This warranty typically covers manufacturing defects and malfunctions under normal use.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact VARO customer support. Contact information can usually be found on the VARO website or on the product packaging. Please have your model number (WSD-602) and proof of purchase ready when contacting support.