

## Motorola Moto C XT1754

# Motorola Moto C XT1754 Smartphone User Manual

Model: Moto C XT1754

## INTRODUCTION

This manual provides essential information for the safe and efficient use of your Motorola Moto C XT1754 smartphone. Please read this manual thoroughly before operating your device.

## SETUP

### 1. Package Contents

Verify that your package contains the following items:

- Motorola Moto C XT1754 Smartphone
- Battery
- Charger
- USB Cable
- Quick Start Guide (not included in this digital manual)

### 2. Inserting the SIM Card and Battery

1. Power off the device.
2. Carefully remove the back cover of the phone.
3. Insert the SIM card(s) into the designated slot(s). Ensure the gold contacts face downwards.
4. Insert the battery, aligning the contacts.
5. Replace the back cover, pressing firmly until it clicks into place.



Image: Front and side view of the Motorola Moto C XT1754, illustrating the phone's physical design relevant for accessing internal components.

### **3. Charging the Battery**

Before first use, fully charge the battery. Connect the USB cable to the phone's charging port and the other end to the power adapter. Plug the adapter into a wall outlet.



Image: Front view of the Motorola Moto C XT1754, showing the display and front camera. This image represents the device in an operational state after initial setup.

## OPERATING YOUR DEVICE

### 1. Power On/Off

To power on, press and hold the Power button until the screen lights up. To power off, press and hold the Power button, then select "Power off" from the options.



Image: Side view of the Motorola Moto C XT1754, highlighting the location of the power and volume buttons for device control.

## 2. Navigation

The Motorola Moto C XT1754 operates on Android 7.0 Nougat. Use the touchscreen for navigation. Common gestures include tapping, swiping, pinching, and spreading.

- **Home Button:** Returns to the home screen.
- **Back Button:** Returns to the previous screen.
- **Recent Apps Button:** Displays recently used applications.

### 3. Camera Functions

Your device features a 5 MP autofocus rear camera with LED flash and a 2 MP fixed-focus front camera with LED flash.

- Open the Camera app from the home screen or app drawer.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera toggle icon.
- Tap the flash icon to adjust flash settings (Auto, On, Off).



Image: Angled front view of the Motorola Moto C XT1754, showcasing the display and the front camera lens, which is used for selfies and video calls.

## 4. Connectivity

The Moto C XT1754 supports 4G mobile networks, Wi-Fi (802.11bgn), and Bluetooth 4.2.

- **Wi-Fi:** Go to *Settings > Wi-Fi* to connect to available networks.
- **Bluetooth:** Go to *Settings > Bluetooth* to pair with other Bluetooth devices.
- **Mobile Data:** Ensure your SIM card is active and mobile data is enabled in *Settings > Data usage*.

## MAINTENANCE

### 1. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials.

### 2. Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture or damage the battery.
- Use only approved chargers and cables.

### 3. Software Updates

Regularly check for software updates to ensure optimal performance and security. Go to *Settings > About phone > System updates*.

## TROUBLESHOOTING

Problem	Solution
Device does not power on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
Cannot connect to Wi-Fi	Check Wi-Fi settings, restart the router, or forget and reconnect to the network.
Apps are slow or unresponsive	Close background apps, clear app cache ( <i>Settings &gt; Apps &gt; [App Name] &gt; Storage &gt; Clear cache</i> ), or restart the device.
Poor call quality	Check network signal strength. Ensure nothing is blocking the microphone or speaker.

## SPECIFICATIONS

Feature	Detail
Model	Moto C XT1754
Operating System	Android 7.0 Nougat
Display	5.0-inch FWVGA (854 x 480 pixels) LCD

Feature	Detail
Processor	Mediatek Quad Core
RAM	1 GB
Internal Storage	16 GB
Rear Camera	5 MP Autofocus with LED Flash
Front Camera	2 MP Fixed-focus with LED Flash
Battery	2350 mAh Lithium Ion
Connectivity	4G, Wi-Fi (802.11bgn), Bluetooth 4.2
Dimensions	7.36 x 0.9 x 14.5 cm
Weight	154 g
Material	Plastic

## WARRANTY INFORMATION

Motorola products are covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Motorola support website. Keep your proof of purchase for warranty claims.

## SUPPORT AND CONTACT

For further assistance, technical support, or service inquiries, please visit the official Motorola support website or contact their customer service. You can find contact information on the Motorola website.

**Official Motorola Website:** [www.motorola.com](http://www.motorola.com)