Tivoli Audio M1BT-1652-JP

Tivoli Audio Model One BT Radio User Manual

Model: M1BT-1652-JP

Introduction

The Tivoli Audio Model One BT is a classic table radio that combines timeless design with high-fidelity audio and modern Bluetooth technology. This acclaimed masterpiece has been refined to deliver clear sound reproduction, precise reception, and user-friendly controls. Designed by audio legend Henry Kloss, this legendary radio now features the latest Bluetooth capabilities. Additionally, it includes a 3.5mm Aux input for wired connections, offering versatile audio playback options.

Image: The Tivoli Audio Model One BT radio, showcasing its classic design in a contemporary setting.

Safety Information

Please read all safety and operating instructions before using your Model One BT radio. Keep these instructions for future reference.

- **Water and Moisture:** Do not use this appliance near water.
- **Heat:** Position the radio away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- **Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.
- **Power Sources:** Connect the appliance only to a power supply of the type described in the operating instructions or as marked on the appliance.
- **Power-Cord Protection:** Protect the power cord from being walked on or pinched.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

Package Contents

Verify that all items listed below are included in your package:

- Tivoli Audio Model One BT Radio
- FM Antenna
- Power Cord
- Instruction Manual
- Warranty Card

Controls and Features

The Model One BT radio features a minimalist design with intuitive controls for ease of use. All primary operations are managed through just three knobs.

Image: Front panel of the Model One BT, highlighting the control knobs and speaker grille.

- **Source/Power Knob:** Selects between OFF, FM, AM, AUX, and Bluetooth modes.
- **Tuning Knob:** A 5:1 geared analog tuning dial allows for precise and simple fine-tuning of radio frequencies.
- **Volume Knob:** Adjusts the audio output level.
- **Tuning LED:** Illuminates to indicate optimal tuning for FM and AM stations.
- **3-inch Full-Range Driver:** A proprietary driver designed to deliver precise tonal balance and rich bass reproduction through a bass-reflex speaker system.
- **Advanced FM Reception:** Utilizes a gallium arsenide (GaAs) compound field-effect transistor for enhanced FM reception, even in challenging environments like reinforced concrete buildings.
- **Bluetooth Connectivity:** Seamlessly stream audio wirelessly from compatible devices.
- **AUX Input:** A 3.5mm auxiliary input for connecting external audio sources via a wired connection.

Setup

1. **Unpack the Radio:** Carefully remove the Model One BT radio and all accessories from its packaging.
2. **Connect the FM Antenna:** For optimal FM reception, connect the included external FM antenna to the FM antenna

jack on the rear of the radio. Extend the antenna fully for best results.

3. **Connect Power:** Insert the power cord into the power input on the back of the radio, then plug the other end into a wall outlet.
4. **Positioning:** Place the radio on a stable, flat surface. For best sound quality, avoid placing it in enclosed spaces that might impede sound projection.

Image: The Model One BT radio positioned on a wooden shelf, ready for use.

Operating Instructions

Power On/Off and Source Selection

1. To turn the radio on, rotate the Source/Power knob clockwise from the "OFF" position to select your desired source: "FM", "AM", "AUX", or "BT".
2. To turn the radio off, rotate the Source/Power knob counter-clockwise to the "OFF" position.

AM/FM Radio Operation

1. Select "FM" or "AM" using the Source/Power knob.
2. Rotate the Tuning knob to scan for radio stations.
3. The Tuning LED will illuminate brightly when you have tuned into the strongest signal for a station, indicating optimal reception.
4. Adjust the Volume knob to your preferred listening level.

Bluetooth Operation

1. Select "BT" using the Source/Power knob. The radio will enter pairing mode, and the Tuning LED may flash.
2. On your Bluetooth-enabled device (e.g., smartphone, tablet), enable Bluetooth and search for available devices.
3. Select "Tivoli Audio BT" from the list of devices.
4. Once paired, the Tuning LED on the radio will remain solid. You can now stream audio from your device to the Model One BT.
5. Adjust the volume using both your device's volume control and the radio's Volume knob.

AUX Input Operation

1. Connect an external audio source (e.g., MP3 player, CD player) to the 3.5mm AUX input jack on the back of the radio using a standard 3.5mm audio cable (not included).
2. Select "AUX" using the Source/Power knob.
3. Start playback on your external audio device.
4. Adjust the volume using both your external device's volume control and the radio's Volume knob.

Maintenance

- **Cleaning:** Always unplug the radio before cleaning. Use a soft, dry cloth to wipe the cabinet and controls. Do not use abrasive cleaners, waxes, or solvents.
- **Wood Finish:** The wood cabinet is a natural material. Minor variations in grain and color are normal. Avoid direct sunlight and extreme temperatures to prevent damage.
- **Antenna Care:** Handle the FM antenna gently. Do not bend or force it excessively.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not securely connected.	Ensure the power cord is firmly plugged into both the radio and the wall outlet.
Poor radio reception	Antenna not properly positioned or connected; weak signal.	Adjust the position of the FM antenna. For AM, rotate the radio itself for better reception. Ensure the antenna is fully extended.
Bluetooth not connecting	Radio not in BT mode; device not in pairing mode; device too far.	Ensure the Source/Power knob is set to "BT". Make sure Bluetooth is enabled on your device and it's in pairing mode. Move your device closer to the radio.
No sound from AUX input	Radio not in AUX mode; cable not connected; external device volume low.	Select "AUX" mode. Check the 3.5mm audio cable connection. Increase the volume on your external audio device.

Specifications

Feature	Detail
Brand	Tivoli Audio
Model Number	M1BT-1652-JP
Color	Classic Walnut/Beige
Compatible Device	Speaker
Connector Type	AUX, Bluetooth
Item Weight	600 grams
Power Source	AC Power (Power cord included)
Tuner Type	AM/FM Analog Tuner
Speaker Type	3-inch Full-Range, Bass-Reflex

Warranty and Support

Warranty: The Tivoli Audio Model One BT radio comes with a 1-year product warranty from the date of purchase. Please retain your proof of purchase for warranty claims.
Support: For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Tivoli Audio customer support. Refer to the warranty card or the official Tivoli Audio website for contact details specific to your region. You can find more information and support resources on the official Tivoli Audio website: www.tivoliaudio.com

© 2024 Tivoli Audio. All rights reserved.