

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Amcrest](#) /

› [Amcrest 960H 8CH Security System - Four 800+ TVL IP66 Bullet Cameras Instruction Manual](#)

Amcrest 4335043668

Amcrest 960H 8CH Security System Instruction Manual

Model: 4335043668

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Amcrest 960H 8-Channel 1TB DVR Security System. This system includes four 800+ TVL IP66 heavy-duty metal weatherproof bullet cameras, designed for reliable surveillance. The 960H standard offers high-quality widescreen video, providing a 34% larger image than D1 resolution. Please read this manual thoroughly before installation and use.

PACKAGE CONTENTS

Verify that all components are present in your package:

- 1x Amcrest 960H 8-Channel Digital Video Recorder (DVR) with pre-installed 1TB Hard Drive
- 4x 800+ TVL IP66 Heavy-Duty Metal Weatherproof Bullet Cameras
- 4x Camera Power/Video Cables
- 1x DVR Power Adapter
- 1x Mouse
- 1x Remote Control
- 1x Ethernet Cable
- Mounting Hardware for Cameras



Image: Complete package contents of the Amcrest 960H 8CH Security System.

SETUP

1. DVR Connection

Connect the DVR to a monitor using an HDMI or VGA cable. Connect the included mouse to a USB port on the DVR. For network access and remote viewing, connect an Ethernet cable from the DVR's LAN port to your router.



Image: Front view of the Amcrest 960H 8CH Digital Video Recorder (DVR).



2. Camera Installation and Connection

Mount the bullet cameras in desired locations, ensuring a clear field of view. The cameras are IP66 weatherproof, suitable for outdoor use. Connect each camera's power and video cable to the corresponding video input ports on the back of the DVR. Ensure secure connections for optimal video quality.



Image: Amcrest 800+ TVL IP66 Bullet Camera.

3. Power On and Initial Configuration

Connect the DVR power adapter to the DVR and then to a power outlet. The system will boot up. Follow the on-screen prompts to complete the initial setup, including setting a password, date/time, and network settings. For remote viewing, download the Amcrest View Pro app on your iOS or Android device and follow the in-app instructions to add your DVR.

OPERATING INSTRUCTIONS

Live View

After successful setup, the DVR will display the live feed from all connected cameras on your monitor. Use the mouse to navigate the on-screen menu for various options.

Recording

The system is configured for continuous recording by default. You can adjust recording settings (e.g., motion detection,

scheduled recording) through the DVR's main menu. The pre-installed 1TB hard drive provides approximately 6 days of continuous recording at the highest resolution.

Playback

Access recorded footage by selecting the 'Playback' option from the DVR menu. You can search by date, time, and event type (e.g., motion detection). Use the controls to play, pause, fast forward, or rewind recordings.

Remote Access

Utilize the Amcrest View Pro app on your iOS or Android device to view live feeds, play back recordings, and manage system settings remotely. Ensure your DVR is connected to the internet and configured for network access.

MAINTENANCE

Hard Drive Management

The DVR supports hard drives up to 4TB. When the hard drive is full, the system will typically overwrite the oldest recordings. Regularly back up important footage to an external storage device if needed. You can check the hard drive status and format it through the DVR's storage settings.

Camera Cleaning

Periodically inspect camera lenses for dirt, dust, or spiderwebs, which can obstruct the view and trigger false motion detection alerts. Gently clean the lenses with a soft, damp cloth. Avoid abrasive cleaners.

Firmware Updates

Check the Amcrest support website for available firmware updates for your DVR. Firmware updates can improve system performance, add new features, or address security vulnerabilities. Follow the provided instructions carefully when performing updates.

TROUBLESHOOTING

- **No Video Display:** Ensure the monitor is correctly connected to the DVR via HDMI or VGA. Verify the monitor is powered on and set to the correct input source. Check all camera connections to the DVR.
- **No Recording:** Confirm the hard drive is installed and recognized by the DVR. Check recording schedules and motion detection settings. Ensure the hard drive is not full or corrupted.
- **Remote Access Issues:** Verify the DVR is connected to the internet and has a stable network connection. Check network settings on the DVR and ensure port forwarding (if required by your network setup) is correctly configured. Ensure the Amcrest View Pro app is updated to the latest version.
- **Poor Image Quality:** Clean camera lenses. Adjust camera position and focus if applicable. Ensure sufficient lighting for night vision performance.

For further assistance, refer to the Amcrest support website or contact their technical support team.

SPECIFICATIONS

Feature	Detail
Brand	Amcrest

Model Number	4335043668
Connectivity Technology	HDMI, VGA, Ethernet
Number of Channels	8
Memory Storage Capacity	1000 GB (1 TB) pre-installed, expandable up to 4 TB
Camera Resolution	800+ TVL
Camera Weatherproof Rating	IP66
Power Source	Corded Electric
Compatible Devices	Cameras, Smartphones (iOS, Android)
Low Light Technology	Night Vision
Video Input	BNC (for cameras), HDMI, VGA (for monitor output)
Item Weight	13.52 pounds (system)
ASIN	B07193PDB9
UPC	851032007518

WARRANTY AND SUPPORT

This product is a Certified Refurbished item, tested and certified to look and work like new. The refurbishment process includes functionality testing, basic cleaning, inspection, and repackaging. For specific warranty details and duration, please refer to the documentation provided with your purchase or contact the seller directly. Amcrest provides technical support for their products; visit the official Amcrest website for support resources and contact information.

