#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > Sharp /
- > Sharp XL-BH250 Micro Shelf Executive Speaker System User Manual

#### Sharp XL-BH250

# Sharp XL-BH250 Micro Shelf Executive Speaker System User Manual

Model: XL-BH250

## 1. Introduction

Thank you for purchasing the Sharp XL-BH250 Micro Shelf Executive Speaker System. This system is designed to provide high-quality audio playback from various sources, including CDs, AM/FM radio, Bluetooth-enabled devices, USB drives, and external audio players. Please read this manual thoroughly before operating the unit to ensure proper use and to maximize your listening experience.

Key features of your new system include:

- Digital AM/FM tuner with 40 programmable presets for easy access to your favorite stations.
- Compatibility with CD-RW, CD-R, WMA, and MP3 formats for versatile music playback.
- Bluetooth streaming capability, allowing wireless connection with Apple and Android devices.
- · Convenient headphone output for private listening.
- Remote control for effortless operation from a distance.
- Multiple connectivity options including USB and optical input for external devices, and NFC touchpoint for quick Bluetooth pairing.

# 2. WHAT'S IN THE BOX

Upon opening the package, please ensure all the following components are present:

- Sharp XL-BH250 Micro Shelf Executive Speaker System (Main Unit)
- Two (2) Speaker Units
- Remote Control
- Power Cord
- User Manual (this document)



Figure 2.1: Overview of the Sharp XL-BH250 system, showing the central control unit and the two separate speaker units.

# 3. SETUP

## 3.1 Placement

Place the main unit and speakers on a stable, flat surface. Ensure there is adequate ventilation around the unit to prevent overheating. Avoid placing the system near heat sources, direct sunlight, or areas with high humidity.

# 3.2 Connecting the Speakers

Connect the speaker wires from the main unit to the corresponding terminals on the back of each speaker. Ensure correct polarity (red to red, black to black) for optimal sound quality.

#### 3.3 Power Connection

After connecting the speakers, plug the power cord into the AC inlet on the back of the main unit, then plug the other end into a standard wall outlet (AC 120V, 60Hz).

# 3.4 Connecting External Devices

- USB Port: Insert a USB flash drive into the USB port on the front panel for MP3/WMA playback.
- Audio In: Connect external audio players (e.g., smartphones, tablets) to the AUDIO IN jack on the front panel using a 3.5mm audio cable (not included).
- Optical Input: For digital audio input from compatible devices, use the optical input on the rear of the unit (cable not included).



Figure 3.1: Front panel of the main unit, highlighting the USB, Audio In, and Headphone ports.

# 4. OPERATING INSTRUCTIONS

#### 4.1 Power On/Off

Press the POWER button on the front panel or the remote control to turn the unit on or off.

#### 4.2 Source Selection

Press the **FUNCTION** button on the front panel or the remote control repeatedly to cycle through available sources: CD, AM, FM, Bluetooth, USB, and AUDIO IN.

# 4.3 CD Playback

- 1. Press the **FUNCTION** button to select CD mode.
- 2. Press the OPEN/CLOSE button to open the CD tray.
- 3. Place up to five CDs on the trays with the label side facing up.
- 4. Press the OPEN/CLOSE button again to close the tray.
- 5. Playback will begin automatically. Use the PLAY/PAUSE, STOP, SKIP, and SEARCH buttons for control.

## 4.4 Radio Operation (AM/FM)

- 1. Press the FUNCTION button to select AM or FM mode.
- 2. Press the TUNING +/- buttons to manually tune to a station.
- 3. Press and hold **TUNING** +/- for automatic station search.
- 4. **To Store Presets:** Tune to the desired station, press**MEMORY**, then use **PRESET** +/- to select a preset number, and press **MEMORY** again to confirm.
- 5. To Recall Presets: Use the PRESET +/- buttons.

# 4.5 Bluetooth Operation

- 1. Press the FUNCTION button to select Bluetooth mode. The Bluetooth indicator will flash.
- 2. On your Bluetooth-enabled device, search for "SHARP XL-BH250" and select it to pair.
- 3. Once paired, the Bluetooth indicator will glow steadily. You can now stream audio from your device.
- 4. NFC Pairing: If your device supports NFC, simply tap it against the NFC touchpoint on the unit for quick pairing.

# 4.6 USB Playback

- 1. Insert a USB flash drive containing MP3/WMA files into the USB port.
- 2. Press the **FUNCTION** button to select USB mode.
- 3. Playback will start automatically. Use the playback controls **PLAY/PAUSE**, **STOP**, **SKIP**) as needed.

#### 4.7 Volume Control

Rotate the VOLUME knob on the front panel or use the VOLUME +/- buttons on the remote control to adjust the sound level.

#### 4.8 Headphone Use

Plug headphones into the PHONES jack on the front panel for private listening. The main speakers will automatically mute.

## 5. MAINTENANCE

# 5.1 Cleaning the Unit

Wipe the unit with a soft, dry cloth. For stubborn stains, dampen the cloth lightly with water. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

#### 5.2 CD Care

Handle CDs by their edges. Keep them clean and free of scratches. Store CDs in their cases when not in use to prevent dust and damage.

# 5.3 General Safety

- Do not block ventilation openings.
- Do not expose the unit to rain or moisture.
- Unplug the unit from the power outlet during lightning storms or when unused for long periods.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not securely plugged in.	Check power cord connection to the unit and wall outlet.
No sound	Volume is too low or muted; Speakers not connected properly.	Increase volume; Check speaker wire connections.
CD not playing	CD inserted incorrectly; CD is dirty or scratched; Incorrect function selected.	Insert CD correctly; Clean or replace CD; Select CD function.
Bluetooth not connecting	Device not in pairing mode; Unit too far from device; Interference.	Ensure unit is in Bluetooth pairing mode; Move device closer; Turn off other Bluetooth devices.
Poor radio reception	Antenna not extended or positioned correctly; Interference.	Adjust the FM wire antenna or reposition the unit for better AM reception.


# 7. SPECIFICATIONS

Feature	Detail
Model Number	XL-BH250
Product Dimensions (L x W x H)	6.9 x 12.4 x 9.5 inches
Item Weight	15.73 pounds
Connectivity Technology	Bluetooth, NFC, USB
Color	Black

Feature	Detail
Speaker Type	Stereo
CD Compatibility	CD-RW, CD-R, WMA, MP3
Tuner	Digital AM/FM with 40 presets
Manufacturer	Sharp
First Available Date	March 13, 2017

## 8. WARRANTY AND SUPPORT

For warranty information and technical support, please contact Sharp customer service. You can find more information and support resources by visiting the official Sharp store on Amazon:




Please retain your proof of purchase for any warranty claims.

© 2024 Sharp. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

#### Related Documents - XL-BH250





#### Sharp XL-B520D(BK) / XL-B720D(BK) Software Upgrade Manual

This manual provides instructions for upgrading the firmware on Sharp XL-B520D(BK) and XL-B720D(BK) audio systems. It covers checking for updates, preparing a USB drive, and the upgrade process.



#### Sharp XL-B514 Tokyo FM Hi-Fi Micro System User Manual

Comprehensive user manual for the Sharp XL-B514 Tokyo FM Hi-Fi Micro System, covering setup, operation, features, safety instructions, and troubleshooting.



## Sharp CD-BH20 Micro Component System Operation Manual

Comprehensive operation manual for the Sharp CD-BH20 Micro Component System, covering setup, features, troubleshooting, and specifications.

#### Documents - Sharp - XL-BH250



#### [pdf] User Manual Instructions Accessories

XL BH250 Operation Manual Draft 020317 GAK102328 The Sharper Image ENGLISH MODEL MICRO COMPONENT SYSTEM OPERATION MANUAL Micro Component System consisting of main unit and CP speaker system Accessories 30HDVH FRQ¿UP WKDW RQO WKH IROORZLQJ DFFHVVRULHV DUH LQFOXGHG Special Note 6XSSO RI WKLV SURGXFW GRHV QRW FROUFHQVH QRU LPSO DQ ULJKW WR GLVWULEXWH FRQWHQW FUHDWHG ZLWK LQ Please confirm Follow the onscreen instructions on your old new phones to pa 206795 fbclid lwAR0ns8971OKYdBlcwKKVrch ofCcsrSZse0Dhz4Ki6JVnquR LV3HwYn cdn4 sharperimage si manuals

MODEL XL-BH250 MICRO COMPONENT SYSTEM ENGLISH OPERATION MANUAL 7KDQN RXIRUSXUFKDVLQJWKLV6

53SURGXFW7RREWDLQWKHEHVWSHUIRUPDQFHIURPWKLVSURGXFWSOHDVHUHDGWKLVPDC FDUHIXOO ,WZLOOJXLGH RXLQRSHUDWLQJ RXU6 53SURGXFW **XL-BH250** Micro Component Syst consisting of **XL-BH250** main unit and CP-BH250 spea...

lang:en score:35 filesize: 1.01 M page\_count: 21 document date: 2017-03-02



## [pdf] User Manual Accessories

ManualsLib Makes it easy to find manuals online! Search through 700 000 online and instruction user service guides owners instal Provided By MANUALSLIB COM manualslib 3 Speaker Terminals 4 AC Power Cord Display 1 Disc Number Indicators 2 Folder Inc Title Artist 5 Album 6 MP3 7 FM Stereo Mode 8 Receiving 9 Sleep 10 Timer Play 11 Total 12 Tuning Bluetooth ® pairing indicator A1LV3fKJyhL images na ssl amazon I

MODEL **XL-BH250** MICRO COMPONENT SYSTEM ENGLISH OPERATION MANUAL 7KDQN RXIRUSXUFKDVLQJWKLV6

53SURGXFW7RREWDLQWKHEHVWSHUIRUPDQFHIURPWKLVSURGXFWSOHDVHUHDGWKLVPDC FDUHIXOO ,WZLOOJXLGH RXLQRSHUDWLQJ RXU6 53SURGXFW **XL-BH250** Micro Component Syst consisting of **XL-BH250** main unit and CP-BH250 spea...

lang:en score:33 filesize: 1.11 M page\_count: 21 document date: 2017-10-10



[pdf] User Manual Guide Accessories

XL BH250 SEC 20201119 EN sharp ca product |||

MODEL **XL-BH250** MICRO COMPONENT SYSTEM ENGLISH OPERATION MANUAL Thank you for purchasing this SHARP product. To obtain the best performance from this product, please read this manuacarefully. It will guide you in operating your SHARP product. **XL-BH250** Micro Component System consisti **XL-BH250**...

lang:en score:32 filesize: 4.17 M page\_count: 21 document date: 2020-11-19



[pdf] User Manual Guide Accessories

Sharper Image 208491 cdn4 sharperimage si manuals |||

MODEL **XL-BH250** MICRO COMPONENT SYSTEM ENGLISH OPERATION MANUAL Thank you for purchasing this SHARP product. To obtain the best performance from this product, please read this manuacarefully. It will guide you in operating your SHARP product. **XL-BH250** Micro Component System consisti **XL-BH250**...

lang:en score:27 filesize: 3.95 M page\_count: 21 document date: 2022-05-25



#### [pdf] Instructions

XL BH250 sharp ca  $\circ$  Si votre appareil ne prend pas en charge la technologie NFC ou si vous Le lecteur MP3 sera chargé hors de fonction USB Cependant SEC 20201119 FR product |||

MODLE **XL-BH250** MICRO CHANE STRO FRANAIS MODE D EMPLOI Nous vous remercions d avoir po votre choix sur ce produit SHARP. Pour une utilisation optimale, veuillez lire ce mode d emploi trs attentivement. Il vous guidera dans I utilisation de votre produit SHARP. Micro-chane stro **XL-BH250** com; de...

lang:fr score:25 filesize: 4.31 M page\_count: 23 document date: 2020-11-19



[pdf] User Manual Guide Accessories

XL BH250XL BH250 SEC 20201119 ENmylittlebigweb ca product EN |||

MODEL **XL-BH250** MICRO COMPONENT SYSTEM ENGLISH OPERATION MANUAL Thank you for purchasing this SHARP product. To obtain the best performance from this product, please read this manuacarefully. It will guide you in operating your SHARP product. **XL-BH250** Micro Component System consisti **XL-BH250**...

lang:en score:16 filesize: 4.17 M page\_count: 21 document date: 2020-11-19



## [pdf]

Francine Lahaie 91E7kp9Hz6S images na ssl amazon I |||

MODLE **XL-BH250** SYSTME D ENTRANEMENT DE MICRO FRANAIS MANUEL DE L OPRATION Merci avoir achet ce produit SHARP. Pour obtenir le meilleur rendement de ce produit, veuillez lire attentivemen manuel. Il vous guidera dans I exploitation de votre produit SHARP. Le systme de microcomposants XL-B lang:fr score:14 filesize: 886.55 K page\_count: 21 document date: 2019-12-09