

## Accessory USA AC Adapter for SX-KN920 SX-KN720

# Accessory USA AC Adapter User Manual

Model: AC Adapter for Panasonic Technics SX-KN920, SX-KN720 Keyboards

Brand: Accessory USA

## 1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Retain this manual for future reference.

- **Certification:** This product is CE, FCC, and RoHS certified, ensuring compliance with safety and environmental standards.
- **Protection Features:** Equipped with Over Voltage Output Protection (OVP), Over Current Output Protection (OCP), and Short Circuit Output Protection (SCP) to safeguard your devices.
- **Compatibility:** Ensure the adapter's specifications match your device's power requirements before connection. Refer to your device's manual for power input details.
- **Environment:** Use the adapter in a dry, well-ventilated area. Avoid exposure to moisture, extreme temperatures, or direct sunlight.
- **Handling:** Do not disassemble, modify, or drop the adapter. Do not use if the casing or cord is damaged.
- **Children:** Keep out of reach of children.

## 2. PRODUCT OVERVIEW

The Accessory USA AC Adapter is designed to provide reliable power to compatible Panasonic Technics keyboards, specifically models SX-KN920 and SX-KN720. This adapter converts standard AC wall power to the appropriate DC voltage and current required by your keyboard.



Figure 2.1: Accessory USA AC Adapter. This image displays the compact design of the AC adapter, including its power plug and cable, ready for connection to a power outlet and compatible device.

### 3. SETUP INSTRUCTIONS

---

1. **Verify Compatibility:** Before connecting, confirm that your Panasonic Technics keyboard model is either SX-KN920 or SX-KN720. Check the power input specifications on your keyboard to ensure they match the adapter's output.
2. **Connect to Keyboard:** Locate the DC power input jack on your Panasonic Technics keyboard. Carefully insert the adapter's output connector into this jack. Ensure a secure fit.
3. **Connect to Power Outlet:** Plug the AC adapter's main power connector into a standard wall power outlet. Ensure the outlet is easily accessible and in good condition.
4. **Power On:** Once connected, you may power on your keyboard using its dedicated power switch.

### 4. OPERATING INSTRUCTIONS

---

This AC adapter is designed for straightforward operation. Once properly connected as described in the "Setup Instructions" section:

- The adapter will supply continuous power to your connected Panasonic Technics keyboard.
- There are no user-adjustable settings on the adapter itself. Its function is to convert and deliver power.
- To discontinue power, simply unplug the adapter from the wall outlet. It is recommended to power off your keyboard before disconnecting the adapter.

### 5. MAINTENANCE

---

Proper maintenance ensures the longevity and safe operation of your AC adapter:

- **Cleaning:** Disconnect the adapter from both the wall outlet and the keyboard before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter's casing, cable, and connectors for any signs of damage, fraying, or loose connections. If damage is observed, discontinue use immediately.

## 6. TROUBLESHOOTING

If you encounter issues with your AC adapter, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Keyboard does not power on.	<ul style="list-style-type: none"> <li>Adapter not properly plugged into wall outlet.</li> <li>Adapter not properly connected to keyboard.</li> <li>Wall outlet is not functioning.</li> <li>Keyboard power switch is off.</li> <li>Adapter or keyboard is faulty.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure adapter is securely plugged into a live wall outlet.</li> <li>Verify the adapter's connector is fully inserted into the keyboard's power jack.</li> <li>Test the wall outlet with another device.</li> <li>Ensure the keyboard's power switch is in the "ON" position.</li> <li>If issues persist, contact support or consider replacing the adapter/keyboard.</li> </ul>
Adapter feels unusually hot.	<ul style="list-style-type: none"> <li>Overload or short circuit.</li> <li>Poor ventilation.</li> </ul>	<ul style="list-style-type: none"> <li>Immediately unplug the adapter from the wall and keyboard. Allow it to cool.</li> <li>Ensure the adapter is not covered and has adequate airflow.</li> <li>If overheating continues, discontinue use and contact support.</li> </ul>

## 7. SPECIFICATIONS

Feature	Detail
Brand	Accessory USA
Compatibility	Panasonic Technics SX-KN920, SX-KN720 Keyboards
Certifications	CE, FCC, RoHS
Protection Features	OVP, OCP, SCP
Power Source	Corded Electric
Main Power Connector Type	2 Pin
Mounting Type	Wall Mount
UPC	650234644008

## 8. WARRANTY AND SUPPORT

**Warranty Information:**

This product comes with a 30-day money-back guarantee, a 60-day free exchange policy (with paid return label), and a 365-day worry-free warranty. Please retain your proof of purchase for warranty claims.

**Customer Support:**

For technical assistance, warranty claims, or any questions regarding your Accessory USA AC Adapter, please contact the manufacturer, Accessory USA, through their official support channels. Refer to the packaging or the retailer's website for specific contact details.