

[Manuals.plus](#) /

› [RYGHT](#) /

› Ryght NERO Wireless Bluetooth In-Ear Earphones User Manual

RYGHT R482785

Ryght NERO Wireless Bluetooth In-Ear Earphones User Manual

Model: R482785

INTRODUCTION

The Ryght NERO Wireless Bluetooth In-Ear Earphones are designed for wireless audio playback and hands-free communication. Featuring Bluetooth 4.1 + APTX technology, an integrated remote control, and an ergonomic design, these earphones offer a convenient listening experience. This manual provides essential information for the proper use and maintenance of your device.

SAFETY INFORMATION

- Do not expose the earphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the earphones to strong impacts.
- Do not attempt to disassemble or modify the earphones. This will void the warranty.
- Clean the earphones with a soft, dry cloth. Do not use harsh chemicals.
- Prolonged listening at high volume levels can cause hearing damage. Adjust volume to a safe level.

PACKAGE CONTENTS

Please check that all items are present:

- Ryght NERO Wireless Bluetooth In-Ear Earphones
- USB Charging Cable
- Multiple ear tip sizes
- Protective bag
- User Manual

SETUP

1. Charging the Earphones

Before initial use, ensure your Ryght NERO earphones are fully charged for at least 5 hours. Subsequent charges typically take 80 minutes for up to 7 hours of playback.

1. Locate the charging port on the integrated remote control.
2. Connect the provided USB charging cable to the charging port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The indicator light will show charging status (refer to product packaging for specific light behavior).
5. Once fully charged, disconnect the charging cable.






Image: Ryght NERO earphones showing the integrated remote control, which houses the charging port and control buttons.

2. Bluetooth Pairing

Pair your earphones with your Bluetooth-enabled device (smartphone, tablet, etc.) to begin wireless audio streaming.

1. Ensure the earphones are charged and turned off.
2. Press and hold the multi-function button (usually the center button on the remote) until the indicator light flashes rapidly (e.g., red and blue alternately), indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "RYGHT NERO" (or similar name) from the list of found devices.
5. Once paired, the indicator light on the earphones will typically flash blue slowly or turn solid blue.
6. If prompted for a password, enter "0000".

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until the indicator light turns on (e.g., blue light).
- **Power Off:** Press and hold the multi-function button for approximately 5 seconds until the indicator light turns off (e.g., red light flashes then off).

Music Playback

Use the integrated remote control to manage your music.

- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Next Track:** Press and hold the "+" button.
- **Previous Track:** Press and hold the "-" button.

Call Management

The integrated hands-free kit allows you to make and receive calls.

- **Answer Call:** Press the multi-function button once when a call comes in.
- **End Call:** Press the multi-function button once during a call.

- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the multi-function button.



Image: A user wearing the Ryght NERO earphones, demonstrating their use during an activity.

MAINTENANCE

Cleaning

- Wipe the earphones and remote control with a soft, dry, lint-free cloth.
- For ear tips, gently remove them and clean with a mild soap solution if necessary, then rinse and dry completely before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

Storage

- When not in use, store the earphones in their protective bag to prevent damage and tangling.

- The magnetic earbuds help prevent tangling during storage.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.



Image: A hand holding the Ryght NERO earphones, demonstrating the magnetic earbuds feature for tangle-free storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earphones do not power on.	Low battery.	Charge the earphones for at least 80 minutes. Ensure initial charge was 5 hours.

Problem	Possible Cause	Solution
Cannot pair with device.	Earphones not in pairing mode; Bluetooth off on device; device too far.	Ensure earphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move device closer to earphones (within 10 meters). Forget previous pairings on your device and try again.
No sound or poor sound quality.	Volume too low; earphones not properly seated; poor Bluetooth connection.	Increase volume on both earphones and connected device. Adjust earphone position for a secure fit. Re-pair the earphones with your device.
Calls not working.	Earphones not connected; microphone blocked.	Ensure earphones are properly paired and connected. Check that the microphone on the remote control is not obstructed.

SPECIFICATIONS

Model Number	R482785
Brand	RYGHT
Connectivity Technology	Bluetooth 4.1 + APTX
Form Factor	In-Ear
Battery Life	Up to 7 hours
Charge Time	Approximately 80 minutes (5 hours for initial charge)
Control Method	Integrated Remote Control (Touch)
Weight	14 g
Material	Plastic
Color	White (Silver and White variant)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Ryght customer service. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0719R1Y5Y>

More documents and user manuals: **<https://manuals.plus/>**