

Manuals.plus /

› Magnussen /

› Magnussen Bellamy Rectangular Sofa Table T2491-73 User Manual

## Magnussen T2491-73

# Magnussen Bellamy Rectangular Sofa Table

MODEL T2491-73 USER MANUAL

## Introduction

Thank you for choosing the Magnussen Bellamy Rectangular Sofa Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Magnussen Bellamy Rectangular Sofa Table (Model T2491-73)

## Safety Information

---

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all bolts, screws, and connectors are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight recommendation of 50 pounds (22.7 kg) on the tabletop.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Avoid placing hot items directly on the table surface without protective coasters.
- This table is designed for indoor residential use only.

## Package Contents

---

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

1. Tabletop with pre-installed drawers (1)
2. Curved Trestle Legs (2)
3. Metal Stretcher Bar (1)
4. Assembly Hardware (bolts, nuts, washers, Allen wrench)

## Assembly Instructions

---

Assembly is required and can typically be completed by one person. All necessary tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent damage.
2. **Attach Legs to Tabletop:** Position one curved trestle leg against the underside of the tabletop, aligning the pre-drilled holes. Secure it using four bolts and washers. Repeat for the second leg.
3. **Install Metal Stretcher Bar:** Connect the metal stretcher bar between the two assembled legs. Secure each end with a nut onto the threaded rod. Ensure the bar is centered and tightened for stability.
4. **Final Tightening:** Once all components are loosely assembled, carefully stand the table upright. Systematically tighten all bolts and nuts using the provided Allen wrench until secure. Do not overtighten.



Figure 2: Product Dimensions (16"D x 50"W x 29"H)



Figure 3: Detail of Leg and Stretcher Bar Assembly

## Operating Instructions

---

The Bellamy Sofa Table features two spacious drawers for convenient storage. These drawers are designed to open partially to prevent accidental removal and spillage of contents. To open, gently pull the matte black hardware knob. To close, push the drawer back until it is flush with the table front.



Figure 4: Drawer Functionality

## Care and Maintenance

---

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub, as this can spread the liquid and damage the finish.
- **Heat and Moisture:** Protect the surface from direct heat and moisture using coasters and placemats.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Moving:** When moving the table, always lift it rather than dragging it to prevent damage to the legs and frame.

## Troubleshooting

---

- **Wobbling:** If the table wobbles, check that all assembly bolts and nuts are securely tightened. Ensure the table is on a level surface.
- **Drawers Sticking:** If drawers are difficult to open or close, ensure they are properly aligned within their glides. Check for any obstructions.
- **Scratches/Minor Damage:** For minor scratches, touch-up pens or furniture markers matching the wood finish may be used. Consult a furniture repair specialist for significant damage.

## Specifications

---

<b>Brand</b>	Magnussen
<b>Model Name</b>	Bellamy
<b>Model Number</b>	T2491-73
<b>Product Dimensions (D x W x H)</b>	16" x 50" x 29" (40.6 cm x 127 cm x 73.7 cm)
<b>Item Weight</b>	49 Pounds (22.2 kg)
<b>Maximum Weight Recommendation</b>	50 Pounds (22.7 kg)
<b>Frame Material</b>	Wood (Pine Solids, Engineered Wood Base)
<b>Top Material Type</b>	Pine Wood
<b>Number of Drawers</b>	2
<b>Assembly Required</b>	Yes
<b>Tools for Assembly Included</b>	Yes

## Warranty and Support

---

For warranty information and customer support, please refer to the product description on the store page where you purchased this item or contact Magnussen Home directly. Keep your purchase receipt as proof of purchase.