

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [INLAND](#) /

› [Inland ProHT Rainbow LED Backlit USB Wired Keyboard User Manual](#)

INLAND 70012

Inland ProHT Rainbow LED Backlit USB Wired Keyboard User Manual

Model: 70012

Brand: INLAND

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Inland ProHT Rainbow LED Backlit USB Wired Keyboard. Designed for gamers and typists, this mechanical keyboard features responsive blue switches, vibrant rainbow backlighting, and a durable, ergonomic design. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Inland ProHT 104 Keys Mechanical Keyboard with Blue Switches
- 1 x Keycap Puller (for cleaning and maintenance)
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

The Inland ProHT Mechanical Keyboard is engineered for precision and durability, offering a superior typing and gaming experience.

Key Features:

- Outemu Blue Switches:** Provide a tactile and audible "clicky" feedback, ideal for typing and gaming that requires precise key presses.
- Rainbow LED Backlighting:** Features 9 distinct backlight modes with adjustable speed and brightness levels to enhance your desktop aesthetics and visibility in low-light conditions.
- 100% Anti-Ghosting with N-Key Rollover:** Ensures every keypress is registered accurately, even during rapid, simultaneous key combinations, crucial for competitive gaming.
- Durable Construction:** Built with a robust design, including double injection ABS keycaps for long-lasting legends

and a spill-resistant design with 4 hydrophobic drainage holes.

- **Ergonomic Design:** Stair-up keycap layout, adjustable foldable kickstands, and non-slip rubber padding promote comfortable use and reduce hand fatigue during extended sessions.
- **Multimedia Function Keys:** 12 dedicated multimedia shortcuts for quick access to volume control, media playback, calculator, and email.
- **Win Lock Function:** Prevents accidental presses of the Windows key during gaming (Fn+Win).

Component Identification:



Figure 3.1: Front view of the Inland ProHT Rainbow LED Backlit USB Wired Keyboard. This image displays the full 104-key layout, including the numeric keypad, function row, and arrow keys, all illuminated with rainbow LED backighting. The brushed metal finish of the keyboard base is also visible.



Figure 3.2: Side profile of the keyboard, illustrating the ergonomic stair-up keycap design. This angle highlights the slight curvature and varying heights of the keycaps, which are designed to provide a more natural and comfortable typing posture.



Figure 3.3: Detailed close-up of an Outemu Blue mechanical switch. The image clearly shows the blue stem of the switch, which is characteristic of clicky, tactile switches, and the transparent housing that allows the LED backlight to shine through.

4. SETUP

Setting up your Inland ProHT keyboard is a straightforward process. No special drivers are typically required for basic functionality.

- 1. Unpack the Keyboard:** Carefully remove the keyboard and all accessories from its packaging.
- 2. Connect to Computer:** Locate an available USB port on your computer (PC, Mac) or gaming console (Xbox). Insert the USB connector of the keyboard firmly into the USB port.
- 3. System Recognition:** Your operating system should automatically detect and install the necessary drivers. This process may take a few moments. Once complete, the keyboard's backlighting will illuminate, indicating it is ready for use.
- 4. Adjust Ergonomics:** If desired, extend the foldable kickstands located on the underside of the keyboard to adjust the typing angle for improved comfort.

Your keyboard is now ready for use.

5. OPERATING INSTRUCTIONS

5.1 Backlight Control

The keyboard features dynamic rainbow LED backlighting with multiple modes and adjustable settings.

- Changing Backlight Modes:** Use the **Fn + INS** key combination to cycle through the 9 different backlight modes.
- Adjusting Brightness:** Press **Fn + ↑** to increase backlight brightness and **Fn + ↓** to decrease brightness. There are 3 levels of brightness.
- Adjusting Speed:** Press **Fn + ←** to decrease the speed of dynamic backlight effects and **Fn + →** to increase the speed. There are 3 levels of speed.

5.2 Multimedia Functions

Access various multimedia and system functions using the **Fn** key in combination with the F1-F12 keys.

Key Combination	Function
Fn + F1	Media Player
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Mute
Fn + F5	Stop
Fn + F6	Previous Track
Fn + F7	Play/Pause
Fn + F8	Next Track
Fn + F9	Email
Fn + F10	Web Browser
Fn + F11	My Computer
Fn + F12	Calculator

5.3 Win Lock Function

To prevent accidental presses of the Windows key during intense gaming sessions, you can disable it:

- **Enable/Disable Win Lock:** Press **Fn + Win** to toggle the Windows key on or off.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your keyboard.

- **General Cleaning:**

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.
- Use compressed air to remove dust and debris from between the keycaps.

- **Keycap Cleaning:**

- The keycaps are pluggable for easy cleaning. Use the included keycap puller to carefully remove individual keycaps.
- Clean the removed keycaps with a mild soap and water solution, then rinse thoroughly and allow them to dry completely before reattaching.
- Clean the exposed switches and keyboard plate with compressed air or a small brush.
- Align the keycap with the switch stem and press down gently until it clicks into place.

- **Spill Management:**

While the keyboard is designed to be spill-resistant with hydrophobic holes, immediate action is recommended in case of liquid spills:

1. Immediately disconnect the keyboard from your computer.
2. Invert the keyboard to allow liquid to drain out through the drainage holes.
3. Wipe any visible liquid from the surface with a dry cloth.
4. Allow the keyboard to air dry completely for at least 24 hours before reconnecting it. Do not use heat sources to dry.

7. TROUBLESHOOTING

If you encounter issues with your keyboard, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Keyboard is not responding.	<ul style="list-style-type: none"> ◦ Ensure the USB cable is securely connected to both the keyboard and the computer's USB port. ◦ Try connecting the keyboard to a different USB port. ◦ Restart your computer. ◦ Test the keyboard on another computer to rule out a system-specific issue.
Backlight is not working or is dim.	<ul style="list-style-type: none"> ◦ Ensure the keyboard is properly connected and receiving power. ◦ Adjust backlight brightness using Fn + ↑. ◦ Cycle through backlight modes using Fn + INS. ◦ If only some LEDs are off, it might indicate a hardware issue.
Certain keys are not responding.	<ul style="list-style-type: none"> ◦ Check for any debris or foreign objects stuck under the keycap. ◦ Carefully remove the keycap using the keycap puller and inspect the switch for damage. ◦ Clean the switch area with compressed air. ◦ If the issue persists, the switch may be faulty.
Windows key is disabled.	<ul style="list-style-type: none"> ◦ You may have accidentally activated the Win Lock function. Press Fn + Win to re-enable the Windows key.
Keyboard input is delayed or erratic.	<ul style="list-style-type: none"> ◦ Ensure your computer's USB drivers are up to date. ◦ Try connecting to a different USB port, preferably a direct port on the motherboard (for desktops) rather than a USB hub. ◦ Check for any background processes or software that might be consuming system resources.

8. SPECIFICATIONS

Feature	Detail
Model Number	70012

Feature	Detail
Brand	INLAND
Connectivity	USB Wired
Keyboard Type	Mechanical
Switch Type	Outemu Blue
Number of Keys	104 (Full-size)
Backlighting	Rainbow LED (9 modes, 3 brightness, 3 speed levels)
Anti-Ghosting	100% Anti-Ghosting with N-Key Rollover
Keycap Material	Double Injection ABS
Special Features	Ergonomic design, Backlit, Foldable kickstands, Spill-resistant (4 hydrophobic holes), Win Lock function, Multimedia keys
Compatible Devices	PC, Mac, Xbox (Windows 7/8/10/XP/VISTA/95/98/XP/2000/ME/VISTA, Mac OS)
Product Dimensions	17.58 x 1.5 x 5.52 inches (44.65 x 3.81 x 14.02 cm)
Item Weight	2.13 pounds (0.96 kg)
Manufacturer	Inland Products Inc
Country of Origin	China


9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Inland Products Inc. directly. Keep your purchase receipt as proof of purchase for any warranty claims.

While specific warranty terms are not detailed in this manual, most electronic products come with a limited manufacturer's warranty covering defects in materials and workmanship under normal use. Please refer to the product packaging or the manufacturer's official website for the most current warranty policy.

For further assistance, you may visit the [INLAND Store on Amazon](#) or contact their customer service.

 USER MANUAL	<p><u>Inland MK PRO V3 RGB Wireless Mechanical Keyboard - Time Calibration Guide</u> Instructions for recalibrating the time on the Inland MK PRO V3 RGB Wireless Mechanical Keyboard, including tool download information from Micro Center.</p>
 GAMING MK PRO 75% USER MANUAL	<p><u>Inland KB83 Gaming MK Pro 75% Wired Mechanical Keyboard User Manual</u> Comprehensive user manual for the Inland KB83 Gaming MK Pro 75% wired mechanical keyboard, detailing features, customization, multimedia functions, and troubleshooting.</p>
	<p><u>Inland MK PRO V2 Max Keyboard: Quantum Mechanical Kit Guide</u> Learn how to personalize your Inland MK PRO V2 Max RGB Wireless Tri-Mode Magnetic Keyboard using the Quantum Mechanical Kit web app. Features include key settings, lighting customization, macro recording, and sharing options.</p>
 USER MANUAL	<p><u>Inland MK PRO V2 Max HE Keyboard: Setup and Calibration Guide</u> Instructions for setting up and calibrating the Inland MK PRO V2 Max HE Gaming Keyboard, including driver installation and stroke calibration procedures.</p>
	<p><u>Inland ThunderSound PCI 5.1 Sound Card - Product Overview</u> Detailed product information for the Inland ThunderSound PCI 5.1 Sound Card, featuring 6-channel audio, Dolby Digital AC-3 support, and Microsoft WHQL certification.</p>
	<p><u>Inland 70119 2.4GHZ Wireless Keyboard and Mouse Combo Quick Setup Guide</u> Get your Inland 70119 2.4GHZ wireless keyboard and mouse combo up and running quickly with this easy-to-follow setup guide. Learn how to insert batteries and connect the USB receiver.</p>




[pdf] Guide

View Your Guide MyBaseGuide Comprehensive Guide to U S Military Bases News and Services Ft Hood

Guidecdn sanity io files 1sxbvyx9 production dddb67a577496a5242566a0738cb2ec3d21a8558 |||

MILITARY RELOCATION Welcome to Central Texas Home of Fort Hood General
Construction Civil Site Se ... 54-532-4444 Napa AutoCare..... 254-213-
6200 West Fort Hood Express Building **70012** Express..... 254-
519-1357 Pizza Hut.....

lang:en **score:16** filesize: 34.87 M page_count: 43 document date: 2025-04-08



[Billboard International Buyer's Guide 1977-78: A Comprehensive Music Industry Directory](#)

Explore the 1977-78 Billboard International Buyer's Guide, a definitive resource for the music, record, and tape industries. This guide lists companies, suppliers, services, and manufacturers worldwide, covering record companies, music publishers, sheet music jobbers, wholesalers, and more. It also provides valuable data on music sales trends and industry statistics from 1921-1976.

lang:en **score:15** filesize: 29.72 M page_count: 414 document date: 2019-03-13