

BANZAI 35543

BANZAI Plummet Falls Inflatable Water Park Instruction Manual

Model: 35543

1. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these instructions may result in serious injury or death.

- Adult supervision is required at all times.
- Recommended for children ages 5 to 12 years old.
- Maximum combined user weight: 120 lbs.
- Ensure the water park is placed on a level, soft surface, such as grass, free from sharp objects.
- Keep children away from the air blower during operation.
- Do not allow children to play near plastic bags to avoid danger of suffocation.
- Always secure the water park with anchor stakes to prevent movement during use.
- Ensure all water connections are secure to prevent leaks and maintain proper water flow.

2. PACKAGE CONTENTS

Your BANZAI Plummet Falls Inflatable Water Park package includes the following items:

- Inflatable Water Park structure (featuring waterslide, climbing wall, overhead sprinkler, and splash pool)
- Air Blower (with GFCI protection)
- Anchor Stakes (for securing the water park)
- Storage Bag
- Repair Patches (various colors)




Figure 2.1: Included accessories: air blower, storage bag, and repair kit.

Text Description: This image displays the essential components included with the water park: an orange air blower, a blue storage bag, and a small clear plastic bag containing multi-colored repair patches and thread. These items are crucial for the setup, maintenance, and storage of the inflatable water park.

3. SETUP INSTRUCTIONS

1. **Unfold the Water Park:** Lay the inflatable water park flat on a clean, level, and soft surface in your backyard. Ensure there are no sharp objects underneath or nearby.
2. **Position the Air Blower:** Place the air blower on a stable surface near the inflation tube of the water park. Ensure the blower's air intake is clear of obstructions.
3. **Connect the Inflation Tube:** Securely attach the water park's inflation tube to the air blower's outlet. Use the provided ties or straps to ensure a tight seal.
4. **Inflate the Water Park:** Plug the air blower into a grounded electrical outlet. Turn on the blower. The water park should inflate in less than 3 minutes. Ensure it is fully inflated and firm before proceeding.
5. **Secure with Anchor Stakes:** Once inflated, use the provided anchor stakes to secure the water park to the ground. Insert stakes through the designated loops around the base of the water park.

6. **Connect Water Hose:** Attach a standard garden hose to the water connection point on the water park. Ensure the connection is tight to prevent leaks.



Figure 3.1: Air blower connected to the water park's inflation tube.

Text Description: This image shows the orange air blower positioned on green grass, with its yellow inflation tube securely attached to the blue fabric of the inflatable water park. This demonstrates the initial step of inflating the structure.

An infographic with a blue background featuring a water ripple pattern. In the top left, there is a small inset photo of a person's legs standing on a blue inflatable slide. The main text 'INFLATES IN 3 MINUTES' is in large, bold, white letters. Below it, a smaller white text block says 'This waterslide set inflates quickly so your kids can start playing in no time.' To the right, a white circle contains the text 'HOW TO SET UP' in bold orange letters. Further right, an orange rounded rectangle contains a list of three steps: '1. Unfold', '2. Inflate', and '3. Banzai!' in white text. Decorative white and orange geometric shapes are scattered around the text.

Figure 3.2: The water park inflates rapidly, typically within 3 minutes.

Text Description: This image shows a partially inflated blue and orange water slide in a backyard, with text overlay emphasizing that it 'Inflates in 3 minutes'. This visually confirms the quick setup time.



Figure 3.3: Securing the water park with anchor stakes.

Text Description: This image shows a hand inserting a yellow plastic anchor stake through a red fabric loop at the base of the blue inflatable water park, demonstrating how to secure the structure to the ground.

Setup Video

Your browser does not support the video tag.

Video 3.1: Official Banzai video demonstrating the setup and features of the Plummet Falls Adventure Kids Inflatable Pool.

Text Description: This video provides a visual guide to setting up the Banzai Plummet Falls Inflatable Water Park, showing the inflation process, water connections, and various play features in action. It highlights the ease of assembly and the fun elements of the water park.

4. OPERATING INSTRUCTIONS

Once the water park is fully inflated and secured, and the water hose is connected, you can begin enjoying the features:

- **Waterslide:** Climb the integrated climbing wall to reach the top of the waterslide. The overhead sprinkler will keep the slide surface wet for a smooth descent into the splash pool.
- **Climbing Wall:** Utilize the sturdy handholds and footholds on the climbing wall to ascend to the slide platform.
- **Overhead Sprinkler:** Water from the connected hose flows through the overhead sprinkler, ensuring the slide remains slick and providing a refreshing spray.
- **Splash Pool:** The base of the water park features a spacious splash pool for landing after the slide and for general water play.



Figure 4.1: Key features of the Plummet Falls Water Park.

Text Description: This image provides an aerial view of the Banzai Plummet Falls Inflatable Water Park, with labels pointing out its main features: a climbing wall, a mesh safety wall at the top, an overhead sprinkler, a waterslide, and a splash pool at the bottom. This helps users identify each component.



Figure 4.2: Children enjoying the water park.

Text Description: This image captures several children playing on the Banzai Plummet Falls Inflatable Water Park in a backyard. One child is sliding down the main slide, while others are splashing and playing in the large pool area at the base. An adult is also visible, supervising the play.

5. MAINTENANCE AND STORAGE

- **Cleaning:** After each use, drain all water from the splash pool. Wipe down the entire water park with a clean cloth and mild soap solution. Rinse thoroughly and allow to air dry completely before storage to prevent mold and mildew.
- **Drying:** Ensure the water park is completely dry, both inside and out, before deflating and storing. This may take several hours in direct sunlight.
- **Deflation:** Turn off and unplug the air blower. The water park will deflate on its own. Gently press out any remaining air.
- **Folding:** Fold the deflated water park neatly to fit into the provided storage bag.
- **Storage:** Store the water park and all accessories in the storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.

- **Repairs:** Use the included repair patches for any small punctures or tears. Follow the instructions provided with the repair kit for proper application.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water park does not inflate fully.	Air blower not connected properly, power issue, or large tear.	Check blower connection and power. Inspect for large tears and use repair kit.
Water is not flowing from sprinkler/slide.	Hose not connected, water supply off, or kink in hose.	Ensure hose is securely attached and water supply is on. Check hose for kinks.
Water park moves during play.	Not properly anchored.	Ensure all anchor stakes are fully inserted into the ground through the designated loops.

7. SPECIFICATIONS

- **Brand:** BANZAI
- **Model Number:** 35543
- **Product Dimensions:** 173"L x 114"W x 96"H (14.4' L x 9.5' W x 8' H)
- **Material:** Plastic
- **Age Range (Description):** 48 months to 1200 months (4 to 100 years, but recommended for 5-12 years)
- **Maximum Weight Recommendation:** 120 Pounds
- **Assembly Time:** Approximately 1 Hour (initial setup)
- **Included Components:** Inflatable Water Park, Air Blower, Anchor Stakes, Storage Bag, Repair Patches
- **UPC:** 191124355432



Figure 7.1: Dimensions of the water park.

Text Description: This image displays the overall dimensions of the inflatable water park, indicating its length as 173 inches, width as 114 inches, and height as 96 inches. This provides a clear understanding of the product's size.

8. WARRANTY AND SUPPORT

Manufacturer Warranty Description: No warranty.

For any product inquiries or support, please refer to the contact information provided on the product packaging or the official BANZAI website.