

[Manuals.plus](#) /

› [APORO](#) /

› Aporo T2 Bluetooth Smart Voice Amplifier User Manual

APORO T2

APORO T2 Bluetooth Smart Voice Amplifier User Manual

Model: T2 | Brand: APORO

1. INTRODUCTION

Thank you for choosing the APORO T2 Bluetooth Smart Voice Amplifier. This compact and versatile device is designed to provide clear voice amplification, Bluetooth audio playback, FM radio, and TF card music playback. It is ideal for teachers, presenters, tour guides, and anyone needing to project their voice clearly in various settings. Please read this manual carefully before using the product to ensure proper operation and maintenance.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- 1 x APORO T2 Master Unit
- 1 x USB Data Cable
- 1 x Wired Headset Microphone
- 1 x Waistband Strap
- 1 x User Manual
- 1 x High-class Gift Box

Package Includes



T2



Gift box




Professional wired microphone



Waistband belt



USB Charger



T2 User manual

Figure 2.1: Package Contents of the APORO T2 Voice Amplifier.

This image displays all items included in the APORO T2 package: the main T2 unit, a gift box, a professional wired microphone, a waistband belt, a USB charger cable, and the T2 user manual.

3. PRODUCT OVERVIEW

The APORO T2 is designed for portability and ease of use. Its compact size and lightweight construction make it convenient to carry and operate.



Figure 3.1: APORO T2 Dimensions and Portability.

This image illustrates the compact dimensions of the APORO T2 amplifier, measuring approximately 4.1 inches in height, 3 inches in width, and 1.1 inches in thickness, with a weight of 0.28 lbs (127g), highlighting its portability.



Figure 3.2: APORO T2 Main Unit with Headset.

A front view of the APORO T2 voice amplifier, showing its display panel indicating "BLUE BT" (Bluetooth mode) and the connected wired headset microphone.

3.1 Controls and Ports

Familiarize yourself with the buttons, ports, and indicators on your APORO T2 unit:



Figure 3.3: APORO T2 Controls and Ports.

This diagram labels the various controls and ports on the APORO T2 amplifier: Previous button, Next button, Mode button, Mode Switch/Pause button, MIC input, On/Off Volume knob, Circulation/Loop/Record button, DC 5V charging port, and TF card slot.

- **On/Off Volume Knob:** Rotate to power on/off and adjust volume.
- **MIC Input:** 3.5mm port for connecting the wired headset microphone.
- **Mode Button:** Press to cycle through modes (Voice Amplification, Bluetooth, FM Radio, TF Card).
- **Previous Button:** Short press for previous track/station; long press for fast rewind.
- **Next Button:** Short press for next track/station; long press for fast forward.
- **Mode Switch/Pause Button:** Play/Pause in music modes; also functions as mode switch.
- **Circulation/Loop/Record Button:** Used for recording function and loop playback.
- **DC 5V Port:** Micro USB port for charging the device.

- **TF Card Slot:** Insert a TF (MicroSD) card for music playback or recording storage.

3.2 Removable Clip

The APORO T2 features a removable clip for easy attachment to a belt or waistband.



Figure 3.4: Attaching the Removable Clip.

This image shows a four-step process for attaching the removable clip to the APORO T2 unit, demonstrating how it slides and locks into place.

4. SETUP

4.1 Initial Charging

1. Before first use, fully charge the APORO T2 unit.
2. Connect the supplied USB data cable to the DC 5V port on the amplifier and the other end to a USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate. A full charge takes approximately 4.5 hours.
4. Once fully charged, disconnect the cable.

4.2 Connecting the Headset Microphone

1. Insert the 3.5mm plug of the wired headset microphone into the MIC input port on the APORO T2 unit.
2. Position the microphone approximately 1-2 cm from your mouth for optimal voice pickup.

4.3 Attaching the Waistband Clip

To wear the amplifier on your belt or waistband, attach the removable clip as shown in Figure 3.4. Slide the clip into the designated slot on the back of the amplifier until it clicks securely into place.

5. OPERATING INSTRUCTIONS



Figure 5.1: Key Features of APORO T2.

This infographic highlights the core functionalities of the APORO T2: Bluetooth 4.2 connectivity, TF card support, 8-10 hours of working time, FM radio capability, HD recording, and noise reduction technology.

5.1 Power On/Off and Volume Control

- To power on, rotate the On/Off Volume knob clockwise until you hear a click and the display illuminates.
- Continue rotating clockwise to increase the volume.
- To decrease volume, rotate counter-clockwise.
- To power off, rotate the knob counter-clockwise until you hear a click and the display turns off.

5.2 Voice Amplification Mode

1. Ensure the wired headset microphone is securely plugged into the MIC input.
2. Power on the device. It will typically default to voice amplification mode.
3. Adjust the volume knob to your desired amplification level.
4. Speak clearly into the microphone.

5.3 Bluetooth Mode

1. Power on the APORO T2.
2. Press the **Mode** button repeatedly until "BLUE" or "BT" appears on the display. The device is now in Bluetooth pairing mode.
3. On your mobile device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "APORO T2" from the list to pair. Once paired, the device will confirm connection.
5. You can now play audio from your connected device through the APORO T2. Use the Previous/Next buttons on the amplifier to control tracks, and the Mode Switch/Pause button for play/pause.

5.4 FM Radio Mode

1. Power on the APORO T2.
2. Press the **Mode** button repeatedly until "FM" appears on the display.
3. To auto-scan and save available FM stations, long press the **Mode Switch/Pause** button. The device will scan and store stations automatically.
4. Use the **Previous** and **Next** buttons to switch between saved FM stations.

5.5 TF Card Playback Mode

1. Insert a TF (MicroSD) card with audio files (e.g., MP3) into the TF card slot. Ensure it is inserted correctly until it clicks.
2. Power on the APORO T2. The device should automatically switch to TF card mode if a card is detected, or you can press the **Mode** button to select it.
3. Audio playback will begin automatically.
4. Use the **Previous** and **Next** buttons to navigate tracks. Press the **Mode Switch/Pause** button to play or pause.

5.6 Recording Function

The APORO T2 supports HD recording to a TF card.

1. Ensure a TF card is inserted into the slot.
2. In Voice Amplification mode, long press the **Circulation/Loop/Record** button to start recording. The display may indicate recording status.
3. To stop recording, long press the **Circulation/Loop/Record** button again. The recorded file will be saved on the TF card.

6. MAINTENANCE

6.1 Cleaning

- Wipe the surface of the amplifier with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the finish.
- Keep the device free from dust and moisture.

6.2 Battery Care

- The APORO T2 uses a high-quality Lithium battery (3.7V/1000mAh).
- To prolong battery life, avoid fully discharging the battery frequently.
- If the device will not be used for an extended period, charge it at least once every three months to maintain battery health.
- Operating time is approximately 8-10 hours in microphone mode and 6-8 hours in music mode on a full charge.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from amplifier.	Device is off; Volume is too low; Microphone not connected or faulty; Incorrect mode selected.	Ensure device is powered on and volume is up. Check microphone connection. Press Mode button to select correct mode.
Cannot pair Bluetooth.	APORO T2 not in pairing mode; Bluetooth on source device is off; Too far from source device.	Ensure APORO T2 is in Bluetooth mode ("BLUE" or "BT" on display). Turn on Bluetooth on your device. Keep devices within 10 meters.
Device not charging.	USB cable faulty; Power adapter faulty; Charging port damaged.	Try a different USB cable and power adapter. Ensure the charging port is clean and undamaged.
Poor FM radio reception.	Weak signal in current location.	Move to a location with better signal. Re-scan for stations.

8. SPECIFICATIONS

Feature	Specification
Output Power	10 Watts
Frequency Response	50Hz-12000KHz
Battery Specification	Lithium battery 3.7V/1000mAh
Charging Time	Approx. 4.5 hours
Working Temperature	-10°C to 45°C
Dimensions (L x W x H)	4.1 x 3 x 1.1 inches (10.4 x 7.6 x 2.8 cm)
Item Weight	0.28 lbs (127 g)
Connectivity	Bluetooth 4.2, USB

Feature	Specification
Audio Input	Wired Headset
Supported Media	TF Card (MicroSD), FM Radio

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

For further assistance, you may also visit the official APORO website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question