

[Manuals.plus](#) /

› [HARBOR BREEZE](#) /

› Harbor Breeze Mazon 44-in Brushed Nickel Flush Mount Indoor Ceiling Fan with Light Kit and Remote (3-Blade) User Manual

HARBOR BREEZE Mazon 00724

Harbor Breeze Mazon 44-in Brushed Nickel Flush Mount Indoor Ceiling Fan with Light Kit and Remote (3-Blade) User Manual

Model: Mazon 00724

Brand: HARBOR BREEZE

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Harbor Breeze Mazon 44-inch Brushed Nickel Flush Mount Indoor Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

SAFETY INFORMATION

- Always disconnect power at the main circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- Ensure the installation site can support the fan's weight.
- Do not operate the fan with damaged blades.
- Keep hands, clothing, and other objects clear of the fan blades when in operation.
- This fan is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Ceiling Fan Motor Assembly
- 3 Silver Finish Plywood Blades
- Integrated Matte Opal Glass Light Kit
- Handheld Remote Control
- Mounting Hardware Kit

- Instruction Manual



Image of the Harbor Breeze Mazon 44-inch Brushed Nickel Flush Mount Indoor Ceiling Fan with light kit and remote.

SETUP AND INSTALLATION

Professional installation is recommended if you are unfamiliar with electrical wiring.

1. **Prepare the Mounting Location:** Turn off power at the circuit breaker. Securely attach the mounting bracket to a ceiling joist or an outlet box approved for ceiling fan support.
2. **Wire the Fan:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the separate detailed installation guide (not included in this summary). Ensure all connections are secure and insulated.
3. **Attach the Fan Assembly:** Carefully lift the fan motor assembly and attach it to the mounting bracket.
4. **Install Blades:** Attach the three silver finish plywood blades to the motor housing using the provided screws. Ensure blades are securely fastened.
5. **Install Light Kit:** Connect the integrated matte opal glass light kit to the fan's wiring. Secure the light kit to the fan assembly.
6. **Restore Power:** Once installation is complete, restore power at the circuit breaker.

OPERATING INSTRUCTIONS

Your Harbor Breeze Mazon ceiling fan comes with a handheld remote control for convenient operation.

Remote Control Functions

- **Fan Speed Control:** The remote allows you to select from 3 motor speeds (Low, Medium, High).
- **Light Control:** Turn the integrated LED light on or off. The light is dimmable; press and hold the light button to adjust brightness.
- **Reverse Air Flow:** This fan features a reverse air flow function, allowing you to change the direction of blade rotation for seasonal comfort.

Note: If the fan produces a humming noise, especially on low speed, ensure it is not connected to a dimmer switch on the wall. This fan's integrated LED light is dimmable via the remote, and an external dimmer switch can cause interference.

MAINTENANCE

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners as they may damage the finish.

- **Blade Care:** Periodically check that all blade screws are tight. Loose blades can cause wobbling and noise.
- **Light Kit:** The integrated LED module is designed for long life and does not require bulb replacement. If the light stops working, refer to the troubleshooting section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	Power off; loose wiring; remote battery low	Check circuit breaker; verify wiring connections; replace remote battery
Fan wobbles	Loose blade screws; unbalanced blades; loose mounting	Tighten all blade screws; ensure blades are balanced; check mounting bracket
Light does not work	Loose wiring; remote issue; integrated LED module failure	Check wiring to light kit; ensure remote is functioning; contact support if LED module fails
Humming noise	Connected to a wall dimmer switch	Remove wall dimmer switch and replace with a standard ON/OFF switch

SPECIFICATIONS

Model: Mazon 00724

Fan Diameter: 44 inches

Number of Blades: 3

Blade Finish: Silver

Finish Type: Brushed Nickel

Light Kit: Integrated LED (18-watt)

Control Method: Handheld Remote

Motor Speeds: 3

Reverse Air Flow: Yes

Mounting Options: Flush mount

Indoor/Outdoor Usage: Indoor

Airflow (CFM): 4545 (High Speed)

Noise Level: 45 dB

Voltage: 120 Volts

Product Dimensions: 44"D x 44"W x 12"H

Item Weight: 16.87 pounds

Certifications: UL Safety Listing

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official HARBOR BREEZE website. Keep your proof of purchase for warranty claims.

Customer Service: For assistance, please contact HARBOR BREEZE customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question