

[Manuals.plus](#) /

› [Tiny Love](#) /

› Tiny Love Take Along Mobile Meadow Days Instruction Manual

Tiny Love 3333130491

Tiny Love Take Along Mobile Meadow Days Instruction Manual

Model: 3333130491

1. INTRODUCTION

The Tiny Love Take Along Mobile Meadow Days is a versatile 3-in-1 musical mobile designed to provide entertainment and comfort for infants. It features soothing tunes and gentle motion to engage and relax your baby. This mobile can be easily attached to various baby gear, including play yards, travel cots, infant carriers, strollers, and bassinets, offering familiarity and stimulation wherever you go.



Image 1.1: The Tiny Love Take Along Mobile Meadow Days, featuring colorful animal characters (fox, bird, hedgehog) and a green musical unit, designed for portability and infant engagement.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Failure to follow these instructions could result in serious injury.

- **WARNING:** To prevent possible injury by entanglement, remove this toy when the child starts trying to get up on their hands and knees in a crawling position.
- Do not use this product in a motor vehicle.

- Adult assembly is required.
- Keep all packaging materials out of reach of children to avoid suffocation hazards.
- Always ensure the mobile is securely attached to the baby gear before use.
- Regularly inspect the mobile for any signs of damage or wear. Discontinue use if any damage is found.

3. PACKAGE CONTENTS

The Tiny Love Take Along Mobile Meadow Days package includes:

- 1 x Tiny Love Take Along Mobile Meadow Days unit

4. SETUP AND INSTALLATION

4.1 Battery Installation

1. Locate the battery compartment on the main unit of the mobile.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 3 AA batteries (not included), ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use new batteries of the same type. Do not mix old and new batteries or different types of batteries. Remove batteries if the product is not used for an extended period.

4.2 Attaching the Mobile

The mobile features a designated connector for various baby gear. Ensure the mobile is securely fastened and out of your baby's reach when attached.

- **For Strollers:** Use the large clip to attach the mobile securely to the stroller canopy or frame.



Image 4.1: The mobile securely attached to a stroller canopy using its large clip, providing entertainment for the baby.

- **For Cribs/Bassinets:** Utilize the adjustable clamp mechanism to fasten the mobile to the side rail of the crib or bassinet. Ensure a tight fit.



Image 4.2: The mobile mounted on a crib rail, positioned above the baby for visual and auditory stimulation.

- **For Infant Carriers/Car Seats:** The mobile can be attached to the handle or canopy of an infant carrier using its clip.




Image 4.3: The mobile clipped onto the handle of an infant car seat, offering entertainment during travel.

- **For Play Yards/Travel Cots:** Attach the mobile to the top rail of the play yard or travel cot using the appropriate connector.



Image 4.4: The mobile attached to the side of a play yard, providing a stimulating environment for the baby.

5. OPERATING INSTRUCTIONS

The Tiny Love Take Along Mobile offers musical melodies and gentle movement to engage your baby.

- **Power On/Off:** Locate the power switch on the main unit. Slide it to the 'On' position to activate the mobile. Slide to

'Off' to turn it off.

- **Music Playback:** The mobile plays 5 different tunes for 30 minutes of continuous music. Cycle through the tunes using the designated button or switch.



Image 5.1: The mobile unit illustrating its musical feature with musical notes graphic.

- **Movement:** The mobile's characters gently spin, providing visual stimulation for your baby. This movement typically operates in conjunction with the music.
- **Silent Mode:** Some models may feature a silent mode, allowing the mobile to spin without music. Refer to the specific controls on your unit. Note that activating silent mode may require cycling past the music setting.

6. CARE AND MAINTENANCE

Proper care ensures the longevity and hygiene of your mobile.

- **Cleaning:** Wipe the mobile's surfaces with a damp cloth and mild soap. Do not immerse the electronic unit in water.
- This product is **not** dishwasher compatible.
- Allow all parts to air dry completely before reassembly or storage.

- Store the mobile in a clean, dry place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your Tiny Love Take Along Mobile, refer to the following common solutions:

Problem	Possible Cause	Solution
Mobile does not turn on or play music.	◦ Batteries are dead or incorrectly installed. ◦ Power switch is in the 'Off' position.	◦ Replace batteries with new AA batteries, ensuring correct polarity. ◦ Ensure the power switch is in the 'On' position.
Music is too loud or has abrupt transitions.	◦ Speaker output is high. ◦ Design characteristic of tune transitions.	◦ Consider placing a small piece of tape over the speaker to slightly muffle the sound. ◦ This is a design characteristic; no direct adjustment is available.
Mobile characters do not spin.	◦ Low battery power. ◦ Obstruction preventing movement.	◦ Replace batteries. ◦ Check for any objects or fabric obstructing the spinning mechanism.

8. SPECIFICATIONS

Feature	Detail
Model Number	3333130491
Brand	Tiny Love
Product Dimensions (L x W x H)	22 x 26.5 x 34 cm
Item Weight	339.99 g (11.99 Ounces)
Material Type	Textile
Batteries Required	Yes (3 AA batteries)
Music Duration	30 minutes continuous music
Number of Tunes	5 different tunes
Mounting Type	Crib Mount (and other universal attachments)
GTIN (Global Trade Identification Number)	07290108861099

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact Tiny Love customer service directly. Contact details can typically be found on the manufacturer's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question