

[Manuals.plus](#) /

› [Superer](#) /

› Superer 65W AC Charger Instruction Manual

Superer ADP195334L

Superer 65W AC Charger Instruction Manual

Model: ADP195334L

PRODUCT OVERVIEW

This manual provides essential information for the safe and effective use of your Superer 65W AC Charger. This power adapter is designed to provide reliable power to compatible Dell OptiPlex Micro Desktop computers.

Compatibility: Fit for Dell OptiPlex 7050, 9020, 3050, 3070, 3080, 3090, 3020, 3060, 5050, 7070, 3040, D09U, D09U001, D10U, D10U002 Micro Desktop models. *Note: Not compatible with Optiplex 7050, 7070 requiring 90W or 130W power adapters. Ensure your device requires 65W (19.5V 3.34A) or 45W (19.5V 2.31A) before purchase.*



Image: The Superer 65W AC Charger, showing the main adapter unit with its attached DC output cable and round tip connector, alongside the detachable AC input power cord with a 2-prong plug.

SAFETY INFORMATION

Your Superer AC Charger is designed with multiple safety features to protect your device and ensure safe operation.

- **UL Listed:** This product meets nationally recognized standards for high-level electronic safety.
- **Overcharge Protection:** Prevents damage to your device from excessive charging.
- **Overvoltage Protection:** Safeguards against voltage surges.
- **Electrostatic Protection:** Protects against electrostatic discharge.
- **Magnetic Field Protection:** Shields against magnetic interference.
- **Short Circuit Protection:** Prevents damage from short circuits.
- **Overcurrent Protection:** Protects against excessive current flow.

Safety Protection



**Overheating
Protection**



**Overvoltage
Protection**



**Electrostatic
Protection**



**Magnetic Field
Protection**



**Short Circuit
Protection**



**Overcurrent
Protection**

Image: A visual representation of the charger's safety features, including icons for overheating, overvoltage, electrostatic, magnetic field, short circuit, and overcurrent protection.

Why Choose Us ?



Advantage	Our Charger	Other Charger
UL Listed - Meet high safety, health and environmental protection requirements in the US	✓	✗
Manufactured with quality materials that exceed the industry standard	✓	✗
Went through rigorous exams to meet DOE and OSHA's requirements	✓	✗

Image: The UL Listed certification logo, indicating compliance with safety standards, alongside a comparison table highlighting the charger's adherence to safety, quality, and regulatory requirements.

PACKAGE CONTENTS

Upon opening the package, you should find the following items:

- 1 x Superer 65W AC Power Adapter
- 1 x AC Power Cord

SPECIFICATIONS

Feature	Detail
Model Number	ADP195334L

Output	19.5V 3.34A 65W (Compatible with 19.5V 2.31A 45W)
Input	100-240V 50-60Hz
Product Dimensions	4.21 x 1.85 x 1.22 inches
Item Weight	10.8 ounces
Connector Type	Round Connector
Total Cord Length	Approximately 10 feet (3 meters)
Color	Black

Item Dimension




Image: A diagram illustrating the physical dimensions of the charger unit, showing its length (4.25 inches), width (1.81 inches), and height (1.2 inches).

Total Cord Length 10 Ft

Max.Output: 65W 19.5V 3.34A



Image: The charger in use, plugged into a wall outlet, demonstrating the total cord length of approximately 10 feet, connecting to a laptop on a desk.


SETUP INSTRUCTIONS

1. **Unpack the Charger:** Carefully remove the power adapter and AC power cord from their packaging.
2. **Connect the AC Power Cord:** Insert the 2-prong end of the AC power cord firmly into the input port on the power adapter unit.
3. **Connect to Power Outlet:** Plug the other end of the AC power cord into a standard wall outlet (100-240V, 50-60Hz).
4. **Connect to Device:** Insert the round tip connector of the power adapter's output cable into the power input port of your compatible Dell OptiPlex Micro Desktop computer. Ensure the connection is secure.

Equipment Charging Port



Straight head



Type - C



Image: A close-up showing the compatible straight head (round) charging port and an incompatible Type-C port, emphasizing the correct connector type for this charger.

Adapter Details



Fastening Cable Tie



2 Prong Plug



Long Lasting & Durable
Cable



Round Tip

Image: Detailed views of the charger's features, including the fastening cable tie, the 2-prong AC plug, the long-lasting and durable output cable, and the round tip connector.

OPERATING INSTRUCTIONS

Once connected, the charger will automatically begin to supply power to your Dell OptiPlex Micro Desktop. The blue indicator light on the adapter unit will illuminate when power is being supplied.

- Ensure all connections are firm before use.
- Use the charger in a well-ventilated area to prevent overheating.
- Disconnect the charger from the power outlet when not in use for extended periods.

MAINTENANCE

- **Cleaning:** Disconnect the charger from all power sources before cleaning. Use a soft, dry cloth to wipe the surface of the adapter. Do not use liquid cleaners or sprays.
- **Storage:** When not in use, store the charger in a cool, dry place, away from direct sunlight and extreme

temperatures. Use the integrated cable tie to keep the cables neatly organized.

- **Cable Care:** Avoid bending or crimping the cables excessively, especially near the connectors, as this can cause internal damage.
- **Inspection:** Periodically inspect the charger and cables for any signs of damage, such as frayed wires, cracked casing, or bent pins. If damage is found, discontinue use immediately.

TROUBLESHOOTING

If you encounter issues with your Superer AC Charger, please refer to the following common solutions:

- **No Power/Device Not Charging:**
 - Ensure the AC power cord is securely connected to both the adapter unit and the wall outlet.
 - Verify that the round tip connector is fully inserted into your Dell OptiPlex Micro Desktop's power port.
 - Check if the wall outlet is functioning by plugging in another device.
 - Confirm that the blue indicator light on the adapter is illuminated. If not, recheck connections.
- **"Wattage Cannot Be Determined" or Reduced Performance (e.g., 0.8GHz):**
 - This issue often arises if the charger's wattage does not meet the specific requirements of your Dell OptiPlex model, even if the connector fits.
 - *Important:* This 65W charger is designed for Dell OptiPlex Micro Desktops that require 65W (19.5V 3.34A) or 45W (19.5V 2.31A). It is **not compatible** with models requiring higher wattage, such as 90W or 130W, even if they are OptiPlex 7050 or 7070. Using an underpowered adapter can lead to performance throttling or error messages.
 - Verify your specific Dell OptiPlex model's power requirements. This information is usually found on the original adapter or in your computer's documentation.
- **Charger Feels Warm:**
 - It is normal for power adapters to become warm during operation.
 - Ensure the charger is placed in a well-ventilated area and not covered by anything that could trap heat.
 - If the charger becomes excessively hot to the touch or emits a burning smell, disconnect it immediately and cease use.

WARRANTY AND SUPPORT

Superer stands behind the quality of its products. Your Superer 65W AC Charger comes with the following:

- **30-Day Replacement or Returns:** This product is eligible for replacement or returns within 30 days of purchase.
- **12 Months Guarantee:** The manufacturer provides an additional 12-month guarantee from the date of purchase.

For warranty claims, technical support, or any other inquiries, please contact Superer customer service through the retailer where you purchased the product or visit the official Superer store page on Amazon: [Superer Store](#).

© 2025 Superer. All rights reserved.

This manual is for informational purposes only. Superer reserves the right to make changes to product specifications without prior notice.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B071J26Q4T>

More documents and user manuals: <https://manuals.plus/>