

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Baymart](#) /
- › [Baymart DY22 Portable Wireless Bluetooth Stereo Speaker User Manual](#)

Baymart DY22

Baymart DY22 Portable Wireless Bluetooth Stereo Speaker User Manual

Model: DY22

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your Baymart DY22 Portable Wireless Bluetooth Stereo Speaker. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.



Image: The Baymart DY22 Portable Wireless Bluetooth Stereo Speaker, black with red accents, shown from a front-top angle.

PRODUCT OVERVIEW

Key Features

- **Superior Sound Quality:** Equipped with 10W acoustic drivers and Passive Vibration Technology for clear, full sound.


SUPERIOR SOUND ULTRA CLEAR SOUND

Dual high-performance drivers for the immersive 360-degree sound



Image: An exploded view diagram illustrating the dual high-performance acoustic drivers within the speaker, emphasizing clear sound and deep bass.

- **Versatile Input Modes:** Supports Wireless Bluetooth, FM Radio, Micro SD card, USB flash drive, and AUX-in.
- **Long Playtime:** Built-in 2200 mAh rechargeable battery provides up to 8 hours of playback.
- **Compact Design:** Portable and easy to carry for indoor and outdoor use.



Portable to go Anywhere

Compact & Convenient Design, just take and go enjoy your BBQ, pool side party and chilling with friends & family

Image: A person holding the compact Baymart DY22 speaker, highlighting its portability for various activities.

- **Broad Compatibility:** Connects with various Bluetooth-enabled devices including smartphones, tablets, and computers.




Image: The speaker on a wooden desk, surrounded by a smartphone, iPad, and laptop, illustrating its wide compatibility with different devices.

- **Built-in Microphone:** For hands-free calling.

Package Contents

- Baymart DY22 Bluetooth Speaker
- 3.5mm Audio Cable
- Micro USB Charging Cable
- Quick Start Manual (this document)

Component Identification

Wide Compatibility

Extended compatibility with most Bluetooth devices, such as Android, iPhone, Tablet, PC, etc



Image: Top view of the speaker showing control buttons: Previous Track, Mode Select, Play/Pause/Call Answer, Next Track, Volume -, Volume +.

WIRELESS BLUETOOTH 5.0

Faster and more stable connection to Bluetooth devices



Image: Rear view of the speaker showing ports: Line-In Jack (AUX), Micro SD Card slot, USB Input Slot, USB Charge Port (Micro USB), and Power Switch (OFF/ON).

SETUP

Initial Charging

1. Locate the Micro USB Charging Cable included in the package.
2. Connect the Micro USB end of the cable to the USB Charge Port on the rear of the speaker.
3. Connect the standard USB end of the cable to a USB power adapter (not included) or a computer's USB port.
4. Allow the speaker to charge fully before first use. Charging time is approximately 3.5 hours. The charging indicator light (if present, refer to device for specific behavior) will typically change or turn off when fully charged.

Powering On/Off

- To power on the speaker, slide the Power Switch (located on the rear) to the "ON" position.
- To power off the speaker, slide the Power Switch to the "OFF" position.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light (refer to device for specific indicator).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "DY22" from the list of available devices.
4. Once paired, the speaker will emit an audible confirmation, and the LED indicator will typically stop flashing and remain solid.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range.



Image: The speaker positioned on a desk, wirelessly connected to a laptop and smartphone, illustrating Bluetooth 5.0 connectivity.

FM Radio Mode

1. Power on the speaker.
2. Press the "MODE" button repeatedly until "FM" mode is announced or indicated.
3. To auto-scan and save available FM stations, press and hold the "Play/Pause" button. The speaker will scan and store stations.
4. Use the "Previous Track" and "Next Track" buttons to navigate between saved stations.

Micro SD Card / USB Playback

1. Insert a Micro SD card into the Micro SD Card slot or a USB flash drive into the USB Input Slot on the rear of the speaker.

2. The speaker will automatically switch to the corresponding mode (if not, press "MODE" to select).
3. Playback will begin automatically. Use the "Previous Track", "Next Track", and "Play/Pause" buttons to control playback.

AUX-in Mode

1. Connect one end of the 3.5mm Audio Cable to the Line-In Jack (AUX) on the rear of the speaker.
2. Connect the other end of the 3.5mm Audio Cable to the audio output jack of your external device.
3. Press the "MODE" button repeatedly until "AUX" mode is announced or indicated.
4. Audio playback will be controlled from your external device.

Call Function

- When connected via Bluetooth, if a call is received, press the "Play/Pause/Call Answer" button to answer the call.
- To end a call, press the "Play/Pause/Call Answer" button again.
- To reject an incoming call, press and hold the "Play/Pause/Call Answer" button.

Volume Control

- Press the "Vol-" button to decrease the volume.
- Press the "Vol+" button to increase the volume.

CHARGING

The Baymart DY22 speaker is powered by a built-in 2200 mAh rechargeable Lithium Polymer battery. When the battery is low, the speaker may indicate this with an audible prompt or a flashing LED. Connect the Micro USB charging cable to the speaker's USB Charge Port and a 5V USB power source to recharge. A full charge takes approximately 3.5 hours and provides up to 8 hours of playtime, depending on volume and usage.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or high humidity.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the power switch is in the "ON" position. Charge the speaker for at least 30 minutes. The battery may be completely depleted.

Problem	Possible Solution
Cannot pair via Bluetooth.	<p>Ensure the speaker is in Bluetooth pairing mode (flashing LED).</p> <p>Make sure Bluetooth is enabled on your device.</p> <p>Move the speaker closer to your device (within 10 meters).</p> <p>Forget "DY22" from your device's Bluetooth list and try pairing again.</p> <p>Ensure no other devices are currently connected to the speaker.</p>
No sound or low volume.	<p>Increase the volume on both the speaker and your connected device.</p> <p>Ensure the correct input mode (Bluetooth, AUX, SD, USB) is selected.</p> <p>For AUX mode, ensure the 3.5mm cable is fully inserted and not damaged.</p>
FM Radio reception is poor.	<p>Relocate the speaker to an area with better signal reception.</p> <p>Perform an auto-scan again to ensure all available stations are saved.</p>
USB/Micro SD card not playing.	<p>Ensure the card/drive is inserted correctly and fully.</p> <p>Verify that the audio files on the card/drive are in a supported format.</p> <p>Try a different Micro SD card or USB drive.</p>
Charging port issues (e.g., crackling sound during charging, difficulty inserting cable).	<p>Ensure the Micro USB cable is not damaged and is inserted correctly.</p> <p>Try a different Micro USB cable.</p> <p>Avoid forcing the cable into the port. If issues persist, contact customer support.</p>

SPECIFICATIONS

Feature	Detail
Brand	Baymart
Model Name	DY22 (732840192354)
Speaker Type	Bookshelf / Portable
Connectivity Technology	Bluetooth, Auxiliary (3.5mm), USB
Wireless Communication Technology	Bluetooth & FM
Bluetooth Range	10 Meters
Speaker Maximum Output Power	10 Watts
Audio Driver Type	Dynamic Driver

Feature	Detail
Power Source	Battery Powered
Battery Type	1 Lithium Polymer battery (included)
Battery Capacity	2200 mAh
Charging Time	3.5 Hours
Input Voltage	5 Volts
Product Dimensions (D x W x H)	2.8" x 8.7" x 2.8" (7cm x 22.3cm x 7cm)
Item Weight	1.4 Pounds (0.64 kg)
Control Method	Touch buttons
Special Features	Bass Boost, USB Port, Built-in Microphone, FM Radio, Micro SD Card Slot
Recommended Uses	Indoor/Outdoor
Is Waterproof	No



Image: Diagram showing the dimensions of the Baymart DY22 speaker: 8.7 inches (22.3 cm) in length, 2.8 inches (7 cm) in width, and 2.8 inches (7 cm) in height.

WARRANTY AND SUPPORT

Warranty Information

The Baymart DY22 speaker comes with a limited warranty. Please refer to the warranty card included in your package or contact Baymart customer support for specific terms and conditions regarding warranty coverage and duration.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Baymart customer support. Contact information can typically be found on the product packaging, the official Baymart website, or through your retailer.