Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Novogratz 2115329N

Novogratz Brittany Futon Sofa Bed Instruction Manual

Model: 2115329N

Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty | Support

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Novogratz Brittany Futon Sofa Bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Novogratz Brittany Futon Sofa Bed is a versatile piece designed with a Mid-Century Modern aesthetic, featuring a ribbed channel tufted backrest, curved armrests, and slanted solid wood legs. It functions as a sofa, lounge, and sleeper bed, making it suitable for various living spaces.



Image: The Novogratz Brittany Futon Sofa Bed in a modern living room environment.

Setup and Assembly

Assembly of your Novogratz Brittany Futon Sofa Bed is designed to be straightforward. All necessary tools and instructions are included in the packaging. It is recommended that **two people** perform the assembly to ensure ease and safety.

Included Components:

- Futon Sofa Bed Frame
- Solid Wood Legs
- Center Support Legs (plastic)
- Hardware (washers, nuts, bolts)
- Assembly Tools (e.g., flat wrench)

Assembly Steps:

1. Unpack all components and verify against the included parts list.
2. Locate the futon arms within the zippered compartments beneath the seat sections.
3. Attach the solid wood legs and center support legs to the futon frame. Ensure all bolts, nuts, and washers are securely tightened. For the arms, ensure proper hand-tightening to prevent wobbling.
4. Carefully flip the assembled futon right side up. Assistance is recommended during this step to avoid damage to the legs or the folding mechanism.
5. Ensure all connections are stable before use.



Image: Rear view of the futon, illustrating the folding mechanism and leg attachment areas.



Image: Feature diagram showing the various components and design elements of the futon.

Operation

The Novogratz Brittany Futon Sofa Bed is designed for versatile use, easily converting between sofa, lounge, and bed positions using a simple push-pull mechanism.

Converting from Sofa to Bed:

1. To convert the futon from a sofa to a bed, gently push the backrest forward until you hear a click, then slowly lower it backward until it lies flat.
2. Ensure the concealed folding legs (if applicable) are extended to provide additional support in the bed position.

Converting from Bed to Sofa:

1. To return the futon to the sofa position, lift the backrest until it clicks into an upright position.
2. Ensure any extended support legs are folded back into their concealed positions.



Image: Visual representation of the futon in its three functional positions: sitting, lounging, and sleeping.



Image: Detailed dimensions for the futon when configured as a sofa and as a bed.

Maintenance

Proper care will extend the life and appearance of your futon sofa bed.

Cleaning Instructions:

- For general cleaning, wipe the futon material with a slightly damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the fabric.
- Spot clean spills immediately with a clean, dry cloth.

General Care:

- Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary.
- Felt-lined legs are designed to prevent scratches on hardwood floors; however, always lift the futon when moving it to avoid dragging.
- Avoid prolonged exposure to direct sunlight to prevent fading of the upholstery.

Troubleshooting

Here are solutions to common issues you might encounter with your futon sofa bed:

Wobbly Arms:

- Ensure that the bolts securing the arms are properly tightened. It is important to tighten them evenly and re-check after initial use.

Cushion Discomfort or Sinking:

- The futon features foam-cushioned seats with a medium firmness. If you desire a softer feel or notice sinking over time, consider adding a mattress topper or additional seat padding.
- For back comfort, using decorative pillows can enhance support.

Instability in Bed Mode:

- Verify that all support legs, including the concealed folding legs, are fully extended and locked into place when the futon is in the bed position.
- Ensure the futon is placed on a flat, stable surface.

Feeling the Wood Frame/Springs:

- If you feel the internal structure, especially near the edges, consider adding a memory foam pad or a thick blanket over the seating area for improved comfort.

Specifications

Feature	Detail
Brand	Novogratz
Model Number	2115329N
Product Dimensions (Sofa)	81.5"L x 34.5"W x 31.5"H
Bed Size (Reclined)	70.5"L x 43.5"W x 16"H
Seat Depth	23.5 inches
Seat Height	16 inches
Weight Limit	600 pounds
Item Weight	90 pounds
Seating Capacity	3
Color	Green
Style	Mid-Century Modern Futon
Upholstery Fabric Type	Linen-look Fabric
Fill Material	Foam

Frame Material	Plywood
Furniture Leg Material	Wood
Item Firmness Description	Medium
Assembly Required	Yes
Recommended People for Assembly	2
Product Care Instructions	Wipe with Damp Cloth

Warranty Information

The Novogratz Brittany Futon Sofa Bed comes with a**1-year limited warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please refer to the warranty documentation included with your product for full terms and conditions.

Customer Support

For any questions, assistance with assembly, or to order replacement parts, please contact Novogratz customer support. Our team is available 7 days a week to provide support.

- **Customer Support:** Available 7 days a week.
- **Online Replacement Parts:** Easily order parts online if needed.

Please have your model number (2115329N) and purchase information ready when contacting support.

© 2026 Novogratz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071KLJGVN

More documents and user manuals: **https://manuals.plus/**