

## CUCKOO CRP-HZ0683FR

# CUCKOO IH Pressure Rice Cooker CRP-HZ0683FR Instruction Manual

Model: CRP-HZ0683FR

## 1. PRODUCT OVERVIEW

The CUCKOO IH Pressure Rice Cooker CRP-HZ0683FR is designed to prepare various types of rice and grains with precision using induction heating and fuzzy logic technology. This appliance features a durable stainless steel inner pot with a nonstick coating, multiple cooking functions, and a voice guide for ease of use.



Image: The CUCKOO IH Pressure Rice Cooker CRP-HZ0683FR, showcasing its design and compact size on a kitchen counter.

## 2. SETUP AND INITIAL USE

### 2.1 Unboxing and Components

Carefully remove all components from the packaging. Ensure the following items are present:

- CUCKOO IH Pressure Rice Cooker unit
- Stainless steel inner pot with X-Wall nonstick coating
- Rice spatula
- Rice measuring cup
- Steam plate



Image: The included accessories: rice spatula, measuring cup, and steam plate.

### 2.2 Initial Cleaning

Before first use, wash the inner pot, inner lid, rice spatula, measuring cup, and steam plate with warm, soapy water.

Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.

## 2.3 Placement

Place the rice cooker on a stable, level surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Preparing Ingredients

1. Measure the desired amount of rice using the provided measuring cup.
2. Rinse the rice thoroughly until the water runs clear.
3. Place the rinsed rice into the inner pot. Add water according to the markings inside the inner pot for your chosen rice type.

Your browser does not support the video tag.

Video: A demonstration of preparing rice and water levels in the inner pot.

### 3.2 Cooking Functions

The CRP-HZ0683FR offers 13 menu options, including:

- GABA/Brown Rice
- Glutinous/White Rice
- Pressure Cook
- Nu Rung Ji
- Multi-Cook

The unit utilizes induction heating for even cooking and a smart algorithm to detect grain type and internal temperature, ensuring optimal results. Cooking white rice can be completed in as little as 20 minutes.



Image: The LED touch control panel, featuring the voice guide function.

### 3.3 Using the Control Panel

The rice cooker features LED touch controls. Select your desired cooking mode by pressing the 'Menu' button. Confirm your selection with the 'Set' button. The 3-language voice guide (English, Korean, Chinese) will provide audible instructions and status updates.

### 3.4 Additional Features

- **Preset Timer:** Allows you to set a delayed cooking start time.
- **Reheat Option:** For warming up cooked rice or leftovers.

- **Keep-Warm Function:** Maintains the temperature of cooked rice without overcooking.



Image: Example of perfectly cooked rice, ready to serve.

## 4. MAINTENANCE AND CLEANING

---

### 4.1 Inner Pot and Inner Lid

The stainless steel inner pot with X-Wall nonstick coating is designed for durability and easy cleaning. It is recommended to hand wash the inner pot and the removable inner lid after each use. Do not use abrasive cleaners or metal scrubbers.



Image: The removable inner lid being cleaned under running water.

### 4.2 Auto-Clean Function

The rice cooker features an auto-clean function that uses steam to clean the interior. To activate, ensure the inner pot is empty and filled with water up to the 'Auto Clean' line. Close the lid and select the 'Auto Clean' option from the menu. This helps loosen residue and maintain hygiene.



Image: Illustration of the steam cleaning process within the rice cooker.

### 4.3 Water Drain

The water drain system collects excess moisture, contributing to freshness and easier cleaning. Regularly check and empty the water drain tray.



Image: Close-up of the water drain mechanism.

## 5. TROUBLESHOOTING

---

For detailed troubleshooting steps, please refer to the comprehensive user manual provided with your product. Below are some common issues and general guidance:

- **Voice Guide Language:** If the voice guide is not in your preferred language, access the settings menu (often by holding the 'Mode' button) and navigate to the language selection. Follow the voice prompts to select English, Chinese, or Korean.
- **Rice Not Cooked Properly:** Ensure the correct water-to-rice ratio is used and that the inner pot is properly seated. Verify the selected cooking mode matches the rice type.
- **Error Codes:** If an error code appears on the display, consult the full manual for specific code meanings and resolutions.

## 6. SPECIFICATIONS

---

Brand	CUCKOO
-------	--------

<b>Model Name</b>	CRP-HZ0683FR
<b>Capacity</b>	6 Cups (Uncooked) / 1.5 Quarts
<b>Product Dimensions</b>	15"D x 11"W x 10"H
<b>Item Weight</b>	13 Pounds
<b>Power Source</b>	Corded Electric
<b>Voltage</b>	110 Volts
<b>Wattage</b>	1207 watts
<b>Material</b>	Stainless Steel
<b>Lid Material</b>	Stainless Steel
<b>Color</b>	Black/Red
<b>Included Components</b>	Rice cooker, stainless steel inner pot, rice spatula, rice measuring cup, steam plate
<b>Other Special Features</b>	Timer



Image: Product dimensions illustration, showing the 10-inch height.

## 7. WARRANTY AND SUPPORT

---

This CUCKOO IH Pressure Rice Cooker CRP-HZ0683FR comes with a **1-year manufacturer's warranty**. For warranty claims, technical support, or service inquiries, please refer to the contact information provided in your product's full user manual or visit the official CUCKOO website.