

Accessory USA AC DC Adapter for Eton Rugged Rukus NRKS200 Series

Accessory USA AC DC Adapter User Manual

FOR ETON RUGGED RUKUS NRKS200, NRKS200GR, NRKS200B SERIES

1. Introduction

This manual provides essential instructions for the safe and effective use of your Accessory USA AC DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically the Eton Rugged Rukus NRKS200, NRKS200GR, and NRKS200B All-Terrain Portable Solar Wireless Sound Systems.

Please read this manual thoroughly before using the product and retain it for future reference.

2. Setup

Connecting the Adapter

1. **Verify Compatibility:** Before connecting, ensure your device is an Eton Rugged Rukus NRKS200, NRKS200GR, or NRKS200B model.
2. **Inspect Adapter:** Check the adapter and its cord for any visible damage. Do not use if damaged.
3. **Connect to Device:** Insert the barrel connector end of the adapter firmly into the power input port of your Eton Rugged Rukus sound system.
4. **Connect to Power Outlet:** Plug the 2-pin main power connector into a standard AC wall outlet (100V - 240V, 50-60Hz).

Important Note: Always ensure the input voltage of the adapter matches the specifications of your power outlet to prevent damage to the adapter or your device.

3. Operating

Powering Your Device

Once the Accessory USA AC DC Adapter is correctly connected to both the Eton Rugged Rukus sound system and a power outlet, your device should begin to receive power. Refer to your Eton Rugged Rukus sound system's manual for specific instructions on powering on and operating the device.

The adapter provides a stable power source for continuous operation or for charging the internal battery of your sound system, if applicable.

4. Maintenance

Care and Storage

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the power cord to prevent damage.
- **Handling:** Do not drop, disassemble, or attempt to repair the adapter yourself. This can void the warranty and pose safety risks.
- **Environmental Conditions:** Avoid exposing the adapter to moisture, rain, or excessive humidity.

5. Troubleshooting

Common Issues and Solutions

- **No Power to Device:**
 - Ensure the adapter is securely plugged into both the wall outlet and the device.
 - Check if the wall outlet is functional by plugging in another device.
 - Inspect the adapter cord for any breaks or damage.
- **Device Not Charging:**
 - Confirm the adapter is the correct model for your Eton Rugged Rukus sound system.
 - Verify the device's charging indicator (if any) is active.
 - Ensure the device's battery is not fully charged or defective.
- **Adapter Overheating:**
 - Unplug the adapter immediately.
 - Ensure the adapter is used in a well-ventilated area and not covered.
 - If overheating persists, discontinue use and contact support.

If these steps do not resolve the issue, please refer to the Warranty and Support section.

6. Specifications

Technical Details

Feature	Detail
Input Voltage	AC 100V - 240V
Frequency Range	50-60Hz
Connector Type	Barrel Connector
Main Power Connector Type	2 Pin

Feature	Detail
Compliance	CE Certified
ASIN	B071L8PT51
UPC	650234610072

7. Warranty and Support

Warranty Information

Accessory USA products are marketed and sold exclusively by Accessory USA Store. This product comes with the following warranty:

- **30 Days:** Money Back Promised.
- **60 Days:** Free Exchange with Paid Return Label.
- **365 Days:** Worry-Free Warranty.

100% MONEY BACK GUARANTEE if our product does not function as intended.

Customer Support

For any questions, concerns, or warranty claims, please contact Accessory USA Store directly through your purchase platform or their official website. Please have your purchase details and product model information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question