

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Graco](#) /

> [Graco Table2Table Premier Fold 7-in-1 Convertible High Chair Instruction Manual](#)

Graco 2022439

Graco Table2Table Premier Fold 7-in-1 Convertible High Chair Instruction Manual

Model: 2022439

[Setup](#)

[Operating Modes](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

INTRODUCTION

The Graco Table2Table Premier Fold 7-in-1 High Chair is designed to adapt as your child grows, offering multiple configurations from infant to toddler. This versatile high chair provides a secure and comfortable feeding solution, transitioning through various stages to meet your family's needs.

SETUP

Follow these instructions for initial assembly and configuration of your Graco Table2Table Premier Fold High Chair.

Key Components and Features



Image: Key features of the Graco Table2Table Premier Fold High Chair, highlighting the infant body support, dishwasher-safe tray insert, one-hand removable tray, 3-position recline, machine-washable seat pad, 3-position removable footrest, and front wheels.

Height Adjustment

The high chair offers 5 height adjustments to ensure the best fit for your dining table. To adjust the height, locate the adjustment buttons on the side of the high chair legs, press them, and slide the chair to the desired height. Ensure both sides are securely locked into place.

5 height adjustments for the perfect fit at your table



Image: The high chair adjusted to a suitable height for a dining table, allowing the child to sit comfortably with family.

Footrest Adjustment

The 3-position removable footrest can be adjusted to provide comfort for your growing child. Adjust the footrest by pressing the release buttons and sliding it to one of the three available positions.

OPERATING MODES (7-IN-1 FUNCTIONALITY)

The Graco Table2Table Premier Fold High Chair offers 7 stages of use to accommodate your child's development.

7 Growing Stages



Image: Visual representation of the 7 operating modes, from infant high chair to a toddler table and chair set.

1. **Infant High Chair:** Use with the seat reclined and infant body support for early feedings.
2. **Traditional High Chair:** For older infants who can sit upright, with the tray attached.
3. **Infant Booster:** Remove the high chair seat and attach it to a dining chair for infants.
4. **Toddler Booster:** Remove the high chair seat and attach it to a dining chair for toddlers.
5. **Youth Chair:** Use the high chair frame as a stand-alone youth chair without the tray.
6. **Toddler Table and Chair:** Separate the high chair into a toddler-sized table and a separate chair.
7. **Seating for Two:** The design allows for seating two children simultaneously in different configurations (e.g., infant booster and youth chair).

Tray Operation

The high chair features a one-hand removable tray for ease of use. To remove, press the button located at the front center of the tray and lift. The tray also includes a dishwasher-safe insert for convenient cleaning. When not in use, the

tray can be attached to the folded high chair legs for compact storage.

Recline Positions

The seat offers 3 recline positions, suitable for infants and young children. Adjust the recline by squeezing the handle at the back of the seat and moving it to the desired position.

Toddler Table and Chair Conversion

To convert the high chair into a toddler table and chair, detach the main seat from the frame. Then, separate the high chair frame into two distinct pieces: a low table and a separate toddler chair. This allows for independent use by older children.

Transitions to a big kid table & chair for your growing toddler



Image: The high chair transformed into a toddler-sized table and chair, suitable for independent play and eating.

MAINTENANCE

Proper care and maintenance will extend the life of your high chair.

- **Seat Pad:** The seat pad is machine-washable. Refer to the care label for specific washing instructions.
- **Tray, Footrest, and Frame:** These components are wipeable. Use only household soap or detergent and warm water for cleaning.
- **Tray Insert:** The tray insert is dishwasher-safe for easy cleaning.

Storage

When not in use, the high chair folds compactly for convenient storage. To fold, ensure the tray is removed (it can be stored on the folded legs), and follow the folding mechanism instructions (typically involving buttons or levers on the sides of the frame).

Compact fold for easy storage



Image: The high chair in its compact folded state, demonstrating its space-saving storage capability.

TROUBLESHOOTING

- **Difficulty Adjusting Height/Recline:** Ensure all release buttons or levers are fully engaged when attempting to adjust. Do not force components.

- **Tray Not Attaching Securely:** Verify that the tray is aligned correctly with the attachment points on the high chair arms and that the release button clicks into place.
- **High Chair Instability:** Ensure all legs are fully extended and locked into position. Do not use the high chair on uneven surfaces.
- **Cleaning Stains:** For stubborn stains on fabric, pre-treat with a mild stain remover before machine washing. For plastic parts, a soft brush may help with textured areas.

SPECIFICATIONS

Model Number	2022439
Brand	Graco
Product Dimensions	15 x 19.29 x 27 inches (D x W x H)
Item Weight	17.44 pounds
Maximum Weight Recommendation	40 Pounds
Material Type	Plastic, Polyester
Color	Landry
Batteries Required	No
Portable	Yes



Image: Detailed dimensions of the Graco Table2Table Premier Fold High Chair.

For further assistance, please visit the [Graco Store](#).