

Lenco XEMIO-280SI

Lenco XEMIO-280SI Color Silver MP4 4GB User Manual

Model: XEMIO-280SI | Brand: Lenco

INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your Lenco XEMIO-280SI MP4 player. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience. The Lenco XEMIO-280SI is a versatile portable media player featuring a 1.8-inch TFT LCD screen, 8GB internal memory, Bluetooth connectivity, and support for various audio, video, and image formats, along with an e-book function and voice recording capability.

WHAT'S IN THE BOX

Upon unboxing your Lenco XEMIO-280SI, please verify that all the following components are included:

- Lenco XEMIO-280SI MP4 Player
- USB Cable
- Earphones

PRODUCT OVERVIEW

Familiarize yourself with the physical components and controls of your Lenco XEMIO-280SI.





Figure 1: Front view of the Lenco XEMIO-280SI MP4 player. The device is silver-colored with a black screen at the top displaying a blue Bluetooth icon and text. Below the screen are physical buttons: a long vertical button labeled 'M' at the top and a 'return' arrow at the bottom, a circular play/pause button to its right, and left/right arrow buttons below these,

flanking the vertical button.

Key Components:

- **1.8" TFT LCD Screen:** Displays menus, media content, and device status.
- **Navigation Buttons:** Used to move through menus and control playback. Includes left/right arrows, a menu button ('M'), and a play/pause button.
- **Micro USB Port:** For charging the device and transferring files to/from a computer.
- **Micro SD Card Reader:** Supports memory cards up to 32GB for expanded storage.
- **3.5mm Headphone Jack:** For connecting earphones or headphones.
- **Built-in Microphone:** For voice recording functionality.

SETUP

1. Initial Charging

Before first use, fully charge the device. Connect the supplied USB cable to the Micro USB port on the player and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status. A full charge typically takes approximately 2-3 hours.

2. Powering On/Off

- **To Power On:** Press and hold the Play/Pause button for a few seconds until the screen illuminates.
- **To Power Off:** Press and hold the Play/Pause button again until the screen turns off.

3. Inserting a Micro SD Card (Optional)

If you wish to expand the storage, gently insert a Micro SD card (up to 32GB) into the Micro SD card slot until it clicks into place. Ensure the card is inserted in the correct orientation.

4. Connecting Earphones

Plug the supplied earphones into the 3.5mm headphone jack on the device.

OPERATING INSTRUCTIONS

1. Menu Navigation

Use the left and right arrow buttons to navigate through menu options. Press the 'M' (Menu) button to enter a selected option or confirm a selection. Press the 'return' arrow button (below 'M') to go back to the previous menu.

2. Audio Playback

From the main menu, select "Music" or "Audio". Browse your files using the navigation buttons. Press the Play/Pause button to start or pause playback. Supported formats include MP3, APE, FLAC, and WAV.

3. Video Playback

Select "Video" from the main menu. Navigate to your desired video file. Press the Play/Pause button to begin playback. Supported formats include AMV and AVI. Ensure videos are in compatible formats for optimal performance.

4. Image Viewing

Select "Pictures" or "Photos" from the main menu. Browse your image files. Press the 'M' button to view an

image. Supported formats include JPG, BMP, and GIF.

5. E-book Function

Select "E-book" from the main menu. The device supports TXT format e-books. Navigate to your text file and press 'M' to open and read.

6. Voice Recording

Select "Recorder" or "Voice Record" from the main menu. Press 'M' to start recording. Press 'M' again to stop and save the recording. Recordings are saved in a dedicated folder on the device.

7. Bluetooth Connectivity

From the main menu, select "Bluetooth". Turn Bluetooth ON. The device will scan for available Bluetooth devices. Select your desired device from the list and pair. Once paired, you can stream audio wirelessly to compatible Bluetooth headphones or speakers.

8. File Transfer (USB)

Connect the device to your computer using the supplied USB cable. The player will appear as a removable disk drive. You can then drag and drop files (audio, video, images, e-books) to and from the device's internal memory or inserted Micro SD card.

MAINTENANCE

Cleaning

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents. Avoid exposing the device to excessive moisture.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

TROUBLESHOOTING

- **Device does not power on:**

Ensure the battery is charged. Connect the device to a power source and try again. If the issue persists, perform a hard reset by pressing and holding the power button for an extended period (e.g., 10-15 seconds).

- **No sound from earphones:**

Check if the earphones are properly plugged into the 3.5mm jack. Ensure the volume is not set to zero or muted. Test with another pair of earphones to rule out faulty earphones.

- **Cannot transfer files to/from computer:**

Ensure the USB cable is securely connected to both the device and the computer. Try a different USB port on your computer. Verify that the device is recognized as a removable disk drive by your operating system.

- **Bluetooth pairing issues:**

Ensure Bluetooth is enabled on both the MP4 player and the target device. Place the devices close to each other. Try unpairing and re-pairing the devices. Ensure the target device is in pairing mode.

• **Screen is frozen or unresponsive:**

Press and hold the power button for approximately 10 seconds to force a restart. If the issue persists, allow the battery to fully drain and then recharge it.



SPECIFICATIONS

Feature	Detail
Brand	Lenco
Model Number	XEMIO-280SI
Screen Size	1.8 Inches (4.5 cm)
Display Technology	TFT LCD
Internal Memory	8 GB
Expandable Memory	Micro SD card up to 32GB
Audio Formats	MP3, APE, FLAC, WAV
Video Formats	AMV, AVI
Image Formats	JPG, BMP, GIF
E-book Format	TXT
Connectivity	Bluetooth, Micro USB
Battery	Built-in rechargeable (3.7V, 170mAh)
Special Features	Voice Recorder, Built-in microphone
Product Dimensions	2 x 2 x 2 cm; 199.58 g
Included Components	USB Cable, Earphone

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Lenco website. Keep your proof of purchase for warranty claims.

Lenco Official Website: www.lenco.com

 Lenco Model: XEMIO-860 User manual - MP3/MP4 Player with Bluetooth and 8GB memory Bedienungsanleitung - MP3/MP4 Player mit Bluetooth und 8 GB Speicher Manuel de l'utilisateur - Lecteur MP3/MP4 avec Bluetooth et 8 GB de mémoire Manual de usuario - Reproductor MP3/MP4 con Bluetooth y 8 GB de memoria Instrukcja obsługi - Odtwarzacz MP3/MP4 z Bluetooth i 8 GB pamięci Bedieningshandleiding - MP3/MP4-speler met Bluetooth en 8 GB-geheugen	Lenco XEMIO-860 MP3/MP4 Player User Manual Explore the Lenco XEMIO-860 MP3/MP4 Player. This user manual details its features, including Bluetooth connectivity, 8GB storage, and support for multiple audio/video formats. Learn about safe operation, technical specifications, and warranty information from Lenco.
 Lenco XEMIO-668 / MP-108 User manual - MP3 player with 8GB memory and LCD screen Bedienungsanleitung - MP3-Player mit 8 GB Speicher und LCD-Bildschirm Manuel de l'utilisateur - Lecteur MP3 avec 8 GB de mémoire et écran LCD Manual de usuario - Reproductor MP3 con 8 GB de memoria y pantalla LCD Instrukcja obsługi - Odtwarzacz MP3 z 8 GB pamięci i ekranem LCD Bedieningshandleiding - MP3-speler met 8 GB-geheugen en LCD-scherm	Lenco XEMIO-668 / MP-108 User Manual Comprehensive user manual for the Lenco XEMIO-668 and MP-108 portable media players, detailing setup, operation, features, safety, and troubleshooting.
 Lenco XEMIO-154 Guide rapide Pour des informations et une assistance, visitez : www.lenco.com	Lenco XEMIO-154 Guide Rapide - Lecteur MP3 Portable Démarrez avec votre lecteur MP3 Lenco XEMIO-154. Ce guide rapide couvre les commandes de l'appareil, l'insertion d'une carte Micro SD, la charge de la batterie, la garantie et les informations de conformité pour le Lenco XEMIO-154.
 Lenco XEMIO-950 MP5 PLAYER / 4GB MEMORY / TOUCH SCREEN For information and support: www.lenco.com	Lenco XEMIO-950 MP5 Player User Manual User manual for the Lenco XEMIO-950 MP5 Player, detailing its features, operation, specifications, and troubleshooting. Includes information on music, video, photo, recording, radio, and e-book functions.
 Lenco XEMIO-950 MP5 PLAYER / 4GB MEMORY / TOUCH SCREEN For information and support: www.lenco.com	Lenco XEMIO-950 MP5 Player User Manual User manual for the Lenco XEMIO-950 portable MP5 player, detailing its features, operations, settings, and technical specifications. Covers music playback, video viewing, photo browsing, voice recording, apps, e-book reading, and radio functions.
 Lenco USER'S MANUAL XEMIO-768 / MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com	Lenco XEMIO-768/MP-208 MP3/MP4 Player User Manual Official user manual for the Lenco XEMIO-768 and MP-208 MP3/MP4 players with Bluetooth. Contains detailed instructions, safety precautions, operational guides, and troubleshooting tips for the portable media device.



[\[pdf\]](#) Datasheet Guide Catalog

M14R mmak XEMIO 280SI MAN COMPLENCO Xemio MP4 player Bluetooth® with 8 Gb Lenco

CatalogXEMIO COMPcdn nedis datasheets COMP COMPXEMIO 280BU CatalogLENCO |||| ||| Model:

Xemio-280 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida Startvejledning

Snabbguide For information and support, www.lenco.com Zie voor informatie en ondersteuning

www.lenco.com Informationen und Helpdesk:www.lenc

Model: Xemio-280 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua

Rpida Startvejledning Snabbguide For information and support, www.lenco.com Zie

voor informatie en ondersteuning www.lenco.com Informationen und

Helpdesk:www.lenco.com Pour des informations et une assistance, visitez : www...

lang:nl **score:33** filesize: 960.97 K page_count: 41 document date: 2023-03-14



[\[pdf\]](#) Datasheet Accessories Catalog

XEMIO 280BU PDS COMPLENCO Xemio MP4 player Bluetooth® with 8 Gb Lenco CatalogXEMIO

COMPcdn nedis datasheets COMP |||

Xemio-280 Bluetooth MP3 Player with 8GB Memory 41.5 EXCLUSIVE 90.5 MM EN

Bluetooth 4.2* 1,8 4,5cm TFT LCD screen 8 GB internal memory Audio formats: MP3,

APE, FLAC, WAV Photo formats: JPG, BMP and GIF Video formats: AMV, AVI E-

book function supports TXT files Voice recording function ...

lang:nl **score:30** filesize: 875.7 K page_count: 1 document date: 2022-10-13



[\[pdf\]](#) Accessories

Xemio 280 Leaflet R4 Download Lenco MP4 Player XEMIO Blau SECOMP AG 17081068 en data 2021

secomp ch i2cmsdata s17 |||

Xemio-280 Bluetooth MP3 Player with 8GB Memory 41.5MM 90.5MM EN NL

Bluetooth 4.2* 1,8 4,5 cm TFT LCD display 8GB internal memory Audio formats: MP3,

APE, FLAC, WAV Photo formats: JPG, BMP, GIF Video formats: AMV, AVI E-book

function supports TXT files Voice record...

lang:nl **score:30** filesize: 589.1 K page_count: 1 document date: 2020-08-18




[pdf] Accessories

Xemio 280 leaflet v6 NL EN DE FR ES Lenco 280BU kopen Nu in de officiële Webshop

6206ea84894d56df8b83336c62f783787c6fcb3a cdn maxx nl |||

Xemio-280 Bluetooth MP3 Player with 8GB Memory 41.5 EXCLUSIVE 90.5 MM EN Bluetooth 4.2* 1,8 4,5cm TFT LCD screen 8 GB internal memory Audio formats: MP3, APE, FLAC, WAV Photo formats: JPG, BMP and GIF Video formats: AMV, AVI E-book function supports TXT files Voice recording function ...

lang:nl **score:30** filesize: 895.83 K page_count: 1 document date: 2022-10-13



[pdf] User Manual Datasheet Catalog

USER S MANUAL user XEMIO 280SI MAN2 COMPLENCO Xemio MP4 player Bluetooth® with 8 Gb

Lenco CatalogXEMIO COMPcdn nedis datasheets COMP COMPXEMIO 280BU CatalogLENCO ||| |||

USER S MANUAL Model: Xemio-280 USER MANUAL HANDLEIDING BENUTZERHANDBUCH MODE

D EMPLOI MANUAL DEL USUARIO BRUGERVEJLEDNING BRUKSANVISNING Media Player With

Bluetooth Audio Transmission Mediaspeler met Bluetooth audio-overdracht Media-Player

USER S MANUAL Model: Xemio-280 USER MANUAL HANDLEIDING

BENUTZERHANDBUCH MODE D EMPLOI MANUAL DEL USUARIO

BRUGERVEJLEDNING BRUKSANVISNING Media Player With Bluetooth Audio

Transmission Mediaspeler met Bluetooth audio-overdracht Media-Player mit

Bluetooth Audio-bertragung Lecteur multimedia avec tran...

lang:en **score:28** filesize: 2.67 M page_count: 200 document date: 2023-03-14