

[Manuals.plus](#) /

› [IRIS USA](#) /

› IRIS USA WOOZOO Desk Fan Model PCF-M15U Instruction Manual

IRIS USA PCF-M15U

IRIS USA WOOZOO Desk Fan Model PCF-M15U Instruction Manual

1. INTRODUCTION

Thank you for choosing the IRIS USA WOOZOO Desk Fan Model PCF-M15U. This instruction manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INSTRUCTIONS

- **Electrical Safety:** Ensure the power supply voltage matches the fan's requirements. Do not operate the fan with a damaged cord or plug. Avoid placing the fan in wet or damp areas.
- **Placement:** Place the fan on a stable, flat surface to prevent tipping. Keep the fan away from curtains, loose clothing, or other objects that could be drawn into the fan blades.
- **Usage:** Do not insert fingers or any objects into the fan grille while it is operating. Unplug the fan from the power outlet before cleaning or when not in use.
- **Children and Pets:** Keep the fan out of reach of children and pets. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- IRIS USA WOOZOO Desk Fan Model PCF-M15U
- Instruction Manual
- Remote Control (*Note: Remote control availability may vary by model variant*)

4. PRODUCT OVERVIEW

The IRIS USA WOOZOO Desk Fan is designed to provide efficient air circulation with multiple features for enhanced comfort.



Horizontal Oscillation

65 degrees of horizontal oscillation to the left & to the right allows air flow to reach every corner of your space.

Figure 1: Front view of the IRIS USA WOOZOO Desk Fan Model PCF-M15U. This compact fan features a spherical design with a spiral grille, designed for optimal air circulation in various indoor settings.

Key Features:

- **3 Speed Settings:** Easily adjust airflow intensity from low to high.
- **Horizontal Oscillation:** The fan oscillates 65 degrees horizontally to distribute air across a wider area.
- **Vertical Tilt:** Manual vertical angle adjustment from -22.5 to 90 degrees allows precise airflow direction.
- **Quiet Operation:** Operates at a low noise level of 35 dB, suitable for bedrooms and offices.
- **Powerful Airflow:** Designed to circulate air up to 46 feet.
- **Compact Design:** Ideal for placement on desks, tables, or nightstands.

Enjoy the Breeze

Powerful motor & unique design pushes air out & allows you to feel the breeze from up to **74 ft** away.

74 ft




Figure 2: Diagram illustrating the six vertical tilt positions, ranging from -22.5 to 90 degrees, allowing users to direct airflow precisely.

Whole Room Circulation

Circulates hot & cool air throughout the room (up to **275 ft²**), helping to regulate room & body temperature.




Figure 3: Visual representation of the fan's powerful airflow, capable of reaching significant distances to circulate air effectively throughout a room.

5. SETUP

1. **Unpacking:** Carefully remove the fan and all packaging materials from the box. Inspect the fan for any signs of damage.
2. **Placement:** Place the fan on a firm, level surface in the desired location. Ensure there is adequate space around the fan for optimal air intake and output.
3. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

6. OPERATING INSTRUCTIONS

Control Panel:

Six Vertical Tilt Positions

-22.5 to 90 degree manual vertical angle settings allow you to set direct air flow anywhere you want it.



Figure 4: The control panel located on the fan base, featuring buttons for power, speed adjustment (I, II, III), and oscillation control.

1. **Power On/Off:** Press the **Power button (O)** on the control panel or remote control to turn the fan on or off.
2. **Adjusting Fan Speed:** Press the **Speed buttons (I, II, III)** on the control panel or the corresponding speed buttons on the remote to cycle through the 3 available speed settings (Low, Medium, High).

Lightweight & Portable

WOOZOO® fans weigh only 3.5 lbs & features built-in handles for ease of portability.



Figure 5: Illustration of the three distinct speed settings available on the fan, allowing users to choose their preferred airflow intensity.

3. **Horizontal Oscillation:** Press the **Oscillation button (circular arrow)** on the control panel or remote to activate or deactivate the 65-degree horizontal oscillation feature.
4. **Vertical Tilt Adjustment:** Manually adjust the fan head to one of the six vertical tilt positions (-22.5°, 0°, 22.5°, 45°, 67.5°, 90°) to direct airflow as needed.
5. **Timer Function (if applicable):** If your model includes a timer, use the **Timer button** on the remote control to set the fan to automatically turn off after a specified duration.

Using the Remote Control:

If your fan model includes a remote control, ensure the battery is correctly installed. The remote allows you to conveniently control all fan functions from a distance.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the IRIS USA WOOZOO M15U Compact Oscillating Circulating Fan, highlighting its features and remote control functionality. This video provides a visual guide to operating the fan's various settings.

7. MAINTENANCE

Regular cleaning will help maintain your fan's performance and extend its lifespan.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Grille and Blades:** Periodically, the front grille can be removed for cleaning the fan blades. Refer to the diagram below for guidance. Use a soft brush or vacuum cleaner to remove dust from the blades and grilles. Ensure the fan is unplugged before attempting to clean.



Figure 6: An exploded view of the fan, illustrating how the front grille can be detached to access and clean the fan blades and interior components.

8. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

- **Fan Does Not Turn On:**
 - Check if the power cord is securely plugged into a working outlet.
 - Ensure the power button is pressed.
- **Weak Airflow:**
 - Increase the fan speed setting.
 - Clean any dust or debris from the fan grille and blades.
- **Unusual Noise:**

- Ensure the fan is placed on a stable, flat surface.
- Check for any obstructions around or within the fan grille.

9. SPECIFICATIONS

Feature	Detail
Brand	IRIS USA
Model Name	PCF-M15U
Product Dimensions (D x W x H)	7.99"D x 8.66"W x 11.93"H
Item Weight	4.4 Pounds
Color	White
Material	Plastic
Number of Speeds	3
Noise Level	35 Decibels
Max Air Distance	46 feet
Oscillation	65° Horizontal
Vertical Tilt	112° (6 positions from -22.5° to 90°)
Power Source	AC (120 Volts, 72 Watts)



Figure 7: Comparison of dimensions for WOOZOO M15U and M18U models, highlighting the compact size of the M15U.

10. WARRANTY AND SUPPORT

The IRIS USA WOOZOO Desk Fan Model PCF-M15U comes with a **5-year warranty**, covering defects in materials and workmanship under normal use. For warranty claims, technical support, or any product-related inquiries, please contact IRIS USA customer service.

For further assistance, please visit the official IRIS USA website or refer to the contact information provided on your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question