

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Baffect](#) /
- › [Baffect Double Sided Magnetic Window Cleaner Instruction Manual](#)

## Baffect Baffect

# Baffect Double Sided Magnetic Window Cleaner Instruction Manual

Brand: Baffect

Model: Baffect (Thickness 18-30mm)

## INTRODUCTION

This manual provides instructions for the safe and effective use of your Baffect Double Sided Magnetic Window Cleaner. This innovative tool allows for efficient cleaning of both sides of windows from indoors, enhancing safety and convenience.

## Key Features

- Double-sided magnetic design for simultaneous indoor and outdoor cleaning.
- Integrated 2.5m safety rope for secure operation.
- Triangular design to reach window corners effectively.
- Detachable and replaceable sponges and squeegee strips.
- Suitable for window glass thickness of 18-30mm.



Image: Baffect Double Sided Magnetic Window Cleaner with its packaging.

## IMPORTANT SAFETY WARNINGS

**WARNING: This product contains strong magnets. Improper handling can cause injury.**

- Always attach the safety rope to your wrist before use.
- Keep the two magnetic halves separated by the plastic separator when not in use to prevent accidental pinching.
- When assembling, gently approach the two halves to avoid sudden magnetic attraction.
- Keep away from children and individuals with pacemakers or other medical implants.
- Ensure the correct model is used for your window thickness to prevent the cleaner from falling or being too difficult to move.
- Do not use on cracked or damaged glass.

# SAFE USE




Image: Diagram illustrating safe handling practices for the magnetic window cleaner, including using the plastic separator and being aware of finger pinching.

## PACKAGE CONTENTS

Verify that all items are present:

- 1 x Baffect Double Sided Magnetic Window Cleaner (18-30mm)
- 1 x 2.5m Safety Rope

- Replacement Sponges
- Replacement Squeegee Strips
- User Manual (this document)

## SETUP AND PREPARATION





### 1. Choosing the Right Cleaner

Before using, accurately measure your window glass thickness to ensure compatibility with the 18-30mm model. Using the wrong thickness can lead to poor performance or the cleaner falling.

Formula: **Window Glass Thickness = Total Frame Length - Inner Frame Thickness - Outer Frame Thickness.**

Refer to the image and video below for visual guidance on measuring.

# HOW TO CHOOSE THE RIGHT WINDOW CLEANER?



**Glass Thickness = Total length of windowpane - Exterior length of windowpane - Internal length of windowpane.**

TYPE	0.08IN 2MM	0.16IN 4MM	0.24IN 6MM	0.31IN 8MM	0.39IN 10MM	0.47IN 12MM	0.55IN 14MM	0.63IN 16MM	0.71IN 18MM	0.79IN 20MM	0.87IN 22MM	0.94IN 24MM	1.02IN 26MM	1.10IN 28MM	1.18IN 30MM
	← 4-30MM (0.16IN-11.8IN) suitable for window thickness in this range →														
										← 18-30MM (0.71IN-1.18IN) suitable for window thickness in this range →					
							← 15-26MM (0.59IN-1.02IN) suitable for window thickness in this range →								
				← 8-15MM (0.31IN-0.59IN) suitable for window thickness in this range →											
	← 3-8MM (0.12IN-0.31IN) suitable for window thickness in this range →														

Image: Visual guide on how to measure window pane thickness for proper cleaner selection.

Video: Official guide on how to correctly select and use the Baffect window cleaner, including measuring glass thickness.

## 2. Opening the Cleaner

To separate the two magnetic halves, rotate them 90 degrees in opposite directions. This method helps to overcome the strong magnetic force safely.

# HOW TO USE



1. Open step: Two side rotate 90° to opposite direction at thr same time in order to open it easily.



2. The brush of triangle sponge was soaked: Let the triangle sponge soaked in the water fully.



3. Put the detergent in the brush of triangle sponge: Two side of triangle sponge are fully and evenly coated with detergent.



4. Keep the safety rope in hand: Prevent the brush failing from high altitude.



5. Open the window: The brush with handle will be placed in the window and the brush with safety rope will be placed out of the window at the same place.



6. Close the window and lateral wipe: Wipe the glass from left to right and then from right to left continuously. The safety rope should be long enough.

Image: Step-by-step visual instructions for opening the magnetic window cleaner by rotating the halves.

## 3. Soaking Sponges and Applying Detergent

Soak the cleaning sponges in water until fully saturated. Apply your preferred window cleaning detergent evenly onto both sponges.

# HOW TO USE



1. Open step: Two side rotate 90° to opposite direction at thr same time in order to open it easily.



2. The brush of triangle sponge was soaked: Let the triangle sponge soaked in the water fully.



3. Put the detergent in the brush of triangle sponge: Two side of triangle sponge are fully and evenly coated with detergent.



4. Keep the safety rope in hand: Prevent the brush failing from high altitude.



5. Open the window: The brush with handle will be placed in the window and the brush with safety rope will be placed out of the window at the same place.



6. Close the window and lateral wipe: Wipe the glass from left to right and then from right to left continuously. The safety rope should be long enough.

Image: Visual guide for soaking the cleaning sponges and applying detergent before use.

## OPERATING INSTRUCTIONS

### 1. Attach Safety Rope

Securely attach the 2.5m safety rope to your wrist. This is a crucial safety step to prevent the outer half from falling if it detaches during cleaning.

# HOW TO USE



1. Open step: Two side rotate 90° to opposite direction at the same time in order to open it easily.




2. The brush of triangle sponge was soaked: Let the triangle sponge soaked in the water fully.



3. Put the detergent in the brush of triangle sponge: Two side of triangle sponge are fully and evenly coated with detergent.



4. Keep the safety rope in hand: Prevent the brush failing from high altitude.



5. Open the window: The brush with handle will be placed in the window and the brush with safety rope will be placed out of the window at the same place.



6. Close the window and lateral wipe: Wipe the glass from left to right and then from right to left continuously. The safety rope should be long enough.

Image: Step showing how to securely attach the safety rope to your wrist.

## 2. Position the Cleaner

Open the window slightly. Place the outer half of the cleaner on the exterior glass, and the inner half (with the handle) on the interior glass, directly opposite each other. The magnets will attract and hold them in place.



Image: The magnetic window cleaner in position on a window, demonstrating its double-sided cleaning capability.

### 3. Cleaning Technique

Move the cleaner slowly across the window surface. For best results and to avoid streaks, move in an "S" shaped pattern or from top to bottom, ensuring the pointed end leads the movement.

# EFFICIENT CLEANING

- 01 Cleaning Sponge
- 02 Absorbent Sponge
- 03 Squeegee




Image: Diagram illustrating the recommended S-shaped cleaning path for optimal results.

# INGENIOUS DESIGNS

BAFFECT

Handle

Powerful Magnet

Absorbent Sponge

Squeegee

Cleaning Sponge

Fixing Button

Separator



Accessories



User Manual



Safety Rope




Image: Diagram illustrating an alternative top-to-bottom cleaning path.

## 4. Finishing

Once cleaning is complete, carefully separate the two halves by rotating them 90 degrees, similar to the opening procedure.

## MAINTENANCE





### Cleaning the Cleaner

After each use, rinse the sponges and squeegee strips thoroughly with clean water to remove dirt and detergent residue. Allow all components to air dry completely before storing.

## Replacing Accessories

The sponges and squeegee strips are detachable and replaceable. To replace, rotate the plastic fastener 90 degrees to release the worn part and insert a new one. Ensure the squeegee is properly seated in its groove.

# HOW TO CHOOSE THE RIGHT WINDOW CLEANER?



**Glass Thickness = Total length of windowpane - Exterior length of windowpane - Internal length of windowpane.**

TYPE	0.08IN 2MM	0.16IN 4MM	0.24IN 6MM	0.31IN 8MM	0.39IN 10MM	0.47IN 12MM	0.55IN 14MM	0.63IN 16MM	0.71IN 18MM	0.79IN 20MM	0.87IN 22MM	0.94IN 24MM	1.02IN 26MM	1.10IN 28MM	1.18IN 30MM
	← 4-30MM (0.16IN-11.8IN) → suitable for window thickness in this range														
										← 18-30MM (0.71IN-1.18IN) → suitable for window thickness in this range					
							← 15-26MM (0.59IN-1.02IN) → suitable for window thickness in this range								
				← 8-15MM (0.31IN-0.59IN) → suitable for window thickness in this range											
	← 3-8MM (0.12IN-0.31IN) → suitable for window thickness in this range														

Image: Visual guide for replacing the cleaning sponges and squeegee strips.

# SAFE USE




Image: Exploded view showing all components of the magnetic window cleaner, including replaceable parts.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cleaner falls off window	Incorrect thickness model for your window; insufficient magnetic force.	Verify your window glass thickness and ensure you are using the correct Baffect model.
Cleaner is difficult to move	Window glass is too thick for the cleaner's magnetic strength; insufficient lubrication (detergent).	Ensure you have the correct model for your window thickness. Apply more window cleaning solution to the glass.
Streaks left on window	Insufficient detergent; sponges/squeegees are dirty or worn; cleaning too fast; improper technique.	Apply more detergent. Clean or replace sponges/squeegees. Move the cleaner slower and use the recommended "S" or top-to-bottom motion.
Magnets are stuck together	Improper separation technique; plastic separator not used for storage.	Always rotate the two halves 90 degrees to separate. Use the plastic separator when storing. Exercise caution to avoid pinching fingers.

## SPECIFICATIONS

Feature	Detail
Brand	Baffect
Model Number	Baffect
Product Dimensions	6.3 x 2.76 x 5.31 inches
Item Weight	10.88 ounces
Recommended Glass Thickness	18-30mm
Item Form	Wipe
Surface Recommendation	Windows
Special Feature	Reusable
Country of Origin	China

## WARRANTY AND SUPPORT

Baffect is committed to providing high-quality products. For any issues or questions regarding your magnetic window cleaner, please contact Baffect customer support.

Refer to the original purchase platform or product packaging for specific warranty details and contact

information.

© 2025 Baffect. All rights reserved.