

## FurReal E0497

# Hasbro FurReal Shaggy Shawn Electronic Pet Instruction Manual

Model: E0497

## INTRODUCTION

Welcome to the world of FurReal Shaggy Shawn! This interactive electronic pet offers a unique grooming experience, allowing children to style its shaggy hair repeatedly. The included buzzing accessory provides tactile and auditory feedback, simulating a real grooming session. Discover various ways to style your terrier pet, from a mohawk to a fancy mustache.

## SAFETY INFORMATION

- **Age Recommendation:** Suitable for ages 4 years and up.
- **Battery Safety:** Use only specified batteries. Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly.
- **Choking Hazard:** Small parts may be generated. Not for children under 3 years.
- **Supervision:** Adult supervision is recommended during play.

## PACKAGE CONTENTS

Your FurReal Shaggy Shawn package includes 3 main pieces:

- 1 x FurReal Shaggy Shawn electronic pet
- 1 x Grooming buzzer accessory
- 3 x LR44 batteries (pre-installed or included separately)

## SETUP

### Battery Installation

1. Locate the battery compartment on the underside of the Shaggy Shawn pet.

2. Using a Phillips head screwdriver (not included), open the battery compartment cover.
3. Insert 3 LR44 batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.



Image: The FurReal Shaggy Shawn electronic pet shown with its grooming buzzer accessory. The pet is a brown and tan terrier with long shaggy hair and a prominent mustache.

## OPERATING INSTRUCTIONS

### Interacting with Shaggy Shawn

- **Power On:** Locate the ON/OFF switch, usually near the battery compartment, and slide it to the "ON" position.
- **Grooming Action:** Use the included buzzer accessory to "groom" Shaggy Shawn's hair. The accessory is designed to emit buzzing sounds and vibrations when pressed against the pet, simulating a real grooming tool.
- **Styling:** Shaggy Shawn's hair is designed to be styled in various ways. You can comb it, create a mohawk, or shape its mustache. The hair can be restyled repeatedly.
- **Petting:** Petting Shaggy Shawn may activate additional sounds or movements, enhancing the interactive experience.



Image: A child interacting with the FurReal Shaggy Shawn, using the grooming accessory to style its hair. The pet is standing on a table.

## MAINTENANCE

---

### Cleaning

- To clean the pet, gently wipe the surface with a damp cloth. Do not immerse the toy in water.
- Avoid using harsh chemicals or abrasive cleaners.
- Allow the toy to air dry completely before storing or further play.

### Storage

- When not in use for extended periods, turn the pet OFF to conserve battery life.
- Store the pet in a clean, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

- **Pet not responding or making sounds:**
  - Ensure the ON/OFF switch is in the "ON" position.
  - Check battery installation. Ensure batteries are inserted with correct polarity.

- Replace with fresh LR44 batteries.
- **Buzzer accessory not vibrating or making sound:**
  - Ensure the accessory is firmly pressed against the pet's hair.
  - The buzzer accessory is mechanical and does not require batteries. If it's not working, inspect for any obstructions or damage.

## SPECIFICATIONS

<b>Model Number</b>	E0497
<b>Brand</b>	FurReal (by Hasbro)
<b>Product Dimensions (L x W x H)</b>	13.31 x 26.7 x 24.1 cm
<b>Product Weight</b>	490 grams
<b>Recommended Age</b>	4 years and up
<b>Batteries Required</b>	Yes
<b>Battery Type</b>	3 x LR44 (included)
<b>Material</b>	Plastic
<b>Number of Pieces</b>	3

## WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Hasbro or FurReal website, or contact their customer service department. Keep your purchase receipt as proof of purchase.

[Visit Hasbro Customer Service](#)